Engineering data sheet

Chapter: 131 - SV Acc

Sheet No.: SV Compensation Hoses

SV22 compensator hoses

Item numbers covered by this datasheet

207051 Hose Dn25-400 0.5m Discharge Elbow
207060 Hose Dn25-400 0.5m Discharge Straight
207061 Hose Dn25-400 1.0m Discharge Straight
207062 Hose Dn25-400 1.5m Discharge Straight
207070 Hose DN32-400 0.5m data in ()
207071 Hose DN32-400 1.0m data in ()

General

The DN25&32 pressure hose is used for connection between the SV22 selector valve and the pipe system to compensate for pipe erection inaccuracies or vibrations.

The hose is used in the Control Inert system as well as with SV22 systems and older INERGEN systems.

Hoses may be delivered in other length by adding "-8" to the part number, here the length of the assembled hose from centre of connection to center of connection must be specified.

Specifications

Tread: 1" (5/4") union w. 60° face (ISO228)

Flow diameter: Ø21.0 (24) mm

Construction: Three-ply steel wire

Temperature: -40°C to +100°C

Bending radius: > 500mm Outside diameter: 45 (55)mm

Pressure

Work pressure: 0 - 400 bar (EN12094-8, Wp<1/3xBp)

Burst pressure: > 1320 bar

Material

Hose: Oil and weather resistant synthetic rubber, two-ply steel

Fitting: Zinc plated steel

Markings

Fittings: ID - ww - yy (ID = place of pressing, ww = week number, yy = year)


Installation

The SV22 must be fastened well so that it will not move during activation.

An adaptor is fitted to the selector valve and the hosed is fastened directly to this adapter.

On the pipe system a suitable pipe adapter must be placed so that the hose can be fastened to this also.

Document: SV Compensation hoses.docx				1	Text
Category:		ld:	MK	3	
SV-CiV system		Rev: 2013	2.01.25	4	
4.4				5	
Vølundsvej 17 DK- 3400 Hillerød				6	
				7	
		+45 702		8	
FIRE EATER 1/s			9		
, ,,,, = = /\ E \ /3					



Page: 1 of 2

Engineering data sheet Chapter: 131 - SV Acc Page: 2 of 2 Sheet No.: SV Compensation Hoses

Related parts

303516	Adapter 1" - 1" ISO	Between SV22 and hose
303508	Adapter 1" - 1" ISO	Between hose and pipe
303517	Adapter 1" - 5/4" ISO	Between hose and pipe
303518	Adapter 1" - 1 1/2" ISO	Between hose and pipe
303519	Adapter 1" -2" ISO	Between hose and pipe
777122	Nipple 1" - ½" ISO-npt	Between hose and pipe system
777124	Nipple 1" - ¾" ISO-npt	Between hose and pipe system
777126	Nipple 1" - 1" ISO-npt	Between hose and pipe system
777128	Nipple 1" - 1 ¼" ISO-npt	Between hose and pipe system
777130	Nipple 1" - 1½" ISO-npt	Between hose and pipe system
777132	Nipple 1" - 2" ISO-npt	Between hose and pipe system

Document: SV Compensation hoses.docx				1	Text
				2	
Category:		ld:	MK	3	
SV-CiV system		Rev:201	2.01.25	4	
44				5	
			_	6	
		lundsvej 17		7	
	DK- 3400 Hillerød Tel +45 7022 2769			8	
FIRE EATER 1/3			9		