2024-11



Fire Eater Control Inert

UL LISTED, FM APPROVED EXTINGUISHING SYSTEM





Ci UL FM manual



 	_	_	
		_	~
			W.
4/1			_
		_	/ 🔪

Chapter 0: Introduction
Safety 3 Environment & Exposure 3
System limitations
CHAPTER 1: SYSTEM COMPONENTS
General4
Item numbers4
Basic components 5
[01] Cylinders: 6
[02] Cylinder rail & Brackets:8
[11] Discharge valve:
[21] Actuators:
[31] Discharge hoses:
[32] Pilot hoses:
[41+42+43] Manifold & Orifice & Accessories:
[54] Fasteners & Pipe hangers:
[61a] Nozzles mono-orifice:
[61b] Nozzles Marine:
[72] Signs & Labels:
[73] Accessories:
[81] Tools:
[92] Control panels: 24
SV system components
[101] SV Zone kit:
[121] SV CiV & Test port:
[122] Pneumatic activation kit: 27 [131] SV Accessories. 28
[141] Manifold kit:
[142] SV22 End plug kit:
[151] Brackets and accessories:
[161] Fittings, adapters and hoses:
Equivalent length & Flow resistance
Equivalent length & Flow resistance
Equivalent length & Flow resistance
CHAPTER 2: SPECIFICATIONS. 35 INERGEN Agent. 35 INERGEN System 35
CHAPTER 2: SPECIFICATIONS. 35 INERGEN Agent 35 INERGEN System 35 Inert gas history 37
CHAPTER 2: SPECIFICATIONS. 35 INERGEN Agent. 35 INERGEN System 35
CHAPTER 2: SPECIFICATIONS. 35 INERGEN Agent 35 INERGEN System 35 Inert gas history 37 The inert gas re-discovery 37 Safety/toxic effect 38 Hypoxia 38
CHAPTER 2: SPECIFICATIONS. 35 INERGEN Agent 35 INERGEN System 35 Inert gas history 37 The inert gas re-discovery 37 Safety/toxic effect 38 Hypoxia 38 Acute adaptation to acute hypoxia 40
CHAPTER 2: SPECIFICATIONS. 35 INERGEN Agent 35 INERGEN System 35 Inert gas history 37 The inert gas re-discovery 37 Safety/toxic effect 38 Hypoxia 38 Acute adaptation to acute hypoxia 40 Hypoxia, hypercapnia, and Carbon Monoxide 41
CHAPTER 2: SPECIFICATIONS. 35 INERGEN Agent 35 INERGEN System 35 Inert gas history 37 The inert gas re-discovery 37 Safety/toxic effect 38 Hypoxia 38 Acute adaptation to acute hypoxia 40 Hypoxia, hypercapnia, and Carbon Monoxide 41 NOAEL/LOAEL 42 Enclosure escape precautions 42
CHAPTER 2: SPECIFICATIONS. 35 INERGEN Agent 35 INERGEN System 35 Inert gas history 37 The inert gas re-discovery 37 Safety/toxic effect 38 Hypoxia 38 Acute adaptation to acute hypoxia 40 Hypoxia, hypercapnia, and Carbon Monoxide 41 NOAEL/LOAEL 42 Enclosure escape precautions 42 Effect on machinery and equipment 43
CHAPTER 2: SPECIFICATIONS. 35 INERGEN Agent 35 INERGEN System 35 Inert gas history 37 The inert gas re-discovery 37 Safety/toxic effect 38 Hypoxia 38 Acute adaptation to acute hypoxia 40 Hypoxia, hypercapnia, and Carbon Monoxide 41 NOAEL/LOAEL 42 Enclosure escape precautions 42 Effect on machinery and equipment 43 Extinguishing efficiency 43
CHAPTER 2: SPECIFICATIONS. 35 INERGEN Agent 35 INERGEN System 35 Inert gas history 37 The inert gas re-discovery 37 Safety/toxic effect 38 Hypoxia 38 Acute adaptation to acute hypoxia 40 Hypoxia, hypercapnia, and Carbon Monoxide 41 NOAEL/LOAEL 42 Enclosure escape precautions 42 Effect on machinery and equipment 43
CHAPTER 2: SPECIFICATIONS. 35 INERGEN Agent 35 INERGEN System 35 Inert gas history 37 The inert gas re-discovery 37 Safety/toxic effect 38 Hypoxia 38 Acute adaptation to acute hypoxia 40 Hypoxia, hypercapnia, and Carbon Monoxide 41 NOAEL/LOAEL 42 Enclosure escape precautions 42 Effect on machinery and equipment 43 Extinguishing efficiency 43 Signs and warnings 43
CHAPTER 2: SPECIFICATIONS. 35 INERGEN Agent 35 INERGEN System 35 Inert gas history. 37 The inert gas re-discovery 37 Safety/toxic effect 38 Hypoxia 38 Acute adaptation to acute hypoxia 40 Hypoxia, hypercapnia, and Carbon Monoxide 41 NOAEL/LOAEL 42 Enclosure escape precautions 42 Effect on machinery and equipment 43 Extinguishing efficiency 43 Signs and warnings 43 References: 44 Material Safety Data Sheet 45 CHAPTER 3: GENERAL INFORMATION 54
CHAPTER 2: SPECIFICATIONS. 35 INERGEN Agent 35 INERGEN System 35 Inert gas history. 37 The inert gas re-discovery 37 Safety/toxic effect 38 Hypoxia 38 Acute adaptation to acute hypoxia 40 Hypoxia, hypercapnia, and Carbon Monoxide 41 NOAEL/LOAEL 42 Enclosure escape precautions 42 Effect on machinery and equipment 43 Extinguishing efficiency 43 Signs and warnings 43 References: 44 Material Safety Data Sheet 45 CHAPTER 3: GENERAL INFORMATION 54 System general 54
CHAPTER 2: SPECIFICATIONS. 35 INERGEN Agent 35 INERGEN System 35 Inert gas history. 37 The inert gas re-discovery 37 Safety/toxic effect 38 Hypoxia 38 Acute adaptation to acute hypoxia 40 Hypoxia, hypercapnia, and Carbon Monoxide 41 NOAEL/LOAEL 42 Enclosure escape precautions 42 Effect on machinery and equipment 43 Extinguishing efficiency 43 Signs and warnings 43 References: 44 Material Safety Data Sheet 45 CHAPTER 3: GENERAL INFORMATION 54 System general 54 Terms and definitions 55
CHAPTER 2: SPECIFICATIONS. 35 INERGEN Agent 35 INERGEN System 35 Inert gas history 37 The inert gas re-discovery 37 Safety/toxic effect 38 Hypoxia 38 Acute adaptation to acute hypoxia 40 Hypoxia, hypercapnia, and Carbon Monoxide 41 NOAEL/LOAEL 42 Enclosure escape precautions 42 Effect on machinery and equipment 43 Extinguishing efficiency 43 Signs and warnings 43 References: 44 Material Safety Data Sheet 45 CHAPTER 3: GENERAL INFORMATION 54 System general 54 Terms and definitions 55 Types of systems 56
CHAPTER 2: SPECIFICATIONS. 35 INERGEN Agent 35 INERGEN System 35 Inert gas history 37 The inert gas re-discovery 37 Safety/toxic effect 38 Hypoxia 38 Acute adaptation to acute hypoxia 40 Hypoxia, hypercapnia, and Carbon Monoxide 41 NOAEL/LOAEL 42 Enclosure escape precautions 42 Effect on machinery and equipment 43 Extinguishing efficiency 43 Signs and warnings 43 References: 44 Material Safety Data Sheet 45 CHAPTER 3: GENERAL INFORMATION 54 System general 54 Terms and definitions 55 Type of Actuation 57 Control panels 57
CHAPTER 2: SPECIFICATIONS. 35 INERGEN Agent 35 INERGEN System 35 Inert gas history 37 The inert gas re-discovery 37 Safety/toxic effect 38 Hypoxia 38 Acute adaptation to acute hypoxia 40 Hypoxia, hypercapnia, and Carbon Monoxide 41 NOAEL/LOAEL 42 Enclosure escape precautions 42 Effect on machinery and equipment 43 Extinguishing efficiency 43 Signs and warnings 43 References: 44 Material Safety Data Sheet 45 CHAPTER 3: GENERAL INFORMATION 54 System general 54 Terms and definitions 55 Type of Actuation 57 Control panels 57 INERGEN FLOW 57
CHAPTER 2: SPECIFICATIONS. 35 INERGEN Agent 35 INERGEN System 35 Inert gas history. 37 The inert gas re-discovery 37 Safety/toxic effect 38 Hypoxia 38 Acute adaptation to acute hypoxia 40 Hypoxia, hypercapnia, and Carbon Monoxide 41 NOAEL/LOAEL 42 Enclosure escape precautions 42 Effect on machinery and equipment 43 Extinguishing efficiency 43 Signs and warnings 43 References: 44 Material Safety Data Sheet 45 CHAPTER 3: GENERAL INFORMATION 54 System general 54 Terms and definitions 55 Type of Actuation 57 Control panels 57 INERGEN FLOW 57 Personal Safety 57
CHAPTER 2: SPECIFICATIONS. 35 INERGEN Agent 35 INERGEN System 35 Inert gas history. 37 The inert gas re-discovery 37 Safety/toxic effect 38 Hypoxia 38 Acute adaptation to acute hypoxia 40 Hypoxia, hypercapnia, and Carbon Monoxide 41 NOAEL/LOAEL 42 Enclosure escape precautions 42 Effect on machinery and equipment 43 Extinguishing efficiency 43 Signs and warnings 43 References: 44 Material Safety Data Sheet 45 CHAPTER 3: GENERAL INFORMATION 54 System general 54 Types of systems 56 Type of Actuation 57 Control panels 57 INERGEN FLOW 57 Personal Safety 57 CHAPTER 4: PLANNING 58
CHAPTER 2: SPECIFICATIONS. 35 INERGEN Agent 35 INERGEN System 35 Inert gas history. 37 The inert gas re-discovery 37 Safety/toxic effect 38 Hypoxia 38 Acute adaptation to acute hypoxia 40 Hypoxia, hypercapnia, and Carbon Monoxide 41 NOAEL/LOAEL 42 Enclosure escape precautions 42 Effect on machinery and equipment 43 Extinguishing efficiency 43 Signs and warnings 43 References: 44 Material Safety Data Sheet 45 CHAPTER 3: GENERAL INFORMATION 54 System general 54 Terms and definitions 55 Type of Actuation 57 Control panels 57 INERGEN FLOW 57 Personal Safety 57
CHAPTER 2: SPECIFICATIONS. 35 INERGEN Agent 35 INERGEN System 35 Inert gas history. 37 The inert gas re-discovery 37 Safety/toxic effect 38 Hypoxia 38 Acute adaptation to acute hypoxia 40 Hypoxia, hypercapnia, and Carbon Monoxide 41 NOAEL/LOAEL 42 Enclosure escape precautions 42 Effect on machinery and equipment 43 Extinguishing efficiency 43 Signs and warnings 43 References: 44 Material Safety Data Sheet 45 CHAPTER 3: GENERAL INFORMATION 54 System general 54 Terms and definitions 55 Type of Actuation 57 Control panels 56 Type of Actuation 57 Control panels 57 INERGEN FLOW 57 Personal Safety 57 CHAPTER 4: PLANNING 58 Fire classes 58 Design concentration 59
CHAPTER 2: SPECIFICATIONS. 35 INERGEN Agent 35 INERGEN System 35 Inert gas history. 37 The inert gas re-discovery 37 Safety/toxic effect 38 Hypoxia 38 Acute adaptation to acute hypoxia 40 Hypoxia, hypercapnia, and Carbon Monoxide 41 NOAEL/LOAEL 42 Enclosure escape precautions 42 Effect on machinery and equipment 43 Extinguishing efficiency 43 Signs and warnings 43 References: 44 Material Safety Data Sheet 45 CHAPTER 3: GENERAL INFORMATION 54 System general 54 Terms and definitions 55 Type of Actuation 57 Control panels 57 INERGEN FLOW 57 Personal Safety 57 CHAPTER 4: PLANNING 58 Fire classes 58 Design concentration 59
CHAPTER 2: SPECIFICATIONS. 35 INERGEN Agent 35 INERGEN System 35 Inert gas history. 37 The inert gas re-discovery 37 Safety/toxic effect 38 Hypoxia 38 Acute adaptation to acute hypoxia 40 Hypoxia, hypercapnia, and Carbon Monoxide 41 NOAEL/LOAEL 42 Enclosure escape precautions 42 Effect on machinery and equipment 43 Extinguishing efficiency 43 Signs and warnings 43 References: 44 Material Safety Data Sheet 45 CHAPTER 3: GENERAL INFORMATION 54 System general 54 Terms and definitions 55 Type of Actuation 57 Control panels 57 INERGEN FLOW 57 Personal Safety 57 CHAPTER 4: PLANNING 58 Fire classes 58 Design concentration 59 General 60 CHAPTER 5: DESIGN 63
CHAPTER 2: SPECIFICATIONS. 35 INERGEN Agent 35 INERGEN System 35 Inert gas history. 37 The inert gas re-discovery 37 Safety/toxic effect 38 Hypoxia 38 Acute adaptation to acute hypoxia 40 Hypoxia, hypercapnia, and Carbon Monoxide 41 NOAEL/LOAEL 42 Enclosure escape precautions 42 Effect on machinery and equipment 43 Extinguishing efficiency 43 Signs and warnings 43 References: 44 Material Safety Data Sheet 45 CHAPTER 3: GENERAL INFORMATION 54 System general 54 Terms and definitions 55 Type of Actuation 57 Control panels 57 INERGEN FLOW 57 Personal Safety 57 CHAPTER 4: PLANNING 58 Fire classes 58 Design concentration 59 General 60 CHAPTER 5: DESIGN 63
CHAPTER 2: SPECIFICATIONS. 35 INERGEN Agent 35 INERGEN System 35 Inert gas history. 37 The inert gas re-discovery 37 Safety/toxic effect 38 Hypoxia 38 Acute adaptation to acute hypoxia 40 Hypoxia, hypercapnia, and Carbon Monoxide 41 NOAEL/LOAEL 42 Enclosure escape precautions 42 Effect on machinery and equipment 43 Extinguishing efficiency 43 Signs and warnings 43 References: 44 Material Safety Data Sheet 45 CHAPTER 3: GENERAL INFORMATION 54 System general 54 Terms and definitions 55 Types of systems 56 Type of Actuation 57 Control panels 57 INERGEN FLOW 57 Personal Safety 57 CHAPTER 4: PLANNING 58 Fire classes 58 Design concentration 59 General 60 <
CHAPTER 2: SPECIFICATIONS. 35 INERGEN Agent 35 INERGEN System 35 Inert gas history. 37 The inert gas re-discovery 37 Safety/toxic effect 38 Hypoxia 38 Acute adaptation to acute hypoxia 40 Hypoxia, hypercapnia, and Carbon Monoxide 41 NOAEL/LOAEL 42 Enclosure escape precautions 42 Effect on machinery and equipment 43 Extinguishing efficiency 43 Signs and warnings 43 References: 44 Material Safety Data Sheet 45 CHAPTER 3: GENERAL INFORMATION 54 System general 54 Terms and definitions 55 Type of Actuation 57 Control panels 57 INERGEN FLOW 57 Personal Safety 57 CHAPTER 4: PLANNING 58 Fire classes 58 Design concentration 59 General 60 CHAPTER 5: DESIGN 63
CHAPTER 2: SPECIFICATIONS. 35 INERGEN Agent 35 INERGEN System 35 Inert gas history. 37 The inert gas re-discovery 37 Safety/toxic effect 38 Hypoxia 38 Acute adaptation to acute hypoxia 40 Hypoxia, hypercapnia, and Carbon Monoxide 41 NOAEL/LOAEL 42 Enclosure escape precautions 42 Effect on machinery and equipment 43 Extinguishing efficiency 43 Signs and warnings 43 References: 44 Material Safety Data Sheet 45 CHAPTER 3: GENERAL INFORMATION 54 System general 54 Terms and definitions 55 Type of Actuation 57 Control panels 57 INERGEN FLOW 57 Personal Safety 57 CHAPTER 4: PLANNING 58 Fire classes 58 Design concentration 59 General 60 CHAPTER 5: DESIGN 63
CHAPTER 2: SPECIFICATIONS 35 INERGEN Agent 35 INERGEN System 35 Inert gas history 37 The inert gas re-discovery 37 Safety/toxic effect 38 Hypoxia 38 Acute adaptation to acute hypoxia 40 Hypoxia, hypercapnia, and Carbon Monoxide 41 NOAEL/LOAEL 42 Enclosure escape precautions 42 Effect on machinery and equipment 43 Extinguishing efficiency 43 Signs and warnings 43 References: 44 Material Safety Data Sheet 45 CHAPTER 3: GENERAL INFORMATION 54 System general 54 Terms and definitions 55 Type of Actuation 57 Control panels 57 INERGEN FLOW 57 Personal Safety 58 Fire classes 58 Design concentration 59 General 60 CHAPTER 5: DESIGN 63 Version number 63

CHAPTER 6: INSTALLATION91

	01
Planning	71 22
[01 + 02] Cylinders & Cylinder rails & Brackets	72
[12] Discharge valve accessories	97 97
[11] Ci IV8 installation	98
[21] Actuators	101
[41-43] Manifold installation	105
[31] Discharge hoses	107
[51 - 54] Distribution piping	109
[1xx] Multizone systems	109 110
CHAPTER 7: TESTING AND COMMISSIONING	111
General	114
Inspection & Test	114
Cylinders	
Discharge valves Manoswitch and Actuators	
Manifolds, Hoses and Zone valves	
Pipe system	117
Nozzles	117
Electrical system	117
Pressure relief	117
Function test	118
Full-scale discharge test	119
Documents to be submitted	119
CHAPTER 8: RESETTING AND RECHARGING	
General	120
Piping and nozzles	
Selector valves	
Pneumatic actuators	
Bleed fitting	120
Discharge valves	120
Recharging cylinders	121
Filling equipment requirements	121
INERGEN, IG541 as per NFPA 2001	122
Filling certificates	124
CHAPTER 9: INSPECTION, SERVICE & MAINTENANCE	. 125
General	125
General Cleaning	125 126
General	126 126
General Cleaning General Pipe system	126 126 126
General Cleaning General Pipe system Nozzles.	126 126 126 126
General Cleaning General Pipe system Nozzles INERGEN® cylinders	126 126 126 126
General Cleaning General Pipe system Nozzles INERGEN® cylinders Discharge valve.	126 126 126 126 126
General Cleaning General Pipe system Nozzles INERGEN® cylinders Discharge valve Inspection	126 126 126 126 126
General Cleaning General Pipe system Nozzles INERGEN® cylinders Discharge valve Inspection General	126 126 126 126 126 127
General Cleaning General Pipe system Nozzles INERGEN® cylinders Discharge valve Inspection	126 126 126 126 126 127 127
General Cleaning General Pipe system Nozzles INERGEN® cylinders Discharge valve Inspection General 0 Information	126 126 126 126 127 127 127
General Cleaning General Pipe system Nozzles INERGEN® cylinders Discharge valve Inspection General 0 Information 1. Room 2. Cylinders 3. Control systems	126 126 126 126 126 127 127 127 128
General Cleaning General Pipe system Nozzles. INERGEN® cylinders. Discharge valve. Inspection General 0 Information 1. Room 2. Cylinders 3. Control systems 4. Discharge valve	126 126 126 126 126 127 127 127 128 128
General Cleaning General Pipe system Nozzles. INERGEN® cylinders. Discharge valve. Inspection General 0 Information 1. Room 2. Cylinders 3. Control systems 4. Discharge valve 5. Manoswitch	126 126 126 126 126 127 127 127 128 128 128
General Cleaning General Pipe system Nozzles INERGEN® cylinders Discharge valve. Inspection General 0 Information 1. Room 2. Cylinders 3. Control systems 4. Discharge valve 5. Manoswitch 6. Actuators	126 126 126 126 126 127 127 127 128 128 128
General Cleaning General Pipe system Nozzles INERGEN® cylinders Discharge valve. Inspection General 0 Information 1. Room 2. Cylinders 3. Control systems 4. Discharge valve 5. Manoswitch 6. Actuators 7. Hoses	126126126126126127127127128128128128
General Cleaning General Pipe system Nozzles INERGEN® cylinders Discharge valve. Inspection General 0 Information 1. Room 2. Cylinders 3. Control systems 4. Discharge valve 5. Manoswitch 6. Actuators	126126126126126127127127128128128128
General Cleaning General Pipe system Nozzles INERGEN® cylinders Discharge valve Inspection General 0 Information 1. Room 2. Cylinders 3. Control systems 4. Discharge valve 5. Manoswitch 6. Actuators 7. Hoses 8. Manifolds 9. Pipe-system 10. Nozzles	126126126126127127127128128128128129129
General Cleaning General Pipe system Nozzles INERGEN® cylinders Discharge valve Inspection General 0 Information 1. Room 2. Cylinders 3. Control systems 4. Discharge valve 5. Manoswitch 6. Actuators 7. Hoses 8. Manifolds 9. Pipe-system 10. Nozzles 11. Signalling devices	126126126126126127127127128128128128129129
General Cleaning General Pipe system Nozzles INERGEN® cylinders Discharge valve. Inspection General 0 Information 1. Room 2. Cylinders 3. Control systems 4. Discharge valve 5. Manoswitch 6. Actuators 7. Hoses 8. Manifolds 9. Pipe-system 10. Nozzles 11. Signalling devices 12. Pressure relief	126126126126127127127128128128129129
General Cleaning General Pipe system Nozzles. INERGEN® cylinders. Discharge valve. Inspection General 0 Information 1. Room 2. Cylinders 3. Control systems 4. Discharge valve 5. Manoswitch 6. Actuators 7. Hoses. 8. Manifolds 9. Pipe-system 10. Nozzles 11. Signalling devices 12. Pressure relief 14. Selector valves.	
General Cleaning General Pipe system Nozzles. INERGEN® cylinders. Discharge valve. Inspection General 0 Information 1. Room 2. Cylinders 3. Control systems 4. Discharge valve 5. Manoswitch 6. Actuators. 7. Hoses. 8. Manifolds. 9. Pipe-system 10. Nozzles. 11. Signalling devices 12. Pressure relief 14. Selector valves. 15. Non-return valves	
General Cleaning General Pipe system Nozzles INERGEN® cylinders Discharge valve Inspection General 0 Information 1. Room 2. Cylinders 3. Control systems 4. Discharge valve 5. Manoswitch 6. Actuators 7. Hoses 8. Manifolds 9. Pipe-system 10. Nozzles 11. Signalling devices 12. Pressure relief 14. Selector valves 15. Non-return valves 16. Bleed fitting	
General Cleaning General Pipe system Nozzles IINERGEN® cylinders Discharge valve. Inspection General 0 Information 1. Room 2. Cylinders 3. Control systems 4. Discharge valve 5. Manoswitch 6. Actuators 7. Hoses 8. Manifolds 9. Pipe-system 10. Nozzles 11. Signalling devices 12. Pressure relief 14. Selector valves. 15. Non-return valves 16. Bleed fitting 17. Additional system inspections	
General Cleaning General Pipe system Nozzles INERGEN® cylinders Discharge valve Inspection General 0 Information 1. Room 2. Cylinders 3. Control systems 4. Discharge valve 5. Manoswitch 6. Actuators 7. Hoses 8. Manifolds 9. Pipe-system 10. Nozzles 11. Signalling devices 12. Pressure relief 14. Selector valves 15. Non-return valves 16. Bleed fitting	
General Cleaning General Pipe system Nozzles. INERGEN® cylinders. Discharge valve. Inspection General 0 Information 1. Room 2. Cylinders 3. Control systems 4. Discharge valve 5. Manoswitch 6. Actuators 7. Hoses. 8. Manifolds. 9. Pipe-system 10. Nozzles 11. Signalling devices 12. Pressure relief 14. Selector valves. 15. Non-return valves 16. Bleed fitting. 17. Additional system inspections 18. Final Service & Maintenance General	
General Cleaning General Pipe system Nozzles INERGEN® cylinders Discharge valve Inspection General 0 Information 1. Room 2. Cylinders 3. Control systems 4. Discharge valve 5. Manoswitch 6. Actuators 7. Hoses 8. Manifolds 9. Pipe-system 10. Nozzles 11. Signalling devices 12. Pressure relief 14. Selector valves 15. Non-return valves 16. Bleed fitting 17. Additional system inspections 18. Final Service & Maintenance General Check list	
General Cleaning General Pipe system Nozzles INERGEN® cylinders Discharge valve Inspection General 0 Information 1. Room 2. Cylinders 3. Control systems 4. Discharge valve 5. Manoswitch 6. Actuators 7. Hoses 8. Manifolds 9. Pipe-system 10. Nozzles 11. Signalling devices 12. Pressure relief 14. Selector valves 15. Non-return valves 16. Bleed fitting 17. Additional system inspections 18. Final Service & Maintenance General Check list Certification of Service & Maintenance	
General Cleaning General Pipe system Nozzles INERGEN® cylinders Discharge valve Inspection General 0 Information 1. Room 2. Cylinders 3. Control systems 4. Discharge valve 5. Manoswitch 6. Actuators 7. Hoses 8. Manifolds 9. Pipe-system 10. Nozzles 11. Signalling devices 12. Pressure relief 14. Selector valves 15. Non-return valves 16. Bleed fitting 17. Additional system inspections 18. Final Service & Maintenance General Check list Certification of Service & Maintenance CHAPTER 10: Typical installations	126126126126127127127127128128128128129129129129129129129130131131131131131
General Cleaning General Pipe system Nozzles IINERGEN® cylinders Discharge valve. Inspection General 0 Information 1. Room 2. Cylinders 3. Control systems 4. Discharge valve 5. Manoswitch 6. Actuators 7. Hoses 8. Manifolds 9. Pipe-system 10. Nozzles 11. Signalling devices 12. Pressure relief 14. Selector valves. 15. Non-return valves 16. Bleed fitting 17. Additional system inspections 18. Final Service & Maintenance General Check list Certification of Service & Maintenance CHAPTER 10: Typical installations Single cylinder system	
General Cleaning General Pipe system Nozzles INERGEN® cylinders Discharge valve. Inspection General 0 Information 1. Room 2. Cylinders 3. Control systems 4. Discharge valve 5. Manoswitch 6. Actuators 7. Hoses 8. Manifolds 9. Pipe-system 10. Nozzles 11. Signalling devices 12. Pressure relief 14. Selector valves 15. Non-return valves 16. Bleed fitting 17. Additional system inspections 18. Final Service & Maintenance General Check list Certification of Service & Maintenance CHAPTER 10: TYPICAL INSTALLATIONS Single cylinder w/ nozzle.	126126126126127127127127127127128128128128129129129129129129130131131131131131131131131131131
General Cleaning General Pipe system Nozzles. INERGEN® cylinders. Discharge valve. Inspection General 0 Information 1. Room 2. Cylinders 3. Control systems 4. Discharge valve 5. Manoswitch 6. Actuators 7. Hoses 8. Manifolds 9. Pipe-system 10. Nozzles 11. Signalling devices 11. Pressure relief 14. Selector valves 15. Non-return valves 16. Bleed fitting 17. Additional system inspections 18. Final Service & Maintenance General Check list Certification of Service & Maintenance CHAPTER 10: TYPICAL INSTALLATIONS Single cylinder system Single cylinder system Single cylinder w/ nozzle Single manifold system Single cylinder system Single cylinder w/ nozzle Single manifold system	126126126126126127127127127127128128128128128129129129129129129130131131131131131
General Cleaning General Pipe system Nozzles. INERGEN® cylinders Discharge valve. Inspection General 0 Information 1. Room 2. Cylinders 3. Control systems 4. Discharge valve 5. Manoswitch 6. Actuators 7. Hoses. 8. Manifolds 9. Pipe-system 10. Nozzles 11. Signalling devices 12. Pressure relief 14. Selector valves 15. Non-return valves 16. Bleed fitting 17. Additional system inspections 18. Final Service & Maintenance General Check list Certification of Service & Maintenance CHAPTER 10: TYPICAL INSTALLATIONS Single cylinder w/ nozzle. Single manifold system Multiple manifold system Multiple manifold system Multiple manifold system Multiple manifold system	
General Cleaning General Pipe system Nozzles INERGEN® cylinders Discharge valve Inspection General 0 Information 1. Room 2. Cylinders 3. Control systems 4. Discharge valve 5. Manoswitch 6. Actuators 7. Hoses 8. Manifolds 9. Pipe-system 10. Nozzles 11. Signalling devices 12. Pressure relief 14. Selector valves. 15. Non-return valves 16. Bleed fitting 17. Additional system inspections 18. Final Service & Maintenance General Check list Certification of Service & Maintenance CHAPTER 10: TYPICAL INSTALLATIONS Single cylinder system Single manifold system Multiple manifold system I Multiple manifold system I Multiple manifold system I	126126126127127127127127128128128128129129129129129129129129130131131131131131131131131131131131
General Cleaning General Pipe system Nozzles. INERGEN® cylinders Discharge valve. Inspection General 0 Information 1. Room 2. Cylinders 3. Control systems 4. Discharge valve 5. Manoswitch 6. Actuators 7. Hoses. 8. Manifolds 9. Pipe-system 10. Nozzles 11. Signalling devices 12. Pressure relief 14. Selector valves 15. Non-return valves 16. Bleed fitting 17. Additional system inspections 18. Final Service & Maintenance General Check list Certification of Service & Maintenance CHAPTER 10: TYPICAL INSTALLATIONS Single cylinder w/ nozzle. Single manifold system Multiple manifold system Multiple manifold system Multiple manifold system Multiple manifold system	



CHAPTER 0: INTRODUCTION

This manual is to be used for Designing, Installing, Operating and Servicing Fire Eater INERGEN fire suppression system: Ci INERGEN and SV (respectively Stand-alone system and Multi-zone system).

This manual is based on the various system requirements set forth by below standards and authorities:

IMO	International Marine Organization	MS/Circ 848, 1267, ao
	Classification societies	FSS code
RMRS	Russian Maritime Register of Shipping	
DNV	Det Norske Veritas	
ABS	American Bureau of Shipping	
BV	Bureau Veritas	
UL	Underwriters Laboratories	UL 2127
FΜ	FM Global	FM 5600
LPCB	Loss Prevention Certification Board	LPS 1230
	BRE Global	
CNPP	Center National Prevention et Protection	A2P
CNBOP	Centrum Naukowo Badawcze Ochrony	No 20(X 198 pos 4)
VNIIPO	·	
TFRI	Tanjin Fire Research Institute	GB25972
NFPA 2001		
EN15004		
ISO14520		

This manual replaces all previously issued manuals.

Units in the manual are SI units if no other designation is given (other derived measures like Bar and mm are also used).

Fire Eater Ci INERGEN system is to be Designed, Installed and Serviced only by personnel who has been properly trained by Fire Eater and have obtained a Fire Eater Diploma passing the required test where applicable. Diplomas are valid for 3 years from date of issuing.

Fire Eater assumes no responsibility for applications of any system other than those addressed in this manual. The technical data in this manual is for information purposes only.

Only original Fire Eater parts should be used in the system. Replacing components with inferior parts can have fatal consequences.

Refilling of INERGEN cylinders is only to be done by a Fire Eater certified filling station.

File: Ci Manual 2024-11 Page 2 of 143



Safety

INERGEN fire extinguishing systems uses equipment under high pressure (up to 400 bar / 40MPa / 5800 psi). Any person installing or servicing these systems must be aware of the safety issues in order to avoid any dangerous situation.

- Never handle, move or leave unfastened a cylinder without the valve protection cap.
- Never leave a cylinder standing unsecured from falling.
- Valve caps are not to be used as a lifting device.
- Secure cylinder properly for pressure bleed-off, Outlet force may exceed 2000N (500lbs f)
- Wear safety glasses and safety shoes.

When transporting

- Observe transportation rules (ADR and other).
- Cylinders next to driver cabin should be parallel with vehicle axels or standing up.
- Ensure proper shipping documents.

Environment & Exposure

INERGEN is a mix of normal atmospheric gasses (without Oxygen), and does not cause any decomposition product when exposed to temperatures of up to $2000\,^{\circ}\text{C}$ (3500 $^{\circ}\text{F}$), neither will the gas have any negative influence on equipment or materials which can be operated in normal office environment.

As INERGEN only consist of atmospheric gasses, full-scale testing can be performed without concerns about environmental impact.

System limitations

This manual describes how to design, install and service a Fire Eater INERGEN system in a closed room with presence of the fuels described in chapter 4.

These are the INERGEN systems which rules are set out for what the system is tested, however this is not necessarily the limit of the system. If a system is to be used for another application or with limits outside what is described in this manual, special considerations should be made how to ensure a safe and effective system and which test should be made to prove the efficiency of the system. Below exclusions are only exclusions of the manual, but not exclusions for fire suppression by the INERGEN system.

This manual does not cover:

Extinguishing of metals or oxygenized material.

Design of explosion suppression INERGEN systems.

If the system is installed to protect a hazard that is already protected by another fire suppression system, special considerations must be made with regards to safe functioning of the system, (typical, but not limited to: Low oxygen concentration, high room pressure, decomposition products, interaction of agents, obscurity).

File: Ci Manual 2024-11 Page 3 of 143



CHAPTER 1: SYSTEM COMPONENTS

The system consists of:

01 Cylinder w INERGEN Storage of INERGEN including hand wheel valve and INERGEN.

02 Cylinder rail & bracket For fixing cylinders.

11 Discharge valve A quick release valve fitted at installation site.

12 Discharge valve acc. Cables electrical low pressure alarm.

Tees

21 Actuator(s) For actuating the quick release valve.

31 Discharge hoses Leading INERGEN from disch. valve to manifold. DN 10 (3/8")

32 Pilot hoses For activating discharge valves. DN6 (1/4")
41 Manifold Gathering INERGEN from multiple cylinders.

42 Orifice Reducing cylinder pressure to desired pipe pressure.

51 Pipes Distributing the INERGEN to the nozzles.

52 Pipe fittings

53 Brackets54 Fasteners

61 Nozzles Distributing INERGEN in a single enclosure.
71 Pressure Relief To prevent over-pressurization during discharge

72 Signs & Labels

73 Acc. Accessories

81 Tools82 Service kit

91 Remote Mech. actuation Pneumatic Discharge Systems, Wire & Pull stations

92 Control panels

Multizone system component

101 SV Zone kit
 121 SV CiV
 122 SV-Ci next kit
 123 SV-Ci next kit
 124 SV-Ci next kit
 125 SV-Ci next kit
 126 Selector valve with brackets, Inlet, Orifice and fittings Control valve to open designated Selector valve
 126 Connectors for the Pneumatic Actuation system

Test port

131 SV Switch kit Electrical monitoring of the SV position
 141 SV MT kit Manifolds w. Non-Return valve and outlet

142 SV End plug kit Fittings and Burst disc for the distribution manifold

151 Brackets and accessories

161 Fittings & Adapters

181 Tools Test and Resetting tools

General

Item numbers

The item numbers used, consists of 6-8 digits. Numbers after "-" describes a variant. Variants can be special requirements, certificates or handling. Typical variants are (not limited to these):

-8: Customer specific versions Calibrated

Calibrated devices like nozzles etc.

-21: DNV

-23: EAC (GOST)

-44: AISI 316

-62: CCOE

-60: UL

-62: FM

-71: LPCB

Notice items with above extension are only available when required due to specific circumstances like special marking, certificate, datasheets and similar required by the authorities etc.

File: Ci Manual 2024-11 Page 4 of 143



Basic components

[00] INERGEN:

INERGEN is a clear inert gas consisting of Nitrogen, Argon and Carbon dioxide, which all are natural atmospheric gasses, stored in high pressure cylinders as permanent gas (no condensation).

Composition (% volume)


Nitrogen 52 %
Argon 40 %
Carbon dioxide 8%

Molar mass 34.08 g/mol

Specific vapor volume $0.706 \text{ m}^3/\text{kg}$ (t = 20°C , p = 1.0132 bar)

INERGEN/Air (relative) $\rho r = 1.18$ (t = 20°C, p = 1.0132 bar)

Triple point of CO₂ @ 5.2 atm and -56.4°C



DIRECTIVES, STANDARDS, AND CONFORMITY MARKINGS

INERGEN gas is covered by:

EEC 89/106 Construction Product Directive (CPD)

EEC 305/2011 Construction Product Regulation (CPR)

Conformity mark: NA

Standards applied are:

EN15004 NFPA 2001

Additional approvals:

TA UL file Ex15566, vol4

TA LPCB LPS1230

TA FM

File: Ci Manual 2024-11 Page 5 of 143



Ci Cylinders (latest edition)

[01] Cylinders:

The cylinders are factory filled with INERGEN agent and fitted with a hand wheel valve. Hand wheel valve outlet threads:

200 bar system W24.32 (Black hand wheel) 300 bar system M25×1.5 (Green hand wheel)

Each hand wheel valve is fitted with a burst disc to prevent cylinder explosion if the cylinder is left in a fire or exposed to elevated temperatures.

Hand wheel valves are installed in accordance with ISO 13341.

The cylinders are transported with a protective cap, which is not to be removed before installation.

DESIGNATION	Pres	SSURE	INERGI	EN™
	Fill	Operating	Volume	Mass
	MPa @ 15°C	MPa @ 15°C	m³ @ 21°C	kg
30-300	30	31.0	8.7	12.4
50-300	30	31.0	14.6	20.7
80-300	30	31.0	23.3	33.1
140-300	30	31.0	40.8	58.0
30-200	20	20.6	6.3	8.9
50-200	20	20.6	10.5	14.9
80-200	20	20.6	16.8	23.8
140-200	20	20.6	29.4	41.7

Other sizes from 2 liter are also available, see datasheet Ci Cylinders

ITEM NUMBERS	DATASHEET
Below cylinders are available as -21 DNV &-71 LPCB	
30, 50, 80 and 140L cylinders are available as -60 UL & -62	2 FM
On request cylinders can be supplied as -23 CU-TR (former	GOST), -25
BV26 CCOE27 Australian, et al.	•

BV, -26 (LCOE, -2/ Australian, et al.
200609	Cylinder 30-300 M25
200615	Cylinder 50-300 bar M25
200624	Cylinder 80-300 bar M25
2004 42	Culindar 140 200 har M2E (no

Cylinder 140-300 bar M25 (per 2014 not yet available as DNV) 200642

200600	Cylinder 02-200 W24
200601	Cylinder 05-200 W24
200602	Cylinder 10-200 W24
200604	Cylinder 20-200 W24
200610	Cylinder 50-200 W24
200616	Cylinder 80-200 W24

200628 Cylinder 140-300 bar M25 (per 2014 not yet available as DNV)

20101X	Cylinders available in China only	CCC - Cylinders
603xxx	Hand wheel valves	Ci HWV Hand wheel valve
105106 105130 10513x	Cylinder cap E-type (open) 160kg Cylinder cap S-type EN962 160kg Cylinder cap S-type EN962 300kg	105106 Cylinder cap open 105130 Cylinder cap S type Cylinder cap S type

INSTALLATION

The cylinder is fixed to the cylinder rail by using the cylinder brackets.

For land systems, minimum 1 rail/bracket for each cylinder. For marine, 2 are required.

If nozzles are placed directly on the discharge valve, 2 brackets must be used.

Other types of fixations are acceptable under the condition that they can hold the forces from the cylinders.

File: Ci Manual 2024-11 Page 6 of 143



DIRECTIVES, STANDARDS, AND CONFORMITY MARKINGS

Cylinders are covered by:

1999/36/EC Transportable Pressure Equipment (TPED)

2010/35/EC Update of above

Conformity mark: π , ρ

Standards applied are:

EN1964-1, EN1964-2 ISO9809-1, ISO9809-2

Hand wheel valves are covered by:

EEC 99/36 Transportable Pressure Equipment (TPED)

2010/35/EC Update of TPED

EEC 89/106 Construction Product Directive (CPD)
EEC 305/2011 Construction Product Regulation (CPR)

Conformity mark:

CE

Standards applied are:

ISO5145 Cylinder valve outlets for gasses

ISO1117, ISO10297

EN12094-4 Fixed firefighting systems valves

File: Ci Manual 2024-11 Page 7 of 143



[02] Cylinder rail & Brackets:

For fixing the cylinder a rail and cylinder bracket are used. The length of the rail is determined by the quantity of cylinders. Cylinders are to be floor supported.

Wooden brackets are also available.

	ers (NOT LIMITED TO THESE NUMBERS) Nilable in aisi316 with item number -44	DATA SHEET
400108 400109 400110	Cylinder bracket 140l (ø360) Cylinder bracket 80l (ø267) Cylinder bracket 50/30l (ø229)	4001## Cylinder brackets 5-140l
400121	Cylinder rail end covers	400121 Cylinder rail end cover
400123	Elbow for cylinder in 2 nd layer	400123 Bracket 2 nd layer
400102 40020n 40030n 40040n	Cyl rail 3000 Cyl rail nx50l nx270 mm Cyl rail nx80l nx320 mm Cyl rail nx140l nx400+200 mm	400XXX Cylinder rail 50-80-140l
105100 105101 105102 105103 105104	Rack Top 50l U-profile Rack Bottom 50l U-profile Rack Cross beam 4x50l Rack Outer beam 4x50l Rack Cyl dummy 50l	Rack U-profiles Rack Beams Rack Cylinder dummy
105200 105201 105202 105203 105204	Rack Top 80l U-profile Rack Bottom 80l U-profile Rack Cross beam 4x80l Rack Outer beam 4x80l Rack Cyl dummy 80l	Rack U-profiles Rack Beams Rack Cylinder dummy
105107 3852003 105109 105113	Treaded Rod M12 Nut M12 Washer M12 Washer M12 Split washer	105107 screw nuts screw washers screw washers

INSTALLATION

Cylinder rails are fixed to a construction using either screws, rivets or welding. Fixing should be at intervals sufficient to carry the load from the cylinders.

Fasteners must be in accordance with section 54.

For marine installations, a minimum of 2 brackets are required per cylinder to prevent displacement of the cylinder when the ship is at sea.

For cylinders in multiple rows, there must be sufficient brackets (400123) to support the load from the cylinders. Typically, 1 bracket per 2 cylinders + one at the end.

DIRECTIVES, STANDARDS, AND CONFORMITY MARKINGS

NA

File: Ci Manual 2024-11 Page 8 of 143
Date: 2024-11-01



[11] Discharge valve:

The discharge valve is supplied (depending on type ordered) complete with a combined pressure gauge and pressure switch, the switches can be connected in a daisy chain.

It is a quick opening valve, which requires manual resetting.

The discharge valve is installed on site after the cylinder has been securely fixed.

The actuator is fitted to the discharge valve after installation and pressurization of the valve.

The valve has a built-in actuator that operates by back pressure. Valves connected to a Ci MT manifold will open once the master cylinder connected to the manifold is activated.

ITEM NUMBERS (NOT LIMITED TO THESE NUMBERS)

DATA SHEET

Ci IV8 discharge valve

The Ci IV8 valves are included in all system approvals (LPCB, CNPP,

CNBOP, DNV, etc.)

Variants available: -60 UL, -62 FM

305410 Ci IV8-300 Manosw 305411 Ci IV8-300 Basic

305420 Ci IV8-200 Manosw

305421 Ci IV8-200 Basic

INSTALLATION

After the cylinder is fixed, the valve protection cap is removed, and the discharge valve is screwed to the hand wheel valve.

After fitting the discharge valve, the hand wheel valve must be opened and sealed in open position.

Attention should be made to the system pressure, as different valve connection treads are used.

200 bar Black hand wheel Chamfered hex union nut 300 bar Green hand wheel Rounded hex union nut

Directives, Standards, and conformity markings

Discharge valves are covered by:

EEC 89/106 Construction Product Directive (CPD)
EEC 305/2011 Construction Product Regulation (CPR)

97/36/EC Pressure Equipment Directive

Conformity mark:

CF

Wheel mark

Standards applied are:

EN12094-4

Additional approvals:

TAC DNV P-14652

File: Ci Manual 2024-11 Page 9 of 143



[12] Discharge valve Accessories:

Accessories for the discharge valves are Manoswitch start kits, the difference between the item numbers is the resistance of the end of line resistor, which has to match the control panel specification.

The DV7 is a Tee, which allows for 2 or 3 discharge valves to be fitted to one cylinder. This is used when multiple zones are protected by a common INERGEN cylinder. (It is used for the same purpose as the Selector valves but is more feasible for small systems).

ITEM NUMBERS (NOT LIMITED TO THESE NUMBERS)	DATA SHEET
The DV7 is included in all system approvals (LPCB, CNPP, CNBOP,	
DNV, etc.) Variants available: -60 UL, -62 FM	
303042 DV7a-2 W24 (200 bar)	DV7
303043 DV7a-3 W24 (200 bar)	
304042 DV7a -2 M25 (300 bar)	
304043 DV7a -3 M25 (300 bar)	
Electrical accessories 303020 Manoswitch cable 2m start kit	Manoswitch Start Kit
303019 Manoswitch 4K7 cable 2m start kit	manoswicen scare inc
540360 Manoswitch 470-5K6 cable 2m start kit 540361 Manoswitch 680-3K3 cable 2m start kit 540362 Manoswitch 470-10K0 cable 2m start kit 540363 Manoswitch 100-200 Ohm cable 2m start kit	54036# Manosw dual resist cable kit
303004 Cable 0.6m M8-3 (manoswitch extension cable) 303005 Cable 1.0m M8-3 (manoswitch extension cable) 303006 Cable 2.0m M8-3 (manoswitch extension cable)	Cable M8-3 extension (Manosw)
303007 Connector Female M8-3 Field attachable 303010 Connector Male M8-3 Field attachable	Cable M8-3 accessories

INSTALLATION

The DV7 is fitted to the cylinder before the discharge valves are installed. Each outlet of the DV7 must have a discharge valve fitted.

The Manoswitch start kit is used for connecting the first manoswitch to the control panel and a terminator to use on the last manoswitch (ending the daisy chain).

Cables and connectors are standard industrial M8-3 connectors used for extending the reach of the M8 cable supplied with the manoswitch.

DIRECTIVES, STANDARDS, AND CONFORMITY MARKINGS

Discharge valves are covered by:

EEC /73/23 Low voltage directive

Conformity mark: NA

Standards applied are: NA

File: Ci Manual 2024-11 Page 10 of 143



[21] Actuators:

Besides the built-in Pneumatic actuator, a variety of actuators are available for the Ci system.

All actuators are screwed on to the actuator connection of the IV8 valve by hand (tightening torque of 10 Nm should not be exceeded).

The Pneumatic actuator has an actuator connection on the top allowing for stacking of another actuator.

ITEM NUMBERS (NOT LIMITED TO THESE NUMBERS) Solenoid actuators are available in -60 UL, -62 FM		DATA SHEET
305451 305450	Ci IS8B w manual Electrical actuator Ci IS8B Solenoid only Electrical actuator	Ci IS8B
305449	Ci IS8 NFPA switch	305449 Ci IS8 NFPA Switch
305442	Ci IM8 Manual actuator	305442 IM8 Manual Actuator
305448	Ci PA8 Pneumatic actuator (add on)	305448 PA8 Pneumatic Actuator
305454 305447	MPW M20 (not CPR per 2014) Ci PALP (not CPR per 2014)	
305621	Ci MT next kit (350mm)	305621 Ci MT next kit
54035x	Ci Junction box	54035x

INSTALLATION

Actuators should be fitted by hand (max 10Nm), Actuators may be screwed back max ½ turn to achieve correct position. Only one additional actuator may be fitted to the Ci PA8.

Before installing the electrical actuator, the Ci IS8 NFPA switch must be fitted to the master cylinder/valve but slipping it onto the valve and tighten the screw to prevent it from coming loose.

Special tools are required to test and reset the actuators.

When a system consists of more than one manifold, the Ci MT next kit (305621) is used to feed pressure from a discharge valve to activate a discharge valve on the next manifold. This principle is continued for additional manifolds.

As each activated discharge valve supplies its own pressure, the number of cylinders activated this way is unlimited.

The Ci Junction box features duplicate terminals for wire connections, for connecting the solenoid, solenoid switch, low pressure switch and manifold pressure to the control panel.

If other arrangements are made, they must have duplicate terminals or leads, or an equivalent arrangement, shall be provided for circuits of products intended to be connected to initiating-device circuits of a releasing control unit; one for each incoming and one for each outgoing wire.

DIRECTIVES, STANDARDS, AND CONFORMITY MARKINGS

Actuators are covered by:

EEC 89/106 Construction Product Directive (CPD) EEC 305/2011 Construction Product Regulation (CPR)

97/36/EC Pressure Equipment Directive

EEC 73/23 Low voltage directive

Conformity mark:

CE

Standards applied are:

EN12094-4

Additional approvals:

TA UL file EX15566, vol 2

File: Ci Manual 2024-11 Page 11 of 143



[31] Discharge hoses:

The discharge hose is a flexible connector between the discharge valve and the manifold. It has 2 functions, one is to lead INERGEN from the discharge valve to the manifold, the second one is to supply pressure from the manifold to activate the discharge valves.

Several different lengths of the discharge hoses are available as standard.

The 3031XX series has one 90° elbow connector and one straight connector			
THE JOSTAN S	erres has one 70 elbow connector and one straight connec		
303102	Hose 0.5m Dn10-400 elbow	Ci Discharge hoses	
303104	Hose 1.0m Dn10-400 elbow		
303106	Hose 1.5m Dn10-400 elbow		
303108	Hose 2.0m Dn10-400 elbow		
303109	Hose 2.5m Dn10-400 elbow		
303111	Hose 3.0m Dn10-400 elbow		
303113	Hose 4.0m Dn10-400 elbow		
The 3033XX series has two straight connectors			
303302	Hose 0.5m Dn10 -400 straight	Ci Discharge hoses	
303304	Hose 1.0m Dn10 -400 straight	•	
303306	Hose 1.5m Dn10 -400 straight		
303308	Hose 2.0m Dn10 -400 straight		
303309	Hose 2.5m Dn10 -400 straight		
303311	Hose 3.0m Dn10 -400 straight		
303313	Hose 4.0m Dn10 -400 straight		

INSTALLATION

Hoses are connected and tightened at the discharge valve first and then connected to the manifold. The Hose must be tightened until metallic contact is achieved and then additional 15°.

DIRECTIVES, STANDARDS, AND CONFORMITY MARKINGS

Hoses are covered by

EEC 89/106 Construction Product Directive (CPD) Construction Product Regulation (CPR) EEC 305/2011 97/36/EC Pressure Equipment Directive

2009/26/EC Marine Equipment Directive (MED

Conformity mark:

CE

Wheel mark

Standards applied are:

EN12094-8 Type 1 & 3 connector ISO 15540 ISO 15541

File: Ci Manual 2024-11 Page 12 of 143



[32] Pilot hoses:

The pilot hose is a flexible connector used for activating the discharge valve by pneumatic pressure. It is used when more than one manifold is used or when the back-pressure function is disabled, it may also be used when a remote pneumatic activation system is used.

Several different lengths of the pilot hoses are available as standard.

ITEM NUMBI	ERS (NOT LIMITED TO THESE NUMBERS)	DATASHEET NO.	
303162	Hose 0.180m Dn6-400	Ci-Hoses PA	
303166	Hose 0.220m Dn6-400		
303172	Hose 0.280m Dn6-400		
303174	Hose 0.330m Dn6-400		
303180	Hose 0.500m Dn6-400		
205064	Hose 0.400m Dn6-400		
205063	Hose 1.000m Dn6-400		
303182	Hose 1.000m 0+90° Dn6-400	Ci-Hoses PA2	
303183	Hose 3.000m 0+90° DN6-400		
303184	Hose 0.400m 0+90° Dn6-400		
303155	Hose 0.350m 2×90° Dn6-400	Ci-Hoses PA3	

INSTALLATION

The hose must be tightened until metallic contact is achieved and then an additional 15°.

DIRECTIVES, STANDARDS, AND CONFORMITY MARKINGS

Hoses are covered by:

EEC 89/106 Construction Product Directive (CPD)
EEC 305/2011 Construction Product Regulation (CPR)
97/36/EC Pressure Equipment Directive

97/36/EC Pressure Equipment Directive 2009/26/EC Marine Equipment Directive (MED

Conformity mark:

CE

Wheel mark

Standards applied are:

EN12094-8 ISO 15540 ISO 15541 Type 1 & 3 connector

File: Ci Manual 2024-11 Page 13 of 143



[41+42+43] Manifold & Orifice & Accessories:

The manifold features built-in check valves which are opened once the discharge hose is connected to ensure proper activation of all connected discharge valves.

The manifold is supplied complete with orifice and pipe system interface.

The pipe system interface is supplied as standard with ISO 7 -1". Other threads are available on request.

The maximum orifice of the standard manifold is $\emptyset 22mm$. (Calculation software may limit the orifice size to calculate correctly, the calculated orifice will be in the print-out)

The maximum number of cylinder connections is 10.

If more than one manifold is used, the Ci MT Next kit (see actuators) must be used to connect from one discharge valve on one manifold to a discharge valve on the next manifold.

ITEM NUMBERS (NOT LIMITED TO THESE NUMBERS)		DATASHEET NO.
Variants a	vailable: -8 Calibrated	
305701	Ci MT1 Manifold	Ci MT Manifold 1-10
305702	Ci MT2 Manifold	
305703	Ci MT3 Manifold	
305704	Ci MT4 Manifold	
305705	Ci MT5 Manifold	
305706	Ci MT6 Manifold	
305707	Ci MT7 Manifold	
305708	Ci MT8 Manifold	
305709	Ci MT9 Manifold	
305710	Ci MT10 Manifold	
305730	Ci MT Orifice kit ISO 1"	CM MT orifice kit
305731	Ci MT Orifice kit NPT 1"	
305732	Ci MT IV8 outlet	
302418	Cylinder erifice	302418 Orifice for cylinder
302410	Cylinder orifice	302418 Office for Cythider
305623	Ci MT Pressure Switch kit	305623 Ci MT Pressure Switch kit
305741	Ci Manifold support bracket	
305304	Non Return valve 1" ISO Ext-In	305304
305305	Non Return valve 1" npt Ext-In	305305
	and the state of t	

INSTALLATION

The orifice with union is fitted to the pipe system, using thread sealant.

The manifold is fitted to the orifice using an O-ring seal. The union should be tightened to prevent it from coming loose.

The pipe system must be sufficiently supported to carry the load from the Ci manifold.

DIRECTIVES, STANDARDS, AND CONFORMITY MARKINGS

Check valves in the manifold are covered by:

EEC 89/106 Construction Product Directive (CPD)
EEC 305/2011 Construction Product Regulation (CPR)

97/36/EC Pressure Equipment Directive

Conformity mark:

CE

Standards applied are:

EN12094-13 Check valve

File: Ci Manual 2024-11 Page 14 of 143



[51] Pipe system:

The pipe system is used for distributing the INERGEN to the protected enclosures.

Typically, the pipe is EN10220/10217 P235TR1, rated for the applicable working pressure (standard 80bar) and has material Charpy V test performed at -40°C.

Typically, the fittings are EN 10242/ 10226/ 1562 with special requirement per VdS standard. Fittings are type tested to 30MPa (300bar) and marked with a red dot and the letter "D" stamped into it. Fittings are suitable for use in installations with clean agent fire extinguishing systems and the low temperature generated during discharge of such system.

Pipes to ASTM Sch40, 80, 160 may also be used. Fittings ASME 3000lb and above may also be used.

Pipes should be threaded and screwed or welded. If another type of assembly is used, the manufacturer of the pipe components must declare that it is suitable for use in fire suppression system using inert gas (here taken into consideration pressure and temperature during use and discharge).

Pipes and fittings may be Black, Galvanized or Stainless steel.

ITEM NUMBERS (NOT LIMITED TO THESE NUMBERS)

DATASHEET NO.

Not listed

Pipes Elbows Tees Reductions Unions

INSTALLATION

The pipe system must be installed in accordance with local authorities' requirements.

See data sheet: Ci Galv pipe and fittings for details regarding item numbers etc.

Installation must be pressure tested in accordance with the requirements in EEC 97/23 (PED) or in accordance with the authority having jurisdiction.

Use FORMFE01210 Test report for pipe pressure testing

DIRECTIVES, STANDARDS, AND CONFORMITY MARKINGS

The complete pipe system is covered by:

EEC 89/106 Construction Product Directive (CPD)
EEC 305/2011 Construction Product Regulation (CPR)
EEC 97/23 Pressure Equipment Directive (PED)

Conformity mark (only the complete pipe system, not the individual component):

Pipe-system Dn<32 should NOT be CE marked

Pipe-system 32<Dn<100 must be CE marked by installation company

Pipe-system 100<Dn must be CE marked by third-party Notified Body

Standards applied are:

PED

File: Ci Manual 2024-11 Page 15 of 143



[54] Fasteners & Pipe hangers:

All fasteners used must be of good quality and made from material suitable for the environment they are being used in. Installation hardware for the pipe system must be able to support the pipe system as well as the forces from nozzles during the discharge.

GENERAL REQUIREMENTS ARE:

Pipe must be allowed to move within the brackets due to length contraction during discharge due to the temperature change.

If the temperature rises from +20°C to +200°C, the ultimate tensile strength of the material used shall not be reduced by more than 25%. Combustible materials shall not be used.

Pipe supports shall be designed so that under extreme load there is no danger of the installation being damaged.

Pipe brackets shall completely surround the pipe and be closed.

The material from which a pipe support is manufactured shall be at least 3mm thick. If galvanized, a thickness of 2,5mm will suffice. This does not, however, apply to a pipe support made from hot-dip galvanized material, which may have a minimum size of 25mm x 1,5mm for pipes up to DN50 (12mm x 1,5mm, if type approved).

Pipe supports shall connect the pipe work directly to the building structure. Building members, to which primary supports are attached, shall be strong enough to carry the load. If not, additional links to loadbearing members shall be created.

All pipe runs longer than 1m shall be fixed with supports. The maximum distance between two supports along the pipe shall not exceed the values given below.

Pipe diameter (mm)	Maximum distance
ripe diameter (min)	between supports (m)
< 25	2
> 25 < 50	3
> 50	4

The distance between a support and the last nozzle shall be as short as possible and shall not exceed:

- > 0.1m for pipe with a diameter < DN25,
- > 0.25m for pipe with a diameter > DN25.

ITEM NUMBERS (NOT LIMITE 8584226	D TO THESE NUMBERS) Pipe clamp 1/2"	DATASHEET NO. Pipe Brackets and accessories
8584232	Pipe clamp 3/4"	
8584239	Pipe clamp 1"	
8584247	Pipe clamp 1 ¼"	
8584254	Pipe clamp 1 ½"	
8584261	Pipe clamp 2"	
8584263	Pipe clamp 2 ½"	
8584263	Pipe clamp 3"	
8591004	Pipe base ø70mm	
2040404 401085	Nipple pipe $\frac{1}{2}$ " 40mm Through bolt expander M8-50	401085

INSTALLATION

The pipe system must be installed in accordance with local authorities' requirements.

DIRECTIVES, STANDARDS, AND CONFORMITY MARKINGS

NA

File: Ci Manual 2024-11 Page 16 of 143



[61a] Nozzles mono-orifice:

The nozzles are calibrated individually by drilling the orifice fixed in the nozzle. A range of standard orifice nozzles is available.

The nominal diameter of the orifice must be marked on the outside of the nozzle.

IMPORTANT: When ordering a calibrated nozzle (orifice diameter of specific dimension), add "-8" to the part number and the diameter of the hole on the order form (example: 210206-8 orifice 5.6mm).

ITEM NUMBERS (NOT LIMITED TO THESE NUMBERS)

DATASHEET NO.

Land applications, included in system approvals (LPCB, CNPP,

CNBOP, UL, FM etc.)

Mono-orifice nozzles			
210204	IN-15 ISO nozzle	Mono-orifice nozzle	
210206	IN-20 ISO nozzle		
210208	IN-25 ISO nozzle		
210210	IN-32 ISO nozzle		
210224	IN-15 npt nozzle		
210226	IN-20 npt nozzle		
210228	IN-25 npt nozzle		
210230	IN-32 npt nozzle		
210202	IN-15 Ci IV8 w adapter		
Nozzle acc	ressories (Aluminum parts currently not FM accepted)		
210123	IN-1/2" Silencer 112		
210125	IN-1/2" Silencer		
210126	IN-3/4" Silencer		
210128	IN-1" Silencer		
210135	IN-1/2" Silencer TBD		
210136	IN-3/4" Silencer TBD		
303129	Nozzle with deflector for direct valve mounting		
205149	Nozzle Deflector ½"		
210334	Nozzle SS deflector (use item "-8" for size definition)		
_	,		

INSTALLATION

The nozzle is screwed on to the pipe system and tightened using a suitable draw bar.

Silencer base plate is screwed on the nozzle or pipe prior to fitting nozzle to the pipe work, the silencer body is then fitted to the base plate.

When nozzle is fitted directly to the discharge valve, the cylinder must be secured with 2 brackets to hold the forces from the nozzle.

Silencers are used in installations where sensitivity to high sound pressures is critical (hard discs etc.) or if reduced turbulence is desired.

DIRECTIVES, STANDARDS, AND CONFORMITY MARKINGS

Nozzles are covered by:

EEC 89/106 Construction Product Directive (CPD) EEC 305/2011 Construction Product Regulation (CPR)

97/36/EC Pressure Equipment Directive

Conformity mark: NA

Standards applied are:

Mono orifice: EN12094-07,

Notice: Mono-orifice nozzles are per 2014-07 covered by UL, FM or LPCB, they are not covered by IMO and DNV.

File: Ci Manual 2024-11 Page 17 of 143



[61b] Nozzles Marine:

The nozzles are calibrated individually by drilling the orifice fixed in the nozzle. A range of standard orifice nozzles is available. The nominal diameter of the orifice must be marked on the outside of the nozzle.

<u>IMPORTANT:</u> When ordering a calibrated nozzle (orifice diameter of specific dimension), add "-8" to the part number and the diameter of the hole on the order form (example: 210206-8 orifice 5.6mm).

ITEM NUMBERS (NOT LIMITED TO THESE NUMBERS)

DATASHEET NO.

Marine applications, included in system approvals (MED, DNV, RMRS, BV ABS etc.)

BV, ABS etc.)		
MED nozzles	with 6 port orifice	
210404	IN-15 MED ISO nozzle SS	Mono-orifice nozzle
210406	IN-20 MED ISO nozzle SS	
210408	IN-25 MED ISO nozzle SS	
210410	IN-32 MED ISO nozzle SS	
210424	IN-15 MED npt nozzle SS	
210426	IN-20 MED npt nozzle SS	
210428	IN-25 MED npt nozzle SS	
210430	IN-32 MED npt nozzle SS	
210504	IN-15 MED ISO nozzle Brass	
210506	IN-20 MED ISO nozzle Brass	
210508	IN-25 MED ISO nozzle Brass	
210510	IN-32 MED ISO nozzle Brass	
240524	IN 45 MED ant normal Dress	
210524	IN-15 MED npt nozzle Brass	
210526 210528	IN-20 MED npt nozzle Brass	
210530	IN-25 MED npt nozzle Brass	
210330	IN-32 MED npt nozzle Brass	
303129	Nozzle for IV8 direct w deflector MED	303129
Nozzle access 205149	sories (Aluminum parts currently not FM accepted) Nozzle Deflector ½"	

210334 Nozzle SS deflector (use item "-8" for size definition)

INSTALLATION

The nozzle is screwed on to the pipe system and tightened.

The MED nozzle is tightened with a wrench.

Nozzle material selection should be made with respect to pipe material.

When nozzles are fitted directly to the discharge valve, the cylinder must be secured with 2 brackets to hold the forces from the nozzle.

DIRECTIVES, STANDARDS, AND CONFORMITY MARKINGS

Nozzles are covered by:

97/36/EC Pressure Equipment Directive 2009/26/EC Marine Equipment Directive (MED

Conformity mark:

Wheel mark

Standards applied are:

MED nozzles: EU 1996/98, MSC 776, 848, 1267

Notice: MED nozzles are per 2014-07 covered by IMO and DNV, they are not covered by UL, FM or LPCB.

File: Ci Manual 2024-11 Page 18 of 143



[71] Pressure relief (Fire Dampers):

To ensure sufficient area of ventilation to the protected room, these pressure reliefs are ideal.

ITEM NUMBERS	(NOT LIMITED TO THESE NUMBERS)	DATASHEET NO.
302720	Pressure relief A040	30272x Pressure relief
302721	Pressure relief A065	
302722	Pressure relief A095	
302723	Pressure relief A150	
302724	Pressure relief A250	
302725	Pressure relief A385	
302726	Pressure relief A615	
302728	Pressure relief A1000	
302762	Pressure relief EV300-EI60	30276x Pressure relief EV
302765	Pressure relief EV500-EI60	
Accessories		
302740	Cap for vent ø080mm	30274x Pressure relief cover
302741	Cap for vent ø100mm	
302742	Cap for vent ø125mm	
302743	Cap for vent ø160mm	
302744	Cap for vent ø200mm	
302745	Cap for vent ø250mm	
302746	Cap for vent ø315mm	
302748	Cap for vent ø400mm	

INSTALLATION

The pressure relief must be installed into the open or to a room significantly larger than the protected enclosure so that unintended pressure build-up is avoided and low oxygen concentration is avoided. In general, a room to which pressure is relieved should be 10 times larger than the protected room.

DIRECTIVES, STANDARDS, AND CONFORMITY MARKINGS

Pressure reliefs are covered by:

EEC 89/106 Construction Product Directive (CPD)
EEC 305/2011 Construction Product Regulation (CPR)

Conformity mark: NA

Standards applied are: NA

File: Ci Manual 2024-11 Page 19 of 143
Date: 2024-11-01



[72] Signs & Labels:
Signs should be placed outside the protected room to inform about the fire suppression system. Additional signs should also be placed on the entry door to the cylinder storage room.

Some authorities require a system identification sign, which must be placed on the cylinders.

ITEM NUMBERS (NOT LIMITED TO THESE NUMBERS) Signs for local requirements are available DATASHEET NO.

File: Ci Manual 2024-11 Page 20 of 143



[73] Accessories:

Components used to complete the installation.

To seal actuators, use "fine" sealing wire; to seal hand wheel valves, use "coarse" sealing wire.

ITEM NUMBER	RS (NOT LIMITED TO THESE NUMBERS)	DATASHEET NO.
214009	Seal (plastic, red)	Seal
214010	Sealing wire (coarse)	
214011	Sealing wire (fine)	
102012	Stainless steel tube 6mm	102012 Stainless tube ø6
214025	Stainless ø6 pipe bracket	214025 Stainless bracket ø6
102021	Pipe retainer ø6 single	10202#
102022	Pipe retainer ø6 dual	
XXX	Compression ring fittings	Compression fittings 6mm
540351	Junction box	540351

INSTALLATION

The sealing wire must be installed so that it is not possible to change the position without breaking the wire. The seal is pressed on the sealing wire using special pliers with identity mark of the technician performing the operation.

Ø6 tube can be used for remote pneumatic actuation and other control functions.

DIRECTIVES, STANDARDS, AND CONFORMITY MARKINGS

Accessories are covered by: NA

Conformity mark: NA

Standards applied are: NA

File: Ci Manual 2024-11 Page 21 of 143



[81] Tools:

Tools for servicing the valves, actuators etc. should only be purchased at Fire Eater and are only sold to authorized installers where employees have received training and education in installation & maintenance of Fire Eater INERGEN systems.

Ordinary tools like wrenches and screwdrivers are also available in selected qualities for the installation.

DATASHEET NO.

ITEM NUMBERS (NOT LIMITED TO THESE NUMBERS)

Tool: Cylinder Pressure gauge M25+W24

530810 Toolkit: Ci 2015 530820 Toolkit: FE SV 2015 530830 Toolkit: Ci SV 2015 530610 Tool kit: Tube Fitter ø6

For dismantling the valve for resetting after discharge

305490 IV8 sep disc Used for resetting after discharge Used for resetting after discharge

For resetting the Ci Actuators after activation (whether or not the cylinder has been discharged)

305495 Ci Actuator Reset Tool Used for service Verifies that sufficient power can be routed to the electrical actuator. 530506 IS8B Electric Circ Tester Used for service

Verifies y the cylinder pressure monitoring circuitry

530502 Manoswitch tester Used for service

Measure the required force to operate the discharge valve and measure the force provided by the actuator (all

actuators, electrical, manual, and pneumatic)

530520 Ci Force Act test Used for service

Testing the discharge valve

530525 Ci Outlet Damper Used for service

To reset the SV selector valve

305149 SV22 Reset tool Used for service

Measure the required pressure to activate the Selector valve

305148 APTB (Test port) Used for service

Test the Non Return Valve for flow

530530 Tool: NRV 1/4 Test Flow Used for service

Test the Non Return Valve for leaktightness

530531 Tool: NRV 1/4 Test No Flow Used for service To verify the switchpoint for manifold and pipe pressure switches.

530540 Tool: Pressure switch setter Used for service

INSTALLATION

DIRECTIVES, STANDARDS, AND CONFORMITY MARKINGS

Tools are covered by: NA

Conformity mark: NA

Standards applied are: NA

File: Ci Manual 2024-11 Page 22 of 143



[82] Service kits:

After discharge the valve has to have the piston replaced before resetting in order to guarantee a leak-free service life.

ITEM NUMBERS (NOT LIMITED TO THESE NUMBERS)

DATASHEET NO.

305403 Ci IV8 Piston

305404 Ci IV8 Service kit box 305404 Ci IV8 Service kit box

INSTALLATION

The individual parts of the service kit box are available separately for refilling the box.

DIRECTIVES, STANDARDS, AND CONFORMITY MARKINGS

Service kits are covered by: NA

Conformity mark: NA

Standards applied are: NA

File: Ci Manual 2024-11 Page 23 of 143



[92] Control panels:

The Control Inert system may be used with any control panel capable of supplying sufficient activation current/voltage for the actuator and which complies with the requirements for which approval the system is used.

E.g., UL & FM: Standard for Control Units for Fire-Protective Signaling Systems, UL 864, and must be UL Listed.

For control panels requiring EOL resistance which are differing from the standard EOL resistor interfaces are available to ensure a proper functioning system.

ITEM NUMBERS (NOT LIMITED TO THESE NUMBERS)		DATASHEET NO.	
563103-62	Sigma A-XT	563103	UL, FM
5400nn	Sigma XT		CE (LPCB)
560nnn	Sigma XT+		CE (LPCB)

INSTALLATION

After installation the correct function must be verified by measuring that there is sufficient power to actuate the actuator by using the Power meter.

DIRECTIVES, STANDARDS, AND CONFORMITY MARKINGS

Control panels are covered by:

UL864 20110628-S8485B issued 2011 June 28

EEC 89/106 Construction Product Directive (CPD)

EEC 305/2011 Construction Product Regulation (CPR)

Conformity mark:

CE

Standards applied are:

EN12094-1 EN 54 UL864

File: Ci Manual 2024-11 Page 24 of 143



SV system components

[101] SV Zone kit:

The Zone kit consists of a Selector valve with Orifice, Pipe adapter, and Tee to create the distribution manifold.

ITEM NUMBERS (NOT LIMITED TO THESE NUMBERS)		DATASHEET NO.
305170	SV22 Zone kit ISO	30517# SV22 Zone kit iso-npt
305171	SV22 Zone kit npt	
304471	SV48 Zone kit NPT	304471
304451	SV48 valve NPT	
304511	SV48-3" valve NPT 3"	
304551	SV48-4" valve NPT 4"	
Included in abo	ove numbers	
305150	SV22 selector valve	305150 SV22 selector valve
304450	SV48 selector valve raw	304450 SV48 selector valve
304510	SV48-3" valve NPT 3" raw	
304550	SV48-4" valve NPT 4" raw	

INSTALLATION

For SV22 systems.

A cylinder rail is installed approx. 2.6 m above the cylinder foot.

Each zone kit is placed in this rail and the inlet tees are pushed together and tightened. Tees are identical for valves and manifolds, except the manifold has different pipe length (space between tees).

For SV48 systems.

The valve and fitting are heavy and with tapered thread (sealing thread).

It is recommended to assemble the valve on a strong support and use lifting devices to put it in place.

DIRECTIVES, STANDARDS, AND CONFORMITY MARKINGS

Discharge valves are covered by:

EEC 89/106 Construction Product Directive (CPD)
EEC 305/2011 Construction Product Regulation (CPR)

97/36/EC Pressure Equipment Directive

Conformity mark:

CE

Standards applied are:

EN12094-5

Additional approvals:

TAC DNV P-14388

Notice: The SV48 valve is with this revision of the manual FM approved as well as CE approved and included in European approval. Not included in UL listing nor any marine approvals.

File: Ci Manual 2024-11 Page 25 of 143



[121] SV CiV & Test port:

The SV CiV is a control valve which is used to control the selector valve at the same time as actuating the Ci IV8 valve. It uses pressure from the IV8 valve to operate the selector valve.

The kit, SV CiV kit, contains the valve and fitting necessary to connect the outlet to a ø6mm tube.

The SV CiV valve must be placed on a cylinder leading to the zone protected by the cylinder to which it is fitted.

The SV Test port is installed on the line from the SV CiV to the SV valve.

The APTB tool is used on the Test port to verify the SV22 opening pressure and verifying that the zone is connected. It is also used for bleeding the pressure of the activation circuitry after activation, in order to reset the SV22.

ITEM NUMBERS (NOT LIMITED TO THESE NUMBERS)		DATASHEET NO.
305182	SV CiV start kit	305182 SV CiV start kit
305183	SV Test port kit	305183 SV Test port kit
Included ir	n above numbers	
305440	SV CiV Control valve	305440 SV CiV Control valve
305302	Non-Return valve	305302 Non-Return valve

INSTALLATION

With the Ci discharge valve depressurized the actuator connector is removed and the SV CiV fitted in its place.

Ø6×1mm tube is fitted to the outlet and routed to the selector valve.

The SV Test port should be installed in close proximity of the SV CiV and be easily accessible at service.

DIRECTIVES, STANDARDS, AND CONFORMITY MARKINGS

Discharge valves are covered by:

EEC 89/106 Construction Product Directive (CPD) EEC 305/2011 Construction Product Regulation (CPR)

Conformity mark:

CE

Standards applied are:

EN12094-4

File: Ci Manual 2024-11 Page 26 of 143



[122] Pneumatic activation kit:

Hose and fitting to utilize the PA system of the discharge valve, as the backpressure activation system is disabled in Multi Zone systems.

ITEM NUMBERS (NOT LIMITED TO THESE NUMBERS) 305179 SV-Ci Next kit 0.4m straight 305180 SV-Ci Next kit 0.7m elbow 305193 SV-Ci Next kit 0.5m straight 305197 SV-Ci Next kit 0.28m Straight

INSTALLATION

The PA plug in the Ci IV8 is removed and the tee is fitted (PTFE tape must be applied to the 1/8" taper thread. Hoses are connected to the tee and between all cylinders to be activated.

It is of utmost importance that the Non-Return valves, which come with the SV CiV kit are used to separate the zones with different cylinder quantities, are placed correctly.

DIRECTIVES, STANDARDS, AND CONFORMITY MARKINGS

Hoses are covered by:

EEC 89/106 Construction Product Directive (CPD)
EEC 305/2011 Construction Product Regulation (CPR)
97/36/EC Pressure Equipment Directive

2009/26/EC Marine Equipment Directive (MED

Conformity mark:

CE

Wheel mark

Standards applied are:

EN12094-8 ISO 15540 ISO 15541 Type 1 & 3 connector

File: Ci Manual 2024-11 Page 27 of 143



[131] SV Accessories

These accessories are only an option to use but can be installed to monitor the system electrically.

All switches are change-over switches, and the "Open" and "Closed" switch are available as a "-8" item with customer specific resistors fitted.

The "Open switch" operates when the valve is fully open.

The "Closed switch" operates when the valve starts to open.

The "Pipe pressure switch" operates when the outlet of the SV22 is pressurized.

The "Pressure switch manual reset" operates when/if pipe system is pressurized.

ITEM NUMBERS (NOT LIMITED TO THESE NUMBERS)		DATASHEET NO.
305168	SV Switch adapter closed ATEX	305168
305186	SV Open Switch kit	305186 SV22 Open Switch kit
305190	SV Closed Switch kit	305190 SV22 Closed Switch kit
305184	SV22 Pipe pressure Switch kit	305184 SV22 Pipe pressure Switch kit
305181	SV22 Pipe pressure outlet	305181
304481	SV48 Pipe pressure outlet	304481
304500	Pressure Switch Manual Reset	304500

INSTALLATION

The "Closed switch" is installed in the 3/8" connection on the side of the SV actuator body by removing the plug covering the connection.

The "Open switch" is installed by removing the piston stop located in to of the SV actuator body.

The "Pipe pressure switch" is installed in the outlet of the SV valve and the pipe adapter is screwed into it.

305168 is a fail-safe construction designed to be used with an ATEX switch but supplied without this switch.

The pressure switch is designed to monitor if a pipe system has been pressurized. Needs to be manually reset.

DIRECTIVES, STANDARDS, AND CONFORMITY MARKINGS

NA

Notice: 304500 is with this revision of the manual FM approved.

File: Ci Manual 2024-11 Page 28 of 143



[141] Manifold kit:

SV-MT manifold kit is supplied with tee to form the distribution manifold when connected to zone kit and other manifold kits. The manifold contains non-return valves to limit the cylinders discharged to be controlled by the PA system.

SV-Ci MT manifold kit has adapters to fit it between tees from the zone kit or between other manifold kits. The SV-Ci MT does not have non-return valve and hence all connected cylinders will be activated by back pressure, the manifold is similar to the one used on stand-alone systems.

One zone kit should always be fitted between two MT kits to ensure sufficient distance between manifolds to make a proper installation.

ITEM NUMBERS (NOT LIMITED TO THESE NUMBERS)		DATASHEET NO.
30517n	SV22 MTn kit (n= 2-8)	20517x SV22 MTx kit
30576n	SV Ci MTn manifold (n= 2-10)	30576x SV Ci MTx manifold
30447n	SV MTn npt 2" KIT (n= 2-8)	30447x
30448n	SV Ci MTn npt 2" KIT (n= 2-10)	SV MT

Above numbers are based on

SV manifold (Back pressure disabled, PA required)

Ci MT Manifold (Back pressure activation active, all cylinders will activate)

INSTALLATION

Similar to the selector valves.

After the manifolds are installed, hoses are connected. Always start with the shorter hose.

DIRECTIVES, STANDARDS, AND CONFORMITY MARKINGS

Check valves in the manifold are covered by:

EEC 89/106 Construction Product Directive (CPD) EEC 305/2011 Construction Product Regulation (CPR) 97/36/EC Pressure Equipment Directive (PED)

Conformity mark:

CE

Standards applied are:

EN12094-13 Check valve

File: Ci Manual 2024-11 Page 29 of 143



[142] SV22 End plug kit:

Two plugs are used to complete the distribution manifold created by connecting the tees of the zone kit and MT kit.

One of the plugs has a built-in burst disc preventing over pressurization of the distribution manifold which is a closed pipe section (when all selector vales are closed).

The two bleed fittings are used to end the PA line at the beginning and at the end.

The bleed fitting is installed so that pressure build up anywhere in the PA line can easily bleed out without causing any undesired effects. The Bleed fitting will close once it is pressurized.

ITEM NUMBERS (NOT LIMITED TO THESE NUMBERS)		DATASHEET NO.
305164	SV22 End plug kit	305164 SV22 End plug kit
304454	SV48 End plug kit	304454
Included in	above numbers	
305544	Burst disc 480 bar	Burst Discs

All plugs are tightened.

INSTALLATION

Directives, Standards, and conformity markings ${\bf N}{\bf A}$

File: Ci Manual 2024-11 Page 30 of 143



[151] Brackets and accessories: To make installation easier, bracket kits can be used.

ITEM NUMBERS (NOT LIMITED TO THESE NUMBERS)		DATASHEET NO.
305166	SV Cable tray kit	305166 SV Cable tray kit
304455	Bracket kit 2" SV48	304455
400306	Cyl rail 1920 mm	Cylinder rail
102021 102022	Pipe retainer ø6 Single Pipe retainer ø6 Dual	10202# Pipe retainer

INSTALLATION

The cable tray kit is used to keeping pilot lines and cables organized when multiple zones are protected.

The Bracket kit 2" supports the 2" distribution manifold.

The cylinder rail is used for SV22 to support valves and manifold line.

DIRECTIVES, STANDARDS, AND CONFORMITY MARKINGS

File: Ci Manual 2024-11 Page 31 of 143



[161] Fittings, adapters and hoses: For more advanced installations, adapters for creating a high-pressure distribution system are available. This can be used when the Selector valves are to be spread out and not placed centrally.

ITEM NUMBERS	(NOT LIMITED TO THESE NUMBERS)	DATASHEET NO.
305154 305155 305156 305157 305159-8	SV22 pipe kit 60mm SV22 pipe kit 85mm SV22 pipe kit 125mm SV22 pipe kit 160mm Customer specific pipe length	30515x SV22 pipekit
305750 305751	SV Adapter 1"ISO - M40×1.5 SV Adapter 1"npt - M40×1.5	305751 SV Adapters
305730 305731	Ci MT ISO orifice kit 1" Ci MT npt orifice kit 1"	Ci_MT Orifice kit
305236 305237	SV22 pipe adapter ISO 1" SV22 pipe adapter npt 1"	
207060 207061 207062 207070 207071 207072	Compensator hose DN25-400 0.5m Compensator hose DN25-400 1.0m Compensator hose DN25-400 1.5m Compensator hose DN32-400 0.5m Compensator hose DN32-400 1.0m Compensator hose DN32-400 1.5m	SV22 Compensation hoses
303516 777056	Nipple 1"-1"BSP-BSP 400bar (SV22 and hose) Bonded seal 1"	
303508 303517 303518 303519	Adapter 1" - 1" ISO Adapter 1" - 5/4" ISO Adapter 1" - 1 1/2" ISO Adapter 1" -2" ISO	
777122 777124 777126 777128 777130 777132	Nipple 1"- ½" ISO-npt Nipple 1"- ¾" ISO-npt Nipple 1"- 1" ISO-npt Nipple 1"- 1¼" ISO-npt Nipple 1"- 1½" ISO-npt Nipple 1"- 2" ISO-npt	
76090806 76090809 76130806 76130809 76241865 76270806 76340809 76610806 76610809	ASTM 6000 Elbow 1" npt galv ASTM 6000 Elbow 2" npt galv ASTM 6000 Tee 1" npt galv ASTM 6000 Tee 2" npt galv ASTM 6000 Reduce 1-2" npt galv ASTM 6000 Socket 1" npt galv ASTM 6000 Union 2" npt galv ASTM Sch160 1"npt 100mm galv ASTM Sch160 2"npt 100mm galv	

Above components are all suitable for use in Fire Eater INERGEN system with up to 40 MPa (400bar) working pressure.

DIRECTIVES, STANDARDS, AND CONFORMITY MARKINGS

All pressure carrying parts:

EEC 97/23 Pressure Equipment Directive

Conformity mark:

if exceeding Dn 32: CE

File: Ci Manual 2024-11 Page 32 of 143



[181] Tools:

To ensure proper operation of the selector valve, a number of tools have been created.

Reset tool is used to reset the selector valve with after activation.

SV Test port is installed for each protected zone allowing for easy annual testing of the required operating pressure of the selector valve and at the same time eliminate the risk of faulty installation.

ITEM NUMBERS (NOT LIMITED TO THESE NUMBERS) DATASHEET NO.		DATASHEET NO.	
305187	Tool kit: SV	305187	
305149	SV reset tool	305149	
305183	SV Test port kit	305183	
305148	Tool: APTB (Test port)	305148	
305147	Tool: APTB CO2 adapter kit	305147	
305188	Tool: SV Switch installation	305188	

INSTALLATION

The Tool kit: SV contains all tools necessary to operate, test and service the SV22 system.

Each tool is also available separately.

Before commissioning the system, the routing of the activation system must be verified and its integrity tested, for this the APTB tool is used, the same tool is used for bleeding the system after activation in order to reset the selector valve.

DIRECTIVES, STANDARDS, AND CONFORMITY MARKINGS NA

File: Ci Manual 2024-11 Page 33 of 143



Equivalent length & Flow resistance

COMPONENT	FLOW DIAMETER [mm]	EQUIVALENT LENGTH [m]	Loss Coefficient
Ci IV8 Discharge valve		0.996	3.09
Hose end Straight	ø8	0.350	1.06
Hose end Elbow	ø8	0.145	0.44
Hose per meter	ø10	0.823	2.06
Ci MT check valve	ø8	0.914	2.79
SV MT	ø8	0.899	2.67
SV Tee	ø22	0.980	1.09
NRV 1"	ø22	3.865	4.31
SV48	ø48	0.112	0.0453

For the hoses, please note that the hose ends are the main contribution for the flow resistance as the diameter here is only $\emptyset 8mm$, whereas the hose has a flow diameter of $\emptyset 10mm$.

File: Ci Manual 2024-11 Page 34 of 143



CHAPTER 2: SPECIFICATIONS

INERGEN Agent

INERGEN agent is a plentiful, non-corrosive gas that does not support combustion nor react with most substances. INERGEN agent contains only naturally occurring gases which have no impact on the ozone layer or the environment in general. INERGEN agent is a mixture of three inerting (oxygen diluting) gases:

52% nitrogen, 40% argon, and 8% carbon dioxide.

The INERGEN agent extinguishes fire by lowering the oxygen content below the level that supports combustion.

When the INERGEN agent is discharged into a room, it introduces the proper mixture of gases that still allow a person to breathe in a reduced oxygen atmosphere. It enhances the body's ability to assimilate oxygen. The normal atmosphere in a room contains approximately 21% oxygen and less than 1% carbon dioxide. If the oxygen content is reduced to below 15%, most ordinary combustibles will not burn. The INERGEN agent will reduce the oxygen concentration to approximately 12.5% while increasing the carbon dioxide content to about 3%. The increase in the carbon dioxide content increases a person's respiration rate and the body's ability to absorb oxygen. Simply stated, the human body is stimulated by the increase in carbon dioxide to breathe deeper and more frequently to compensate for the lower oxygen content of the atmosphere.

ENVIRONMENTAL IMPACT

The INERGEN agent is a mixture of three naturally occurring gasses: Nitrogen, Argon, and Carbon dioxide.

As INERGEN is derived from gasses present in the earth's atmosphere, it exhibits no ozone depleting potential, does not contribute to global warming, nor does it contribute unique chemical species with extended atmospheric lifetime. Because INERGEN is composed of atmospheric gasses, it does not pose the problems of toxicity associated with the chemically derived Clean Agent fire extinguishing.

INERGEN System

The Fire Eater INERGEN Fire Suppression System is an engineered system utilizing a fixed nozzle agent distribution network. The system is designed and installed in accordance with the authorities having jurisdiction and NFPA 2001, "Clean Agent Fire Extinguishing Systems."

When properly designed, the INERGEN system will extinguish fire in Class A, B, and C hazards by lowering the oxygen content below the level that supports combustion.

The system can be actuated by detection and control equipment for automatic system operation along with providing local and remote manual operation as needed. Accessories are used to provide alarms, ventilation control, door closures, or other auxiliary shutdown. When the INERGEN agent is discharged into a room, it introduces the proper mixture of gases that will allow a person to breathe in a reduced oxygen atmosphere. A system installation and maintenance manual is available and containing information on system components and procedures concerning design, operation, inspection, maintenance and recharge. The system is installed and serviced by authorized distributors that are trained by the Fire Eater.

The INERGEN system is particularly useful for suppressing fire in hazards where an electrically non-conductive medium is essential or desirable; where clean-up of other agents present a problem; or where the hazard is normally occupied and requires a non-toxic agent.

The following are typical hazards protected by INERGEN systems:

- Computer rooms with or without lowered ceiling and raised floors
- Telecommunication Switch gear rooms
- Vaults & Storage rooms
- Process equipment rooms
- Machinery spaces
- Historic buildings & museums
- All normally occupied or unoccupied electronic areas where equipment is either very sensitive or irreplaceable.

File: Ci Manual 2024-11 Page 35 of 143



COMPOSITION AND MATERIALS

The basic system consists of extinguishing agent stored in high strength alloy steel cylinders, discharge valves, hoses, manifolds, and various types of actuators. The agent is distributed and discharged into the protected area through a network of piping and nozzles. Each nozzle is drilled with a fixed orifice designed to deliver a uniform discharge to the protected area.

Additional equipment includes: Control panels, releasing devices, remote manual pull stations, corner pulleys, door pumps, pressure trips, bells and alarms, and pneumatic switches.

INSTALLATION

All system components and accessories must be installed by personnel trained by the manufacturer. All installations must be performed according to the guidelines stated in the manufacturer's design, installation, operation, inspection, recharge, and maintenance manual.

ΑνδίΙ ΔΒΙΙ ΙΤΥ

INERGEN Systems are sold and serviced through a network of independent distributors located in many countries.

On www.fire-eater.com a list of Fire Eater distributors and approved filling stations is available.

MAINTENANCE

Maintenance is a vital step in the performance of a fire suppression system. As such it must be performed by an authorized Fire Eater distributor in accordance with NFPA 2001 and the manufacturer's design, installation, recharge, and maintenance manual. When replacing components on the Fire Eater system, use only Fire Eater approved parts.

TECHNICAL SERVICES

For information on the proper design and installation, contact a local international authorized INERGEN System distributor. The Fire Eater applications engineering department is also available to answer design and installation questions. See www.fire-eater.com or call +45 7022 2769.

File: Ci Manual 2024-11 Page 36 of 143



Inert gas history

The inert gases have been known to have fire extinguishing properties for many years. Before the early 19th century, the only fire extinguishing agent widely known and used was water. As today, it was commonly available, cheap and the inventors and other industrious people were working hard to improve supply techniques such as pumps and means of transportation by vehicles.

The 17th and 18th centuries were challenging years where scientists struggled to discover the laws of physics and chemistry, and to investigate the surrounding world. The Swedish chemist Carl Wilhelm Scheele discovered in 1772 that air was a mix containing two principal substances: Oxygen and Nitrogen. (The French scientist A. Lavoisier, 1743-1794, was making similar observations, as he found that combustion consumes Oxygen and leaves behind "the thing that has no life" Azote).

Some years later the Danish physicist H.C. Ørsted (1777-1851) studied the elements later to be classified in the periodical system. On the basis of the work done by Scheele he discovered that the components of air, Oxygen and Nitrogen, behaved very differently. He saw that Oxygen was taking actively part in a chemical process such as combustion and Nitrogen was not. On the contrary Nitrogen would actually suffocate a fire, and after this discovery he gave the element Nitrogen the Danish name "Kvælstof" which means the element that suffocates fire.

Still later the periodical system was completed (Niels Bohr) and the real inert gases Helium, Neon, Argon, Krypton and Xenon were identified.

Nitrogen and Carbon Dioxide are not classified as true inert gases, since they can participate to some degree in chemical processes, but in a fire this ability is insignificant, and generally they are referred to as "inert gases" in the fire extinguishing systems industry.

One of the characteristics of the inert gases is that they do not take place in chemical processes, not even at high temperatures generated by combustion (Note: Krypton and Xenon are known to react with Fluorine at high temperature and pressure, but this is not relevant to fire extinguishing). So by introducing them into an enclosure at high concentrations, they dilute the Oxygen and extinguish the fire. The normal atmospheric Oxygen content is 20.95%, and by reducing that, to less than 15%, most commonly present combustibles, such as oil, gasoline, wood and plastics are extinguished.

The inert gas re-discovery

In the early 1980's Fire Eater A/S was involved in a project, where it was obvious that Halon 1301 could not be used safely, due to the formation of seriously toxic thermal de-composition products.

It appeared obvious that the use of inert gases alone would lead to other safety problems, since the Oxygen concentration required for fire extinguishing, is very close to the minimum acceptable level for man. The idea of using a small amount of CO2, to compensate for the low Oxygen concentration required for fire extinguishing, was investigated. Experiments and search in scientific medical studies, discovered the amazing result, that CO2 used in a 3-6% concentration, is able to compensate the ill-effect of 8-12% Oxygen concentrations, and maintain consciousness and normal breathing.

The idea was filed as a patent application in 1987 and in 1991 commercialized based on a cooperation between Fire Eater A/S, Denmark (and its sister company Fire Research ApS) and Air Products & Chemicals, and Ecosystems, Pennsylvania, USA. The name of the process to compensate for Oxygen deficiency by Carbon Dioxide, in fire fighting, is INERGEN.

INERGEN is globally available through licensed suppliers. The INERGEN suppliers are not just high quality fire extinguishing systems suppliers, but furthermore they are specially trained in the use of INERGEN and the INERGEN system components, and through the organized license structure, experience and knowledge is distributed to all INERGEN suppliers. For the marine use of INERGEN this also means that the systems can be fully serviced where INERGEN is available, which in 2010 is worldwide.

File: Ci Manual 2024-11 Page 37 of 143



Safety/toxic effect

Since the days of H. C. Ørsted it was commonly known that the reduction of Oxygen had some side effects: The suffocating effect of Nitrogen did certainly also apply for human beings, not only for the fire. This is true, but only in more severe cases of Oxygen deficiency.

Outside the fire extinguishing industry a need appeared, to know more about oxygen deficiency, the medical term being Hypoxia. Aviators were exposed to hypoxia during high un-pressurised flights, and from the 1930s physiologists were researching this field intensively. Also astronauts and mountain climbers are exposed to hypoxia, and that has provided a broad platform of scientific literature and data, to support the theoretical background of INERGEN and to some degree other inert gases or gas blends.

It is important to understand, that the Inert gases (He, Ne, Ar, etc.) and Nitrogen do not have any toxic effects at normal atmospheric pressures. It is even more important to understand that Carbon Dioxide does not have any toxic effects, but it has physiologic effects as a very important part of the human metabolism, and regulatory mechanisms in Oxygen supply.

When a Carbon Dioxide system is known to involve high personnel risks, it is due to the high concentrations used: More than 30% exceeds the human short term tolerance, and will result in unconsciousness in a matter of minutes.

Hypoxia

Hypoxia is the medical term for the lack of Oxygen in humans. The symptoms vary by the Oxygen concentration, and the exposure time. There are different reasons for hypoxia, but of course the most interesting one at this occasion, is the hypoxia caused by the use of fire extinguishing gases. Acute hypoxia occurs, when the Oxygen concentration is reduced in the matter of hours or less, as this does not allow for the natural compensation, having effect in a matter of days in prolonged gradual hypoxia.

When the inspired oxygen is reduced, it leads to a reduction in the blood-oxygen saturation. Initially this is detected by chemoreceptors in the major arteries, and automatically induces an increase in lung ventilation. Due to this, the equilibrium Carbon Dioxide partial pressure slightly decreases, and the initial respiration increase is outweighed. At 12% inspired Oxygen there is only little, or no change in ventilation. If the Oxygen concentration is further decreased, the lowered arterial Oxygen pressure will take effect, and ventilation will gradually increase, until about the 8-9-10% limit at which unconsciousness is often observed in young healthy males within a few minutes (2-4). There is a significant individual sensitivity to both the lowering of the arterial Oxygen, and Carbon Dioxide partial pressure.

Hypoxia is especially essential to the brain tissue, since the brain metabolism depends critically on the partial cerebral (brain cells) Oxygen pressure, blood-oxygen saturation and the acidity. If the partial Oxygen pressure drops below a certain limit, it results in immediate unconsciousness.

An unpublished paper by the Institute of aeronautical medicine, Copenhagen, suggests the following limits of consciousness, for male fighter pilots in good physical condition:

10.6%	30 minutes
8.0%	3-5 minutes
6.3%	1.5-2.5 minutes
5.2%	1 minute
3.8%	0.5 minute
2.4%	0.25 minute

The paper indicates that there are great individual differences, and that age, overweight, smoking, and a physical condition other than well trained, will decrease the tolerance to low Oxygen considerably.

In a broad population of "normal subjects" the first light symptoms of hypoxia can be observed at about 15.5% Oxygen. The symptoms such as impaired judgement, clumsiness, diminished visual acuity and increased response times are becoming more significant as the Oxygen concentration drops to 11-12%.

As the Arterial Oxygen level drops within 5 seconds, the symptoms starts with practically no delay. One of the very serious effects of severe acute hypoxia is that it is not identified by a large number of individuals. On the contrary they are experiencing a light intoxication or light-headedness, and will be likely to respond irrationally to warnings, or signs of danger.

File: Ci Manual 2024-11 Page 38 of 143



Down to about 12% Oxygen, most physiologists agree, that short exposures do not cause any permanent injuries (exposures up to 30 minutes), and only in very few cases leads to unconsciousness.

At a flooding concentration chosen for the inert gas system of 50% (0.5m³ gas per m³ room), the average high (average of the upper 5% of measured discharges) Oxygen concentration is 12.9%. The average (of the 90% of the measured discharges) is 12.6%. The average low (average of the lower 5% of measured discharges) is 11.4%. The statistical basis of the above is 139 full-scale discharge tests under real life conditions. The enclosures ranged from 18m³ to 690m³ and were measured to an accuracy of +/- 3 cm. Cylinder pressure was gauged to a temperature compensated accuracy of +/- 2%, and room temperatures were within the range 19-24°C. these tolerances do not explain the otherwise satisfactory tolerance of +0.2%/-1.3% Oxygen concentrations measured, but enclosure tightness, actual cylinder temperature during test, and atmospheric pressure, possibly play the most significant role.

In fire situations, Oxygen concentrations have been experienced to drop to 8-10% after discharge of extinguishing gas, due to the Oxygen consumption of fire and the increased enclosure temperature.

The system design required to extinguishing fires, and the safety limits are obviously very close to each other for Inert gas systems. They can be used safely if all the design conditions are strictly held, and by very short exposures (less than 2 minutes) it is obvious that they do not represent an acute risk within reasonable tolerance limits and influences of the surroundings. However there is a simple, reliable and natural way to expand the exposure tolerance to low Oxygen: adding a small amount of Carbon Dioxide to the Inert gas mixture.

File: Ci Manual 2024-11 Page 39 of 143



Acute adaptation to acute hypoxia

As mentioned, Carbon Dioxide is a very important part of the human physiology. It is a product of metabolism, and the primary regulator of the acidity of blood and tissues, through its conversion to Carbonic acid and the hydrogen ion.

During exercise, the amount of Carbon Dioxide in the blood and in the expired air is increased and it represents the major drive to ventilation increase. Increasing the inspired Carbon Dioxide (hypercapnia), will like exercise, raise the acidity (lower pH) and increase the ventilation, depending on the inspired Carbon dioxide concentration.

As Carbon Dioxide above 8% concentration is clearly beginning to cause some problems at prolonged exposures, one could be tempted to make the following conclusions: Hypoxia is bad, Carbon dioxide is bad. Combined hypoxia and hypercapnia is twice as bad, as the problems are adding up. 1 + 1 = 2. This is good arithmetic, but not true in this case; on the contrary — it should rather be viewed as 1 + -1 =status quo! This statement, not being scientifically correct, anyhow reflects the real effect.

In the case of a lowered Carbon dioxide concentration the pH rises. This causes vasoconstriction in the brain. In the case of hypercapnia, the result is a vasodilatation. In plain and simple words: The brain has a shunting valve mechanism that allows for an increased blood flow through the brain at high Carbon dioxide concentrations and decreases when the concentration is lowered. This is easily demonstrated: After hyperventilating for a minute or two, dizziness is felt strongly, and if continued it will lead to fainting. This is a result of the decreased Carbon Dioxide, and this little experiment clearly demonstrates the statement in ref. 1: "Carbon Dioxide is no less vital to life than Oxygen".

Some interesting effects of Carbon Dioxide are: During tests carried out by Gibbs and others (ref. 2), subjects were in four experiments breathing 6% Oxygen + 5% Carbon Dioxide for three minutes, then 4% Oxygen + 5% Carbon Dioxide for another three minutes. EEG remained normal and consciousness was fully maintained. Two subjects went even further: 2% Oxygen + 5% Carbon Dioxide for additionally two minutes. EEG remained normal and they were able to add and subtract, and obey demands.

Of course, this experiment is in the extremes, but clearly indicates the beneficial effect of Carbon Dioxide.

Another interesting experiment (ref. 1), shows that a test individual unconscious due to a 5% Oxygen/95% Nitrogen atmosphere, recovered consciousness immediately after addition of 5% Carbon Dioxide (inspired gas 90% Nitrogen, 5% Oxygen, 5% Carbon Dioxide). Again, a very clear indication that Carbon Dioxide is the life insurance needed in the use of Inert gases and gas blends.

Carbon Dioxide is giving acute adaptation to acute hypoxia!

File: Ci Manual 2024-11 Page 40 of 143



Hypoxia, hypercapnia, and Carbon Monoxide

During a fire a lot of harmful smoke and decomposition products will be produced. The most significant one being Carbon Monoxide. Statistical information collected out of postmortems on human fire fatalities indicate that 70% had more than 30% Carboxyhaemoglobin (blood cells bound to Carbon Monoxide) which will have incapacitated the victim.

The mechanism of Carbon Monoxide (CO) is to bind to the blood cells with an affinity 200-250 times that of Oxygen and thereby reducing the blood Oxygen carrying capacity. This situation is physiologically similar to hypoxia.

What are the tolerable limits of Carboxyhaemoglobin? Basically, Carboxyhaemoglobin is not at all desirable, but to some people a part of their life: very heavy smokers and citizens of a large city. Heavy smokers may have a pre-load of Carboxyhaemoglobin of 10-15% as an extreme. And this is actually very close to "an acceptable level".

As the inert gas blend, containing Carbon Dioxide, purposely increases the ventilation this will naturally lead to an additional Carbon Monoxide exposure: but there are 5 very important factors in effect:

- The Carboxyhaemoglobin pre-load.
- The exposure time.
- The Carbon Monoxide concentration.
- The Oxyhaemoglobin saturation.
- The rate of ventilation.

The rate of ventilation is increased by 2.5 times at 5% Carbon Dioxide in 12.2% Oxygen, and the heart rate is increased by 10/min (ref. 3).

The following example is based on breathing 20.9% Oxygen, and is giving an indication of the magnitude of the problem. The Carboxyhaemoglobin pre-load is 5%, and the exposure time is 10 minutes:

CO PPM	6 l/min.	18 l/min.	30 l/min.	40 l/min.
500	6.14%	8.42%	10.71%	12.68%
1000	7.28%	11.84%	16.42%	20.26%

These values may not at all be conservative due to the unknown factor of the Oxyhaemoglobin level, but are useful in relating to real life fire situations:

A gasoline 0.25 m^2 pan fire with 1 liter fuel, in an enclosure volume of 35 m^3 is giving the following results after total combustion:

- CO peaks at about 1100 PPM
- Oxygen low 17%
- Carbon Dioxide high 2.9%

Experiments with INERGEN extinguishing (50% vol. gas/vol. room) under the same basic circumstances prove that the Oxygen diluting effect of INERGEN, is at the same time CO-diluting:

- CO is reduced to approx. 700 PPM
- Oxygen low is 8%
- Carbon Dioxide high 5%
- Temperature peak 163°Celsius (325°F).

It is of course not recommendable to stay in room during such a fire and extinguishing (temperature 163°C!), but the gas situation in the enclosure will support consciousness for more than 10 minutes. Consciousness will not be supported for more than 1-2 minutes if the Carbon Dioxide level is not increased above 3%.

File: Ci Manual 2024-11 Page 41 of 143



NOAEL/LOAEL

There is no NOAEL and LOAEL for inert gasses as there are no toxicological effects from exposure to low oxygen concentration.

NFPA 2001 defines NOAEL AND LOAEL "For halocarbons". The NOAEL and LOAEL are based on the toxicological effect known as cardiac sensitization. Cardiac sensitization occurs when a chemical causes an increased sensitivity of the heart to adrenaline, a naturally occurring substance produced by the body during times of stress, leading to the sudden onset of irregular heart beats and possibly heart attack. Cardiac sensitization is measured in dogs after they have been exposed to a halocarbon agent for 5 minutes. At the 5 minute time period, an external dose of adrenaline (epinephrine) is administered and an effect is recorded, if the dog experiences cardiac sensitization."

No Effect Level and Low Effect level for inert gas are in NFPA 2001 set to be respectively at concentration of 43% and 52% corresponding to an oxygen level of 12% and 10% (normal atmosphere is 21% oxygen). These levels are based of physiological effects similar to the effects of doing exercise and should hence not be mixed with toxicological effects caused by chemical agents.

Enclosure escape precautions

Even though the inert gas systems containing Carbon Dioxide offers a very high degree of safety to humans, it is under no circumstances recommended to stay in the enclosure during fire extinguishing or during fire extinguishing system discharge, if it can be avoided.

When inert gases and inert gas blends are used there are certain additional advantages: The gases are stored under high pressure, but always in the gaseous form. During discharge of the gas, there is no significant condensation of air moisture, and therefore escape route visibility, is not decreased by the fire-extinguishing agent.

During Hypoxia the physical performance will decrease slightly but at a 8-12% Oxygen concentration, there is only little change in a graded exercise performance measurement. This degree of hypoxia, when compensated with 3-5% CO₂, will not be the reason for anybody to unsuccessful escape. Possibly the most important factor in successful escape out of the enclosure is: The preservation of consciousness and a normal response behavior. At this point, the INERGEN inert gas blend has an absolutely unique performance. Down to extreme degrees of hypoxia, the Carbon Dioxide provides extended consciousness and improved psychomotor abilities.

If the Carbon Dioxide concentration increases to a level at which it is uncomfortable, it is on the other hand giving a very fine warning against staying in the enclosure. By 5-6% Carbon Dioxide this becomes significant and provides an additional safety feature.

Exposure time to reduced oxygen atmosphere should be limited to:

Time	Agent conc.	Oxygen
5 minutes	43%	12.0%
3 minutes	52 %	10.0%
0.5 minutes	62%	8.0%

Above limitations are set out in NFPA 2001: 2022 (4.3.3)

File: Ci Manual 2024-11 Page 42 of 143



Effect on machinery and equipment

Engines must be stopped before discharge of a fire extinguishing system, but If INERGEN is accidentally discharged before the engine is stopped, there will be no risk of damages to the engine. The diesel engines will continue running with no significant output changes (Study with Danish Navy 19. /4. -1993), and no effect on lubricants, metal parts, electrical machines, and electrical and electronic parts.

After the discharge of INERGEN the air quality will improve, due to the dilution of corrosive and toxic substances and due to the reduction of the relative humidity.

Extinguishing efficiency

Inert gases require higher concentrations, and therefore they have often been looked upon as less efficient than the Halon type extinguishing agents.

From a mere cost/weight/space point of view, that is correct. This is the disadvantage of inert gas systems. High concentration requirement and gaseous storage require large storage volume and/or high pressure compared to both Halon 1301 and the new Halon type fire extinguishing agents.

From a fire extinguishing point of view however, the inert gases are no less efficient than the Halon type fire extinguishing agents, except for the speed of fire extinguishing. The Halon type compounds are usually discharged in 10 seconds or less. This is necessary in order to limit the formation of decomposition products of the Halo-Carbon itself. As the inert gases do not produce any decomposition products, the gas is discharged over longer time, but in such a way that the extinguishing concentration is reached within 60-120 seconds (according to the MSC Circ. 776, Appendix sect. 4.1: Max. 30 seconds after the agent discharge, the fire shall be extinguished. This means that the fire shall be extinguished max. 150 seconds after the discharge start). This may seem like a long time, but very shortly after the discharge start, the rate of combustion is significantly reduced, and the development of fire, and the fire damages are practically stopped instantly.

Efficiency also concerns the ability to extinguish class A fires (plastic and wood), and materials heated to very high temperatures, without contaminating the enclosure with toxic decomposition products. At this point the inert gases are also offering an improvement, compared to Halon and Halo-Carbons such as HCFC's, HFC's and PFC's.

Furthermore, the Inert gases are offering truly 3-dimensional extinguishing capability, since they blend perfectly with air (they are basically air themselves), and as the air/agent blend after discharge is just slightly heavier than normal air they are able to maintain an extinguishing concentration for a very long time.

Signs and warnings

A written operation instruction must be present at the control panel/manual discharge activators, that clearly indicate:

- Ventilation and engine(s) are stopped before INERGEN discharge.
- Fire dampers and doors are closed before INERGEN discharge.
- At the points of access to the enclosure, signs must be present that indicate:
 - Evacuate the room in case of fire/fire alarm.
 - o Operating instructions and valve identification.n

File: Ci Manual 2024-11 Page 43 of 143



References:

- Ref 1. Harvey, Raichle, Winterborn, Jensen, Lassen, Richardsson, Bradwell. The lancet 639-641, 1988
- Ref 2. Gibbs, Lennox, Nims. Journ. Aviat. Medicine, 250-261, 1943
- Ref 3. Consolazio, Fisher, Pace, Pecura, Pitts, Behnke. Am. Journal physiologi, 479-503, 1947
- Ref 4. Nielsen, Smith. Acta Physiol. Scand., 293-313, 1943
- Ref 5. Ketty, Scmidt. Journ. Clin. Invest., 27:4, 484-492, 1948
- Ref 6. Slobodnick, Wallick, Chimiak. Rep. no. 04-91, Navy Exp. diving unit, Panama City, FL, 1991
- Ref 7. Siesjo, Johannsson, Norberg, Salford. Brain Hypoxia, Academic press, New York, 1975
- Ref 8. Lambertsen. Respiration, V.B. Mountcastle, Mosby, St. Louis, 1980

File: Ci Manual 2024-11 Page 44 of 143



Material Safety Data Sheet
Latest available SDS is always available on request, the following pages contain valid data sheet on date of this publication.

File: Ci Manual 2024-11 Page 45 of 143





EU regulation 1907/2006, 1272/2008, 453/2010, 2015/830, 2020/878

Product Gas mixture, 52% Nitrogen, 40% Argon, 8% CO2

IG541, INERGEN

Fire Eater Supplier

Vølundsvej 17, 3400 Hillerød, Denmark

www.fire-eater.com, email: info@fire-eater.com

+45 7022 2769 Emergency response

 Product use Fire Extinguishing Systems

Section 2: Hazard(s) Identification

 OSHA/HCS status This material is considered hazardous by the OSHA Hazard Communication Standard (29

CFR 1910.1200)

Classification of the substance or mixture

GASES UNDER PRESSURE - Compressed gas H280, Full text of H-phrases: see section 16

• 67/548/EEC (DSD) or 1999/45/EC (DPD) Not classified

Adverse physicochemical, human health and environmental effects No additional information available

GHS Label elements

Hazard pictograms (CLP)



Signal word Warning

Hazard statement H280 - Contains gas under pressure; may explode if heated

OSHA-H01 - May displace oxygen and cause rapid suffocation.

Precaution statements

General Read and follow all Safe Data Sheets (SDS's) before use.

P403 - Store in a well-ventilated place. Storage

P410 - Protect from sunlight. Protect from sunlight when ambient temperature exceeds

52°C/125°F.

 Disposal Not applicable

File: SDS IG541 eng 2022-05 Supersedes rev: 2018-11-25 Rev: 2022-05-25 Page: 1/8

File: Ci Manual 2024-11 Page 46 of 143 Date: 2024-11-01





EU regulation 1907/2006, 1272/2008, 453/2010, 2015/830, 2020/878

Section 3: Composition/Information on Ingredients

• Mixture

Name	Product ide	ntifier	%	Classification	Classification
				Directive 67/548/EC	Regulation 1272/208 (CLP)
Nitrogen	CAS No EC No REACH No	7727-37-9 231-783-9 ANNEX IV	52	Not classified	H280: Contains gas under pressure; may explode if heated
Argon	CAS No EC No REACH-No	7440-37-1 231-147-0 ANNEX IV	40	Not classified	H280: Contains gas under pressure; may explode if heated
Carbon dio×ide	CAS No EC No REACH No	124-38-9 204-696-9 ANNEX IV	8	Not classified	H280: Contains gas under pressure; may explode if heated

• REACH Registration: All components are listed in Annex IV of Regulation EC 1907/2006 (REACH)

and are exempted from registration in accordance with article 2(7)(a).

Contains no components or impurities which influence the classification of the product.

Section 4: First-Aid Measures

Description of necessary first-aid instructions

• Inhalation: Remove victim to uncontaminated area wearing self contained breathing apparatus.

Keep victim warm and rested. Call a doctor. Apply artificial respiration if breathing stopped.

Skin contact: Adverse effects not expected from this product.
 Eye contact: Adverse effects not expected from this product.

• Ingestion: As this product is a gas, refer to inhalation section.

Most important symptoms and effects, both acute and delayed

• No additional information available

Indication of any immediate medical attention and special treatment needed

· None.

File: SDS IG541 eng 2022-05 Rev: 2022-05-25 Page: 2/8 Supersedes rev: 2018-11-25

File: Ci Manual 2024-11 Page 47 of 143





EU regulation 1907/2006, 1272/2008, 453/2010, 2015/830, 2020/878

Section 5: Fire-Fighting Measures

Extinguishing media

• Suitable extinguishing media: Use an extinguishing agent suitable for the surrounding fire.

• Unsuitable extinguishing media: Non known.

Special hazards arising from the substance or mixture

· No reactivity hazards other than the effects described below

Advice for firefighters

• Firefighting instructions: Depressurize the cylinders by releasing the fire extinguishing system if

connected in this.

Do not activate the release valve if cylinder is not securely fastened.

Remove ignition source if safe to do so.

Move containers from fire area if this can be done without risk.

Use water spray to keep fire-exposed containers cool.

Protection during firefighting: Compressed gas: asphyxiant, suffocation hazard by lack of oxygen.

Special methods: Use fire control measures appropriate for the surrounding fire.

Exposure to fire and heat radiation may cause gas receptacles to rupture. Cool

endangered receptacles with water spray jet from a protected position.

Section 6: Accidental Release Measures

Personal precautions, protective equipment and emergency procedures

Non-emergency personnel: No action shall be taken involving any personal risk or without suitable training.

Evacuate surrounding areas. Keep unnecessary and unprotected personnel from entering.

Avoid breathing gas.

Provide adequate ventilation. Wear appropriate respirator when ventilation is

inadequate. Put on appropriate personal protective equipment.

Stay upwind.

• Emergency responders: Monitor oxygen level to determine concentration of released product.

Wear self-contained breathing apparatus when entering area unless atmosphere is proved

to be safe.

Ensure adequate air ventilation.

Act in accordance with local emergency plan.

• Environmental precautions: None

Methods and materials for containment and cleaning up

· Clean-up procedures: Ventilate with fresh air

File: SDS IG541 eng 2022-05 Rev: 2022-05-25 Page: 3/8 Supersedes rev: 2018-11-25

File: Ci Manual 2024-11 Page 48 of 143





EU regulation 1907/2006, 1272/2008, 453/2010, 2015/830, 2020/878

Section 7: Handling and Storage

Precautions for safe handling

• General Put on appropriate personal protective equipment (see Section 8).

Contains gas under pressure. Do not puncture or incinerate container.

Use equipment rated for cylinder pressure.

Protect cylinders from physical damage; do not drag, roll, slide, or drop.

Use a suitable hand truck for cylinder movement. Do not use valve cap for lifting.

Conditions for safe storage

Storage Store in accordance with local regulations.

Store away from direct sunlight in a dry, cool and well-ventilated area. Keep container

tightly closed and sealed until ready for use. Cylinders can be stored horizontal or vertical.

Valve cap/guard must be fitted to the cylinder and only to be removed when the cylinder

is securely fastened.

Cylinders are always to be firmly secured to prevent falling or being knocked over.

Cylinder temperatures should not exceed 65 °C (150 °F).

Section 8: Exposure Controls/Personal Protection

General: All components are exempted from REACH registration in accordance with article 2(7)(a).

Annex IV of Regulation EC 1907/2006 (REACH)

Contains no other components or impurities which will influence the classification of the

product.

Occupational exposure limits

• General: Good general ventilation should be sufficient to control worker exposure to airborne

contaminants.

Nitrogen	52%	Oxygen Depletion [Asphyxiant]		
Argon	40%	Oxygen Depletion [Asphyxiant]		
Carbon dio×ide	8%	OSHA PEL: 5.000 ppm ACGIH TLV (2012)		
		TWA: 5.000 ppm STEL: 30.000 ppm		

• Appropriate engineering controls:

Oxygen detectors should be used when asphyxiating gases may be released.

Provide adequate general and local exhaust ventilation.

Systems under pressure should be regularly checked for leakages. Ensure exposure is

below occupational exposure limits (where available).

• Thermal hazard protection: None necessary.

• Environmental exposure controls : None necessary.

• Other information: Wear safety glasses EN 166

Wear safety shoes while handling containers. Standard EN ISO 20345 - Personal protective

equipment - Safety footwear.

File: SDS I G541 eng 2022-05 Rev: 2022-05-25 Page: 4/8 Supersedes rev: 2018-11-25

File: Ci Manual 2024-11 Page 49 of 143



Safety Data Sheet **INERGEN**



EU regulation 1907/2006, 1272/2008, 453/2010, 2015/830, 2020/878

Section 9: Physical and Chemical Properties

Appearance:

 Physical state: Gas Color: Colorless Odorless Odor:

Flammability: Non flammable, does not sustain combustion

Molar mass 34.08 g/mol

· Vapor density: 1.416 kg/ m^3 (t = 20°C, p = 1.0132 bar)

· Relative density: 1.18 (@t = 20°C, p = 1.0132 bar)

Section 10: Stability and Reactivity

· Reactivity: No specific test data related to reactivity available for this product or its ingredients.

· Chemical stability: The product is stable

Possible hazardous reactions: Under normal conditions of storage and use, hazardous reactions will not occur.

Hazardous decompositions products: None • Hazardous polymerization: None

Section 11: Toxicological Information

All components are exempted from REACH registration in accordance with article 2(7)(a). • General:

Annex IV /V of Regulation EC 1907/2006 (REACH)

Contains no other components or impurities which will influence the classification of the

product.

· Information on toxicological effects

Acute toxicity: None Irritation/corrosion: None

Sensitization: Stimulate the respiratory system to increase breathing

Mutagenicity: None Carcinogenicity: None Reproductive toxicity: None Teratogenicity: None

• Specific target organ toxicity (single or repeated exposure):

• Aspiration hazard: Stimulate the respiratory system to increase breathing

Potential acute health effects

Eye contact: None

Inhalation Increased breathing

Skin contact None Ingestion See Inhalation

Symptoms related to the physical, chemical and toxicological characteristics: None

· Delayed and immediate effects and also chronic effects from short and long term exposure

Eye contact: None

File: SDS IG541 eng 2022-05 Rev: 2022-05-25 Page: 5/8 Supersedes rev: 2018-11-25

File: Ci Manual 2024-11

Date: 2024-11-01

Page 50 of 143





EU regulation 1907/2006, 1272/2008, 453/2010, 2015/830, 2020/878

Long term exposure None
 Potential chronic health effects None
 Numerical measures of toxicity None

Section 12: Ecological Information

• Toxicity None

Persistence and degradability
 Bio accumulative potential:
 Soil/water partition Coefficient):
 Not relevant

• Ecological effects: No known ecological damage caused by this product.

Section 13: Disposal Considerations (non-mandatory)

• Disposal methods: May be vented to atmosphere in a well ventilated place.

Do not discharge into any place where its accumulation could be dangerous.

Refer to the code of practice of EIGA (www.eiga.org).

Container must be disposed of in a safe way. Do not puncture or incinerate container

Section 14: Transport Information (non-mandatory)

• UN number: UN 1956

Labeling

• ADR, IMDG, IATA, DOT, TDG.



File: Ci Manual 2024-11 Page 51 of 143





EU regulation 1907/2006, 1272/2008, 453/2010, 2015/830, 2020/878

ADR (road transport)

Shipping Name: COMPRESSED GAS, N.O.S. (Nitrogen, Argon)

• H.I. nr: Transport hazard class: 2 Classification code

Packing Instructions: P200

274, 655 Special provision: Limited quantity: 120ml Exempted quantities: E1

Transport category:

Hazard identification (Kemler No) 20

> 20 1956

Orange plates:

Tunnel Restriction: E: Passage forbidden through tunnels of category E

EAC code: 2TE

ICAO-Ti/IATA-DGR

Shipping Name: Compressed gas n.o.s. (Nitrogen, Argon)

Class: 2.2 Passenger and Cargo Aircraft

Allowed

Packing Instructions: P200

Cargo Aircraft only

Allowed

P200 Packing Instructions:

IMDG (Sea transport)

Shipping Name: COMPRESSED GAS, N.O.S. (Nitrogen, Argon)

• Class: 2.2 Emergency Schedule (EmS)

Fire: F-C

Spillage:

· Packing Instructions: P200 Special provisions: 274 Limited quantites: 120 ml Excempted quantities: E1 Stowahe category:

File: SDS IG541 eng 2022-05 Supersedes rev: 2018-11-25

Rev: 2022-05-25

Page: 7/8

File: Ci Manual 2024-11 Page 52 of 143 Date: 2024-11-01





EU regulation 1907/2006, 1272/2008, 453/2010, 2015/830, 2020/878

Section 15: Regulatory Information (non-mandatory)

EU-Regulation

REACH All components are exempted from REACH registration in accordance with article 2(7)(a).

Annex IV/V of Regulation EC 1907/2006 (REACH)

Contains no other components or impurities which will influence the classification of the

product.

Contains no substances with Annex XVII restriction

Wassenaar Arrangement

No ECCN number as all components are free to export without any restrictions.

Section 16: Other Information

• Training: INMON0001

• This Safety Data Sheet has been established in accordance with the applicable European

Union legislation.

Classification in accordance with calculation methods of regulation

(EC) 1272/2008 CLP / (EC) 1999/45 DPD / 2015/830

• This SDS is issued 2022-05 and replace revision 2018-11

Previous revisions: 2018-11

2016-11

• This SDS is compiled by: Michael Kroneder, Comendo Ignis AB, Billesholm, Sweden

END OF SAFETY DATASHEET



DN: cn=Michael Kroneder, o=Comendo Ignis AB, ou, email=mk@ci-ab.se, c=SE Date: 2022.05.26 09:39:24 +02'00'

File: SDS IG541 eng 2022-05 Rev: 2022-05-25 Page: 8/8 Supersedes rev: 2018-11-25

File: Ci Manual 2024-11 Page 53 of 143



CHAPTER 3: GENERAL INFORMATION

System general

The Control Inert (Ci) system is a standalone system, for manual, pneumatic or electric activation.

The SV system is an add-on to the Ci system. Multiple zones can be protected by a shared INERGEN bank.

These additional systems are (not limited to but include)

SV22 and SV48 system (Multizone system by using Selector valve with 1" or 2" flow)

Periodical inspection and maintenance by qualified and trained personnel must be made minimum in accordance with the authority having jurisdiction.

Minimum inspection intervals:

UL Semi-annual (cylinder pressure must be verified)

FM LPCB CNPP CNBOP

NFPA: At least annual: inspection and test;

at least biannually: pressure check

MED: IMO/MSC

This system is made up of units tested within limitations contained in the detailed installation manual. The system designer must be consulted whenever changes are planned for the system or area of protection. An authorized installer or system designer must be consulted after the system has been discharged.

For a list of authorized installers and service companies, please see www.fire-eater.com

The Ci and SV extinguishing system and components are designed for a minimum and maximum operation, transportation, and storage temperature of -50 °C and +80°C, at temperatures above +70°C special consideration with regards to pressure developed in the cylinder must be made (burst disc pressure increased or pressure reduced).

Various authorities have witnessed different testing limitations based on their requirements. The Ci and SV system have these authority limitations for operation, transportation, and storage:

UL - FM $0 \,^{\circ}\text{C} \, (32 \,^{\circ}\text{F}) \text{ and } +65 \,^{\circ}\text{C} \, (150 \,^{\circ}\text{F}).$

File: Ci Manual 2024-11 Page 54 of 143



Terms and definitions

PILOT CYLINDER

Cylinders which sole purpose is to activate the extinguishing system by supplying a pneumatic pressure.

PDS cylinders can be placed remotely and be of different types and styles.

MASTER CYLINDER

A cylinder which supplies pneumatic pressure for activating the extinguishing system as well as contributing to the extinguishing agent supply.

This cylinder will be fitted with an activator which can be either Electrical, Manual or Pneumatic, and supply gas to the protected hazard as well as pressure to the pneumatic activation line.

SLAVE CYLINDER

Cylinders which are activated by either a Pilot cylinder or a Master cylinder.

The gas from the cylinder is only used for extinguishing, not to activate other cylinders or equipment.

MDC

Minimum Design Concentration

The minimum design concentration used for calculating the minimum required INERGEN agent and the discharge time for a specific hazard.

MDC is based on the MEC multiplied by a safety factor (typically 1.3 or 1.2).

AMDC

Adjusted Minimum Design Concentration

The design concentration used to achieve 85% of the MDC at the end of the holding time.

FDC

Final Design Concentration

The concentration of INERGEN supplied to the hazard, based on the cylinder quantity and filling.

MEC

Minimum Extinguishing Concentration is the extinguishing concentration measured for extinguishing the fuel.

File: Ci Manual 2024-11 Page 55 of 143



Types of systems

Total flooding is the approved type of system available. A total flooding system normally consists of a fixed supply of INERGEN connected to piping with nozzles to direct the agent into an enclosed hazard space. In a total flooding system, the enclosure around the hazard must be tight enough to hold the required percentage of INERGEN concentration for a period of time to extinguish the fire.

CONTROL INERT (STAND ALONE) NOZZLE ON CYLINDER

A system can consist of a single or multiple cylinders with nozzles directly attached to the cylinder. If multiple cylinders are used an activation line must be attached to each cylinder. One cylinder could be a master cylinder supplying pressure through the PA to the other cylinders or a separate actuator on each cylinder.

CONTROL INERT (STAND ALONE) SINGLE MANIFOLD

The master cylinder will typically be placed at one end of the cylinders or on both (where redundancy is required), but it could be any of the cylinders of the system, it only depends on to which cylinder the actuator is placed as this will make it the master cylinder.

CONTROL INERT (STAND ALONE) MULTIPLE MANIFOLD

As the single manifold system, but for each manifold added to the system it is necessary to join the manifolds together at the valves, as pressure cannot move from one manifold to the next without using the Ci MT next kit.

The Ci MT next kit is connected on a valve from the manifold, which is pressurized during activation to a valve on a manifold not being pressurized.

An infinite number of manifolds may be linked as the pressure is generated by each cylinder. The quantity of manifolds is only limited by the allowable activation time as required authorities having jurisdiction.

MULTI-ZONE SYSTEMS SV22 AND SV48 SYSTEMS

A common bank of INERGEN can also be used to protect multiple rooms.

When using the SV system, the SV manifold can be used as it disables the back pressure activation function due to the Non-Return Check valves integrated in the manifold. This way it is possible to control how many cylinders will be activated. With the Back pressure activation function disabled it is necessary to use the Pneumatic activation (PA) ports on front of the valves to activate the required number of cylinders. The different numbers of cylinders that are to be activated are separated by Non return valves in the PA line.

When multiple cylinders are activated for all hazards, the SV Ci MT manifold can be used where the backpressure will activate all cylinders connected.

File: Ci Manual 2024-11 Page 56 of 143



Type of Actuation

There are three basic types of actuation for the INERGEN systems: pneumatic, mechanical and electrical.

ELECTRICAL

Automatic electrical actuation of the cylinder valve, through an approved control panel, can be accomplished by using the Ci IS8 Solenoid actuator. The actuator is energized by an electric signal from the detection/control panel.

MECHANICAL

Mechanical actuation is accomplished by the Ci IM8 Actuator which is a hand operated Push-Button style actuator which is mounted the Ci IV8 discharge valve. By pushing the button, a spring is released. A wire rope mechanical actuator can also be used for "short distance" remote operation of the system.

PNFLIMATIC

A Pneumatic actuator is available as well, this is the Ci PA8 which is a direct pneumatic actuator that can be attached to the discharge valve. When using external pressure sources this device should be used in order not to mix pressures through the PA In/Out on the discharge valve.

Control panels

Multiple control panels are available.

INERGEN FLOW

The flow of INERGEN in the system discharge piping is a compressible flow. The agent is a compressed gas, the temperature and density of which changes as the pressure in the pipe decreases. The flow calculation is based on classical energy conservation considerations.

For simple systems, an assumption of adiabatic expansion of the agent is sufficient. IMT (INERGEN Management Tool) flow calculation program, however, accounts for heat transfer from the pipe into the flowing agent. The consideration of heat input to the agent permits a greater degree of flexibility in system design. An orifice is placed in the manifold outlet for Ci systems and for SV systems the Orifice is placed just before or right after the Selector valve.

Discharge nozzles control the amount of INERGEN which flows into various portions of the protected space.

Personal Safety

Proper INERGEN system design requires that the design concentrations fall within the design window that limits the upper and lower requirements of both oxygen and carbon dioxide. INERGEN agent has acceptable toxicity for use in occupied spaces when used as specified in the United States Environmental Protection Agency (EPA) proposed Significant New Alternative Policy (SNAP) program rules and NFPA 2001, "Clean Agent Fire Extinguishing Systems." When design concentrations are inside this window, no adverse effects will take place on the human respiratory system. Any exposure outside of these limits requires the use of self-contained breathing apparatus. Respirators will not function in oxygen deficient atmospheres. Because of the decomposed products of combustion generated during an actual fire and extinguishment, it is a good safety rule to ventilate the hazard for at least 15 minutes before entering or if entry is required sooner, wear an approved self-contained breathing apparatus.

Avoid direct contact to the cold, high pressure discharge and avoid direct inhalation of undiluted gas.

File: Ci Manual 2024-11 Page 57 of 143



CHAPTER 4: PLANNING

Fire classes

Attention must be paid to the fact that fire classes vary depending on location. Make sure that all documents used refer to the same classes or that the variations are considered.

NFPA 2001	European	Fuel / Heat source
Class A	Class A	Ordinary combustible
Class B	Class B	Flammable liquids
	Class C	Flammable gases
Class C	Higher Hazard Class A (EN15004) Not defined in EN2 2004	Electrical equipment
Class D	Class D	Combustible metals
Class K	Class F	Cooking oil or fat

In this manual Fire Classes will refer to the NFPA fire classes, unless specified otherwise.

File: Ci Manual 2024-11 Page 58 of 143



Design concentration

Fore Fire Eater INERGEN systems below design concentrations are applicable.

To obtain the AMDC the Design factors are added for any special conditions which affect the system (Tee design factor, Atmospheric pressure, Room leakage etc.)

	Class	MDC	Notes	Discharge time
IMO MSC/Circ848	Engine room	42.9	MEC: 35.6% (DBI 1998) SF: 1.2	85% < 120 sec
IMO MSC/Circ 1267	Engine room	46.2	MEC: 35.6 % (DBI 1998) SF: 1.3	85% < 120 sec
UL UL2127	А	39.3	MEC: 32.1 % (DBI 2012) SF: 1.2 +1.93% (distribution)	95% < 120 sec
UL UL2127	В	41.1	MEC: 31.6 % (DBI 2012) SF: 1.3	95% < 60 sec
UL UL2127	С	43.3	MEC: 32.1 % (DBI 2012) SF: 1.35	95% < 120 sec
FM Global FM5600	А	37.5	MEC: 31.2 % (FE 2013) SF: 1.2	95% < 120 sec
FM Global FM5600	В	41.6	MEC: 31.9 % (DBI 2012) SF: 1.3	95% < 60 sec
EN15004:2008	А	37.2	MEC: 28.6 % (BRE 2014) SF: 1.3	95% < 60 sec
EN15004:2008	В	43.7	MEC: 33.6 % (BRE 2014) SF: 1.3	95% < 60 sec
EN15004:2008	НН А	41.5	95% of Class B (min Class A)	95% < 60 sec
LPCB LPS1230:2005	А	37.2	MEC: 28.6 % (BRE 2014) SF: 1.3	95% < 60 sec
LPCB LPS1230:2005	В	43.7	MEC: 33.6 % (BRE 2014) SF: 1.3	95% < 60 sec
LPCB LPS1230:2005	Cable	42.6	MEC: 42.6 % (BRE 2014) SF: 1.0	95% < 60 sec
NFPA NFPA 2001:2012	А	34.2	Table value (Table A.5.4.2.2(b))	95% < 120 sec
NFPA NFPA 2001:2012	В	40.6	Table value (Table A.5.4.2.2(b))	95% < 60 sec
NFPA NFPA 2001:2012	С	38.5	28.5 x 1.35 (5.4.2.5)	95% of Class A < 120 sec

^{*}For class B the specified minimum design concentration is for heptane, if the hazard contains liquids with a cup burner value higher than that tested for heptane the design concentration has to be determined in accordance with the relevant standard (EN15004, FM5600, UL2127, NFPA 2001), as a guide for comparison of extinguishing concentration of ignitable liquids please see ISO 14520-15 to verify if the cup burner value exceeds that for heptane.

File: Ci Manual 2024-11 Page 59 of 143



General

Planning for design and installation of an INERGEN system starts when the customer is first contacted with regards to protecting his hazard area with INERGEN. Most of the information necessary for the design of a system is collected during the first meeting with the customer. The information gathered at this point will determine the ease or difficulty of the rest of the project. One of the key elements for fire protection is to correctly define the hazard and conduct a complete survey to determine if the system will properly protect against the hazard. Coordination with all parties involved in the project will further improve the flow of the overall project. A thorough hazard analysis is required to determine the type of protection required. It is important to cover each element and accurately record the information. This information will be used to determine the size and location of the INERGEN system required and to determine, at a later date, if any changes were made to the protected area after the system was installed.

Information necessary for designing an INERGEN system is listed in the following paragraphs.

Initial General Information:

- Which rules are to be applied?
- Who will approve the system? (Any other regulatory or insurance agencies)
- Will any special requirements apply to the system design or installation?

Hazard area Information:

- Obtain the general arrangement drawings of the areas to be protected.
- If the general arrangement drawings do not include the following information, then these must be obtained separately.
- Record all dimensions for the hazard areas such as length, width, ceiling height, angles of corners if not 90 degrees, false ceiling, raised floor etc.
- Draw a sketch including plan and elevation views of the hazard area if drawings are not available.
- Indicate the quantity and locations of all exits from the area on the sketches.
- Record all dimensions for any structural objects such as beams or columns, built-in cabinets, ducts, etc. which may allow a reduction of the hazard volume.
- Identify anything unique about the area that would affect system design or installation.
- Identify the area's normal, maximum, and minimum ambient temperatures.
- Is the area normally occupied?
- Identify any openings, or potential openings in the hazard enclosure that may cause loss of agent during or after discharge.
- If possible, determine the maximum strength of the weakest wall, floor, or ceiling. This information will be used to calculate venting requirements. If this information is not available, a conservative number will be used to calculate the required free venting area. This conservative number will probably increase the size of venting required.

INERGEN Supply Requirements:

- Will the cylinders be located in a dedicated space? If so, record the dimensions of that space.
- Is the operating temperature (cylinders storage) range within the accepted limits?

Limit: -50°C to 65°C [-60°F to 150°F]
UL & FM: -0°C to 65°C [32°F to 150°F]

- Determine if the floor will support the cylinders and bracketing.

 Assume cylinder weight of 1920kg/m² for an 80l-300bar system for this requirement.
- Will the cylinder bracketing be secured to a wall?
 If so, is the wall strong enough to support it and the cylinders?
- Will a reserve supply of agent be required?
 If so will it need to be connected to the manifold?
- Will a discharge test be required?
- If several areas are to be protected, will it be by a multi-zone system or several stand-alone systems?

File: Ci Manual 2024-11 Page 60 of 143



FOR FM GLOBAL INSURED SYSTEMS:

- Reserve supplies are necessary to permit prompt restoration of the system after a discharge, to minimize interruption of the process and the interval of impaired protection. The reserve should at least equal the minimum requirement for the in-service supply, unless available from an outside source within 24 hours.
- Where two or more hazard areas are protected by a single supply through selector valves, connect the reserve supply to the piping. Provide a switchover arrangement, if needed, to permit actuation by the normal means. A manually actuated main/reserve switch is normally provided at the control panel for this purpose.
- Provide a connected reserve where an INERGEN system is the sole protection for valuables and important occupancies unless protection can be fully restored within 24 hours, occupancies are constantly attended and written impairment procedures have been established.

File: Ci Manual 2024-11 Page 61 of 143



Activation and Alarm Requirements:

- Will the system be activated automatically or/and manually?
- What type of manual actuation (direct mechanical, cable pull or pneumatic) is required?
- Identify the locations for all manual pull stations.
- If automatic detection is a part of the system?
- What types of alarm devices are required; audible and/or visible?
- Where will the system activation be signaled?
- Does the hazard area require explosion proof, weatherproof or fireproof wiring and devices?
- Devices requiring shut down or started up?

Piping and wiring Information:

- Determine the location of the cylinders.
- Identify the preferred supply piping routes.
- If the system includes selector valves, identify their location.

Ventilation and Leakage Concerns:

- Identify any un-closable openings regardless of their size.
- Advise the customer of the possible need to seal these openings to prevent agent loss.
- Advise the customer of the possible need to provide pressure venting during discharge.
- Determine the route venting will need to take to reach outside atmosphere. (Clear description of how to reach outside atmosphere)
- Will the venting route involve venting through other enclosures or ducts? If so, provide details about the rooms or duct routing information. If the venting will be through other enclosures, will they be protected also? If so, will they be protected separately or simultaneously?
- Will dampers be required for inlet or exhaust ducts? If so, how will they be operated, electrically or pneumatically?
- Door fan test to NFPA 2001.

File: Ci Manual 2024-11 Page 62 of 143



CHAPTER 5: DESIGN

After completing the hazard analysis in Chapter 4, proceed with the following elements to work up a complete design and bill of materials. An example is included with each step, to help the reader understand the procedure. The example uses a computer room and subfloor as shown below.

The IMT calculation software is self-explaining additional information may be found under "help".

The calculation from IMT will have to be printed to show all the information available for the system, not all information will be displayed directly in the program. This can be done by printing a PDF of the calculation where all output will be available, including the actual calculation limits.

Version number

These numbers are part of the calculation report printed on the last page of the output file.

IMT VERSION:	3.x.x	2.x.x	
Flow design engine:	2018-08-01	2014-08-27	
Room design engine:	2014-07-23	2014-07-23	
Flow simulation engine:	2018-08-02	2014-08-08	

Limitations on system design

The following are limitations to a Fire Eater INERGEN system that will ensure proper performance:

300 m (orifice to last nozzle) Max pipe length:

Max pipe to cylinder volume ratio: 20%

40 - 600 sec for 95% agent mass. Discharge time:

40-120 sec for 95% UL & FM approved systems

Re-number: Minimum 0.4×10^6 .

Minimum Manifold Orifice: No limit

Max 0.64 (ø17.6/ø22.0 mm) Manifold Orifice to Pipe ratio:

Nozzle Orifice: Minimum ø3.0 for UL & FM approved systems

Nozzle to Pipe area ratio: Max 0.7 5/95 - 95/5 Tee split: Bull head (min/max): Tee split: Through/Side (min/max): 5/95 - 95/5 Nozzle pressure: Min 20 bar Nozzle pressure variance ratio: Max 1.65 / 2.0 Max elevation change Max 50 m Mach-number: Max 0.40 Minimum distance to first Tee: 0 m

Flow velocity: Lower limit by Re-number and upper limit by Mach-number.

Pipe volume per nozzle: Limited by nozzle orifice to pipe area ratio.

Limited by max pipe length. Nozzle agent arrival time:

Pipe type: Black, galvanized and stainless steel pipe.

EN10220/10217

ASTM Sch 40, Sch80, Sch160 Black, galvanized, stainless steel.

Cylinder pressure: 20 and 30 MPa @ 15°C.

Temperature: -0°C to +65°C. Nozzle quantity: 1 to 100

Activation limitations on one solenoid

PA line (Pneumatic activation): max 250 m (app. 750 cylinders)*

UL/FM: max 50 m (app 150 cylinders)**

Number of manifolds: max 80 (up to 750 cylinders)*

UL/FM: max 50 (up to 500 cylinders)**

File: Ci Manual 2024-11 Page 63 of 143 Date: 2024-11-01

Pipe fittings:

^{*} This is the activation lines length/number of cylinders that can be activated within 2 sec.

^{**} This is the activation lines length/number of cylinders that can be activated within 1 sec as per UL-FM requirement.

If longer activation lines or more manifolds are required, additional activators (Ci IS8B or Ci PA8) has to be added to the system and installed so above distances are not exceeded.



Guide to calculation software IMT

Calculations made in previously approved versions remain valid. However, Fire Eater recommends updating to the most recent version, as this is regularly updated.

IMT Main features

The IMT program allows the system designer to design an Inergen™ system using information about room size(s), authority requirements and pipe system layout. In addition, the performance of an "As built" (installed) system can be analyzed and verified against authority requirements.

For a normal design task, the following features are used (not necessarily in order of use):

- Creation of a new "system" based on a predefined template.
- Customer and project data input (project name, address, notes etc.).
- Revision control and revision notes.
- Design state used to manage the state of a design from "Work in progress" to "Installation approved".
- Selection of MDC for each room based on authority requirements and room (enclosure) hazard class.
- Selection of discharge time and target based on authority requirements and room (enclosure) protection class.
- Definition of an arbitrary number of rooms (enclosures) protected by a single pipe system, each room can have its own hazard class and design factor.
- Calculation of required number of cylinders based on room volumes, hazard class(es), design factors, cylinder volume and filling.
- Selection of manifold and orifice type, selection of pipe and nozzle families.
- Interactive 3D modelling of pipe system from orifice(s) to nozzles, defining the length of each pipe section.
- Interactive editing of 3D pipe system model, changing pipe section lengths, adding or deleting nodes etc. Changes are reflected in real time in the 3D model.
- Node, pipe, nozzle and orifice numbering can be set automatically, or user defined for some or all objects.
- Pipe table overview with real time update from 3D model, giving pipe system details in a table format.
- Calculation of pipe system using "Design", "Fixed pipe" or "As built" modes.
- Each successful calculation gets a unique Calc-ID upon completion, this is shown on all calculation print outs and pdf drawings generated by IMT.
- A successful calculation is locked, preventing the user from changing anything influencing the calculation without invalidating and resetting the Calc-ID.
- Pipe table overview updates with calculation data when available.
- PDF calculation report of valid calculations, containing all parameters defining the system and all calculation results including any warnings and applied calculation limits.
- PDF drawings of system, containing an arbitrary number of drawing pages, each with user selected projection, zoom factor and pipe, nozzle, node and manifold data from a valid calculation.

File: Ci Manual 2024-11 Page 64 of 143



IMT3 work flow

This is a brief overview of the typical workflow and the associated GUI views (menus, dialogs and tabs). To keep this short and manageable, we will not show every GUI view, as most are self-explanatory. For best results, you should work through an example in IMT3 while reading this.

INSTALLING IMT3

IMT3 can be installed on Windows™ PC's using IMT3_installer.exe. This will guide you through the installation process and install the program in folder C:\fireeater\IMT3. Shortcuts will be created on the Desktop and in the Start menu.

In addition to the IMT3 calculation program, two separate programs "IMT3-partfinder" and "IMT3-partseditor" are also installed. These are not used for IMT3 calculation, but rather for creating parts lists and making quotations etc. based on IMT3 calculations. IMT3-partfinder and IMT3-parts-editor will not be covered further in this manual.

STARTING IMT3

IMT3 is started by clicking on one of the shortcuts named "IMT3". When IMT3 is started the first time on a new PC, you will be prompted to enter your personal user id and activation key, provided by Fire Eater. Afterwards IMT3 will check that you are a valid user using the IMT3 server, this means that when running IMT3 for the first time, your PC will need to be connected to the Internet.

After initial activation IMT3 can run without entering the user id and activation key for as long as IMT3 successfully connects to the IMT3 server at least every 60 days. This means that during normal usage IMT3 does not need to be continuously connected to the Internet.

Every time IMT3 is started, it will try to connect to the IMT3 server, checking for software updates and new parts data, used by the IMT3-partfinder (PF). You may minimize the update window without affecting normal IMT3 operation.

The activation menu can be found manually in: Settings >> Activation settings.

NEW SYSTEM

In IMT3, each calculation with meta data is called a "system". A new calculation is started by using *File >> New system*, this will prompt you to select a template for your system. You can choose between default templates provided and maintained by FE or user templates created by each user. All template settings can be overridden by the user, they are just default settings for new systems.

You will then be prompted to select a file name for your system. IMT3 uses a Model View Controller (MVC) architecture, meaning that each system is represented by a data base stored in the "*.imt" file. Every change in the system is immediately stored in the "*.imt" file, thus making a "Save" button unnecessary.

SYSTEM SETTINGS MENU

The Settings >> System settings menu is used to change settings such as filling and storage temperatures and the default manifolds etc. used when inserting a new component in the pipe system.

The system settings menu is the place to check if you encounter something that cannot be changed otherwise.

Once a new system is opened you will be presented with number of tabs: "Project", "Inergen design", "Pipe drawing", "Pipe table" and "Calculation". In a nominal work flow you will probably use them in this order.

PROJECT TAB

The Project tab is used to manage system meta data. Meta data for the project and the customer can be managed, as well as revision version and design state.


None of the data in the Project tab is directly used in the calculation, thus you may skip this tab. After a successful calculation you will therefore still be able to edit the Project tab without doing a recalculation. Some of the data in the Project tab is used in the PDF calculation report and the PDF system drawings (in the title blocks).

INERGEN DESIGN TAB

This tab is used to determine the number of cylinders needed to protect the rooms (enclosures) by a single pipe system.

File: Ci Manual 2024-11 Page 65 of 143





By selecting the appropriate "authority" you can choose which set of rules you wish to use for the system. For each room, you can choose the hazard class within that standard. The hazard for discharge time sets the discharge time and discharge time target for the system.

For physical reasons, it is impossible to set a different discharge time target for each room (since the nozzle areas control both the INERGEN™ distribution **and** the discharge rate, they cannot independently control both distribution and discharge time for each room). Thus, the need for a single discharge time and discharge target for all rooms connected to the same pipe system.

The discharge time applies to the last room to reach the discharge time target INERGEN™ concentration, regardless of the hazard class chosen for that room.

The *Design factor* can be used to set an additional safety factor above the MDC. This is applied by calculating the flooding mass for each room from the MDC and then adding the percentage *Design factor* to that flooding mass. It is thus perfectly acceptable to specify a *Design factor* of 500% if so desired.

You can add and delete rooms by right clicking anywhere in a room column (except in the header row) and choosing "Add room" or "Delete room".

After choosing the cylinder volume and filling pressure, the number of cylinders needed are calculated by pressing *Calculate cylinders*. This also finds the actual final INERGEN $^{\text{m}}$ concentrations etc., for each room (which is always at least as high as the MDC, because the total number of cylinders are rounded up).


In addition to the standard cylinder volumes shown in the list, it is also possible to write any custom cylinder volume.

File: Ci Manual 2024-11 Page 66 of 143



PIPE DRAWING TAB

This tab is used to model the pipe system in 3D, specify the system and calculation type and specify the nozzles and pipe families.



After selecting the appropriate system type (determines the available manifolds etc.), the calculation type can be selected from "Design", "Fixed pipe" or "As built":

- Design: Calculate the manifold orifice(s), nozzles and pipe sizes to get the desired distribution and hit the discharge time target at the specified discharge time.
- Fixed pipe: Same as design but keep the pipe sizes fixed at the user selected values. Requires all pipe sizes to be specified by the user or a previous "Design" calculation.
- As built: Simulate the discharge using known manifold orifices, nozzles and pipe sizes.


The pipe system model is started by selecting the starting position (typically the manifold orifice position) using the *Place start node* button.

Then, while in *Draw mode*, use the left mouse button to select a vertex (this shows the allowed drawing directions, taking into account that only planar tee's and 90 deg elbows are supported). Dragging the mouse in one of the allowed drawing directions, draws a pipe section in increments of the selected *Step size*.

File: Ci Manual 2024-11 Page 67 of 143



Each new pipe section always ends in a nozzle (shown with a blue dot). However, when you continue drawing from a pipe end, it automatically converts to an internal vertex. A vertex with 3 connections is automatically converted to a Tee.



Switching into *Edit mode* allows you to select and edit any element in the pipe system model. Thus, you can change pipe section lengths, edit the room number for nozzles etc., using the menu on the lower right or alternatively in the dialog box when double clicking a pipe section or node.

Notice that in **these** menus its necessary to confirm any numerical input (a pipe section length for example) with a press of the return key. This is because when return is pressed, the 3D pipe system model is updated to reflect changed pipe section lengths etc.

PIPE TABLE TAB

This tab gives an overview of the pipe system with the currently available data. It is updated from the pipe system model each time you switch to the tab. No user input is possible, but by clicking on the column headers, the rows may be sorted according to your preferences.

CALCULATION TAB

This is used to start the calculation engine when *Calculate pipe system* is pressed. After the calculation is finished, any errors, warnings or cautions will be displayed.


If the calculation is successful the *Calculation valid* text is displayed in the left side of the bottom status bar, along with a unique *Calc-ID* composed of the user ID and the calculation date and time.

File: Ci Manual 2024-11 Page 68 of 143



UPDATED PIPE TABLE TAB

After a successful calculation, the pipe table tab will be automatically updated with the calculation results: Nozzle pressures, max flow rate, total nozzle flow etc. If it is a design calculation, the calculated nozzle orifice and nozzle dimension plus the calculated pipe dimensions will also be shown in the table.



CALCULATION REPORT

A complete calculation report can be printed as a pdf file by selecting *File >> Print pdf report*. This includes all data describing the system including the selected authority and associated "authority" calculation limits, plus the actual calculation limit for this calculation. The unique Calc-ID is shown on each page, along with the imt file name for reference.

File: Ci Manual 2024-11 Page 69 of 143




PIPE SYSTEM DRAWINGS

Selecting *File* >> *Print drawings* opens a dialog box to print pdf drawings of the pipe system complete with selected annotations for nozzles, pipes, etc. It is possible to define as many drawing pages as needed with different zoom level, projection and annotations for each drawing page.

The selected annotations are shown in boxes connected with leaders to the annotated object (nozzle, pipe section etc.). Each click on the object "dot", rotates the annotation one quarter turn around the object "dot", making it possible to optimize the annotation layout for best clarity.

The pipe sections are color coded according to pipe size. Notice that all pipe sections belonging to a pipe branch always have the same pipe size. The pipe size is therefore only shown once for each pipe branch and not for each pipe section.



New drawing pages are added by copying an existing page using the *Copy* button. The new page is inserted immediately after the current one. Use the *Page no*. drop down to select the current page. *Move* and *Del* buttons are used to reorder or delete pages.

Notice that all page definitions are saved in the imt file, so your changes will be recalled if you close and reopen the drawing dialog box.

The *Print pdf* button prints the actual drawing pages as a single pdf file. The calculation time is printed on each page, corresponding to the Calc-ID time.

Meta-data in the title blocks is taken from the Project tab.

File: Ci Manual 2024-11 Page 70 of 143



Troubleshooting

List of Errors, Warnings and Cautions with explanation and possible solutions.

Errors will indicate that the calculation failed.

Warnings are given when one of the limitations specified by the selected "Authority" has been exceeded.

Cautions indicate that special precautions are required during installation (Ex. DN-50 with a DN-15 Nozzle).

In the following XX, YY, ZZ and VV are variable according to the specific warning, error, or caution.

ERRORS

Text	Explanation	Possible solution(s)
Desired room concentrations must be positive!	Self-explanatory	Check MDC for each room
Room: XX temperature: YY degC or room pressure: ZZ Pa (abs) exceeds NFPA2001 limits!	Self-explanatory	Change room conditions
Room XX volume must be positive!	Self-explanatory	Check room volumes
The cylinder volume must be positive for cylinder type: "Custom"	Self-explanatory	Check custom cylinder volume
Nozzle: XX room: YY not found in list of rooms!	Nozzle XX not connected to a valid room	Check room number of nozzle
Room: XX is not protected by any nozzles!	No nozzle in room XX	Check that each room has at least one nozzle
Nozzles in room: XX cannot protect a larger volume than the room volume!	The sum of all nozzle volumes in room XX, is larger than the room volume	Check volumes of each nozzle in room XX or use <i>Auto</i> nozzle volume on one or more nozzles in the room
Nozzles in room: XX do not protect the entire room volume!	The sum of all nozzle volumes in room XX, is smaller than the room volume	Check volumes of each nozzle in room XX or use <i>Auto</i> nozzle volume on one or more nozzles in the room
Total number of cylinders is not the same as used in room design!	The total number of cylinders used in the flow calculation is not the same as in the <i>Inergen design</i> calculation	Check the number of cylinders for each manifold or use <i>Auto</i> cylinders for one or more manifolds
Flooding discharge time target must be larger than zero and less than the final actual flooding for the worst case room!	The target for the discharge time is incorrect (below zero or too large compared to the actual final concentrations)	Check discharge time target or increase MDC or <i>Design factor</i> (to increase the number of cylinders)
Flooding discharge time target larger than 95% of final flooding concentration in worst case room.	The discharge time target, converted to a flooding target is larger than 95% of the final flooding concentration	Check discharge time target or increase MDC or Design factor (to increase the number of cylinders)
Manifold XX of type YY has too many connected cylinders (maximum ZZ)!	Too many cylinders connected to manifold	Increase the number of manifolds
The tee at node XX is not defined correctly. A tee can not have two	An non supported tee connection has been found (this is normally only	Check Pipe drawing

File: Ci Manual 2024-11 Page 71 of 143



Text	Explanation	Possible solution(s)
branch connections! Please correct the pipe(s) inlet/outlet connections!	possible if you have deleted a pipe section and rejoined the "free" pipe system incorrectly)	
Maximum pipe size XX in selected pipe type YY is too small for the current design: Please select another pipe type, increase maximum pipe size or discharge time!	The pipe family does not have a large enough pipe size for the required flow rate	Check pipe family and maximum pipe size or decrease maximum flow rate
Flooding discharge time too short: Please increase flooding discharge time and/or decrease cylinder size.	Impossible to discharge Inergen in required discharge time (the discharge valves etc. give too much resistance)	Decrease the required flow rate for each cylinder
Flooding discharge time too short: Please increase flooding discharge time, decrease cylinder size or increase number of manifolds.	As above, but it could also be the manifold which is causing problems	Decrease the required flow rate for each cylinder and/or manifold
Fixed pipe sizes specified, but pipe: XX with size YY of type ZZ is not defined in pipe list!	The selected pipe size does not exist in the current list of pipe sizes	Check selected pipe size, pipe family and maximum pipe size
Fixed pipe solution error - one or more pipes are too small: Increase discharge time or pipe size.	The fixed pipe size is too small for the required flow rate	Decrease flow rate in pipe or increase selected pipe size
Fixed pipe solution error - solution did not converge.	Unspecified error. Probably caused by too small or too large pipes	Switch to <i>Design</i> to obtain reasonable pipe sizes
Pipe: XX with size YY of type ZZ is not defined in pipe list!	The selected pipe size does not exist in the current list of pipe sizes	Check selected pipe size, pipe family and maximum pipe size
Nozzle XX orifice diameter YY mm is larger than orifice inlet diameter: ZZ mm.	The nozzle orifice is too large compared to the physical nozzle size	Check specified nozzle orifice size, use two smaller nozzles instead of one large.
Nozzle XX orifice diameter: YY mm is not smaller than the pipe diameter: ZZ mm!	The nozzle orifice is too large compared to the physical nozzle size	Check specified nozzle orifice size, use two smaller nozzles instead of one large
Nozzle XX orifice diameter must be larger than zero!	Self-explanatory	Define a positive nozzle orifice diameter
Nozzle XX with pipe size YY is not defined in nozzle family ZZ!	Probably caused by fixing a nozzle to a too large diameter pipe	Use tees to split flow and add more smaller nozzles
Nozzle XX is not connected to the pipe system!	The pipe system is split into one or more sub systems	Reconnect sub systems
The flow solution iteration did not converge to an accurate solution within the allowed number of iterations!	The system may be too "extreme" in some way	Switch to <i>Design</i> to obtain reasonable pipe, nozzle and orifice sizes

File: Ci Manual 2024-11 Page 72 of 143



WARNINGS

Text	Explanation	Possible solution(s)
The system uses a custom cylinder size: The discharge time may be different than specified/calculated!	Custom cylinders may give additional uncertainty in discharge time due to variations in thermodynamic properties	Use standard cylinder sizes to get best accuracy
XX is not a valid YY approved cylinder type.	Self-explanatory	Use an approved standard cylinder type/size
Pipe XX inlet Tee split ratio YY is lower than the minimum limit ZZ for this standard and Tee connection type. Please change the system layout or the nozzle flows.	The inlet tee split ratio is lower than the minimum value in the selected standard	Increase flow rate in the pipe (larger nozzles) or reconfigure the pipe system (ex. using two splits in series)
Pipe XX inlet Tee split ratio YY is higher than the maximum limit ZZ for this standard and Tee connection type. Please change the system layout or the nozzle flows.	The inlet tee split ratio is higher than the minimum value in the selected standard	Decrease flow rate in the pipe (smaller nozzles) or reconfigure the pipe system (ex. using two splits in series)
Nozzle XX orifice diameter YY mm exceeds the maximum orifice diameter ZZ mm for nozzle family WW. Decrease nozzle flow or choose nozzle family with larger nozzles.	Self-explanatory	Decrease the nozzle size (or decrease volume coverage for nozzle)
Nozzle XX orifice diameter YY mm is smaller the minimum orifice diameter ZZ mm for nozzle family WW. Increase nozzle flow or choose nozzle family with smaller nozzles.	Self-explanatory	Increase the nozzle size (or increase volume coverage for nozzle). If possible replace two nozzles with one
The system is designed/simulated with a pipe system working pressure safety factor of less than one! This may result in a dangerously high pipe pressure!	Self-explanatory	Increase safety factor and/or switch to a pipe family with a higher working pressure
The system is designed/simulated with a user defined pipe system working pressure equal to XX barg. The user is responsible for ensuring a safe pipe pressure!	Self-explanatory	Switch to another pipe family, instead of using a user defined working pressure
The 95% IG-541 discharge time: XX sec. is shorter than YY sec, allowed by the selected standard!	The time to discharge of 95% of the total IG-541 mass, is shorter than allowed by the selected standard	Increase discharge time
The 95% IG-541 discharge time: XX sec. is longer than YY sec, allowed by the selected standard!	The time to discharge of 95% of the total IG-541 mass, is longer then allowed by the selected standard	Decrease discharge time

File: Ci Manual 2024-11 Page 73 of 143



Text	Explanation	Possible solution(s)
The discharge time: XX sec. is longer than YY sec, allowed by the selected standard!	The discharge time to target concentration is longer than allowed by the selected standard	Decrease the discharge time to target. It may be necessary to increase the number of cylinders (higher Design factor)
Manifold: XX orifice diameter YY mm exceeds the maximum orifice diameter ZZ mm for this manifold type. Increase the number of manifolds and/or the discharge time.	The manifold orifice diameter has hit its upper limit	Decrease the maximum flow for the manifold. Increase number of manifolds or increase the discharge time
Manifold: XX orifice diameter YY mm exceeds the maximum orifice diameter ZZ mm pr. inlet for this manifold type. Increase the discharge time, the actual IG-541 concentration or decrease the cylinder size.	The manifold orifice diameter pr. cylinder has hit its upper limit	Decrease the maximum flow from the cylinders. Increase the discharge time, use smaller cylinders or use more cylinders (increase Design factor)
Number of nozzles: XX exceeds the standard limit: YY	The upper limit on the quantity of nozzles has been hit	Use fewer and larger nozzles
Pipe XX nozzle/pipe area ratio: YY exceeds standard limit: ZZ	The pipe size is too small for the total nozzle size(s) supplied by this pipe	Increase the pipe size or decrease the nozzle size(s). Increase discharge time if using Fixed pipe
Nozzle XX orifice diameter YY mm is smaller than the standard minimum limit: ZZ mm.	The nozzle orifice diameter is too small	Increase nozzle diameter (increase the flow rate/decrease the discharge time). Use fewer larger nozzles
Ratio of total pipe volume to total cylinder volume: XX exceeds the standard limit: YY	The volume of the pipe system compared to the cylinders is too large	Decrease the pipe sizes or increase the number or size of cylinders. It may be necessary to increase the discharge time
Total pipe length: XX m from distribution system inlet to nozzle YY exceeds the standard limit: ZZ m	The distance from manifold orifice to farthest nozzle is too long	Move cylinders closer to nozzles, rearrange the pipe system
Pipe XX Mach number YY exceeds the standard limit: ZZ	The flow rate is to large in the pipe	Increase the pipe size or decrease the nozzle size(s). Increase discharge time if using Fixed pipe
Nozzle XX pressure YY barg is lower than the standard limit: ZZ!	The peak nozzle pressure is too small	Decrease the pipe flow losses: Bigger pipe(s) or smaller nozzle(s)
Nozzle pressure variance XX between nozzle YY and ZZ exceeds the standard limit: VV	The difference between the largest and smallest peak nozzle pressure is to large	Decrease the pipe flow losses to the nozzle with the smallest peak pressure: Bigger pipe(s) or smaller nozzle(s)
Pipe XX Re-number: YY is less than the standard minimum limit: ZZ	The pipe flow rate is too small	Increase the flow rate: Decrease the discharge time, decrease the pipe size or increase the nozzle size(s)

File: Ci Manual 2024-11 Page 74 of 143



Text	Explanation	Possible solution(s)			
The required working pressure: XX barg exceeds the user defined working pressure (applying a safety factor of YY)! The pipe system may be unsafe!	The simulated pressure is too high	Use higher WP pipes or decrease the pipe pressures (smaller manifold orifice or larger nozzles)			
The cylinder mass flow rates are not identical, the calculated discharge time may be inaccurate!	The simulated cylinder flow rates are not identical (only possible if using more than one manifold)	Adjust the manifold orifice sizes			
Room XX maximum over pressure: YY Pa exceeds maximum limit: ZZ Pa	The simulated room over pressure is larger than the limit	Increase the pressure relief area or decrease peak flow into room (longer discharge time)			
Room XX discharge time flooding target is higher than 95% of the actual final flooding: The calculated discharge time is not accurate!	The discharge time target is too large compared to the final IG-541 concentration	Decrease the discharge time target or increase the final concentration in the room			

CAUTIONS

Text	Explanation	Possible solution(s)
Using user defined custom cylinder volume: XX m^3, calculated cylinder empty and total mass not correct	Only give correct cylinder empty mass for standard cylinders	Use standard cylinders
Using user defined maximum nozzle to pipe area ratio: XX	Self-explanatory	Use extra caution
Nozzle XX interface size YY is smaller than pipe size ZZ.	A reducer is necessary to mount the nozzle to the pipe system	Remember to include it in the part list
One or more of the system orifices are not chocked. The nozzle pressure calculation accuracy may be degraded.	The pipe system pressure is too high for chocked manifold orifice flow. (Only possible when using high pressure pipes!)	Peak pressure and discharge time may be inaccurate. Use standard FE pipes (that do not support this high a pressure)

PDF CALCULATION REPORT

If a valid calculation is available (a valid Calc-ID), the pdf calculation report can be printed. Any calculation error will invalidate the calculation.

A list of warnings and cautions if there are any will be printed at the end of the calculation report in the calculation summary.

The calculation summary contains:

- HWV type
- Discharge valve type
- Time to discharge of 95% of all INERGEN™ in cylinders (this is not the discharge time to the discharge time target)
- IMT version number
- Flow sim engine or flow design engine revision date
- List of warnings
- List of cautions
- An optional list of "info"

All pages of the calculation report contain the IMT file name and Calc-ID in the footer, along with the current page number and the total number of pages.

File: Ci Manual 2024-11 Page 75 of 143



Application method

Total flooding is the only approved application method for INERGEN systems designed in accordance with this manual.

CAUTION:

All calculations are performed at the temperature stated in the IMT program (standard temperature is 21°C). If the temperature at the cylinder storage or the protected enclosure varies by more than \pm 5.5°C from calculated, the calculated design quantity of extinguishing agent may be incorrect.

The calculation method has only been investigated for the pipes and fittings specified in chapter 1 of this manual.

If cautions or warnings are printed on the software calculation print out, there is a risk that the system will not supply the designed quantity of extinguishing agent at the specific locations.

File: Ci Manual 2024-11 Page 76 of 143



Design

The following steps must be followed, in the order they are presented, to properly design an INERGEN total flooding system. A simple design example will be used throughout the steps to help understand each step.

Please refer to the datasheet "IMT Software general" for more details on specific functions.

STEP NO.1 - Determine the hazard area volume(s)

The first step in the design of a system is to calculate the volume of each area to be protected.

Multiply the length by the width to determine the area, and then multiply the area by the height to determine the volume for each hazard area.

If any area is an odd shape, the designer may need to divide it up into regular shapes that will allow volume calculations, and then sum all the volumes to determine the actual volume of that area. If the irregular shape might affect distribution of the agent, it may be best to calculate sections of the hazard area as separate areas and include nozzles for each of these areas.

If the ceiling height exceeds the maximum allowable ceiling height as defined in the General Information Section of this manual, multiple levels of nozzles must be designed into the system.

Complete this step for each area protected by the system.

Example:

Server room: 125m³

Length: 10.0m With: 5.0m Height: 2.5m

Subfloor 40m³

Length: 10.0m With: 5.0m Height: 0.8m

STEP NO.2 - Determine volume reductions

The volume of solid objects in each hazard area that are not removable can be deducted from the volume of the hazard. This volume may include columns, beams, cut-out room sections, closets that will always be closed, ducts that pass completely through the area without any openings, and any other large, permanently fixed objects that cannot be removed from the hazard enclosure. Calculate the volume of all such objects and add them together to determine the amount of space to be deducted from the volume. Complete this step for each enclosure protected by the system.

Example:

Server room:

Columns: $0.6m \times 0.6m \times 2.5m \times 3 \text{ columns} = 2.7m^3$

Subfloor:

Columns: $0.6m \times 0.6m \times 0.8m \times 3 \text{ columns} = 0.8m^3$

STEP NO.3 - Calculate Reduced Volume

Subtract the volume of solid, permanent objects (Step No. 2) from each of the hazard areas' volumes (Step No.1). The result is the reduced volume for the enclosure.

Room volume - solid object volume = reduced volume

Complete this step for each area protected by the system.

STEP NO.4 - Determine minimum design concentration

The Minimum Design Concentration (MDC) is determined by the hazard being protected and applied rules. A list of MDC can be found in this manual ch4 under "Design Concentration".

The Minimum Design Concentration is determined by the hazard present in the protected enclosure which requires the highest MDC.

Skip to the next step if using one of the built-in standards.

File: Ci Manual 2024-11 Page 77 of 143



STEP NO.5 – Specify INERGEN concentrations

If using one of the built-in standards, the MDC will be automatically selected when the appropriate "Authority" and "Hazard type" is selected.

Alternatively, the minimum design concentration in accordance with Step No 4. can be entered if "Custom" *Hazard type* is selected.

If design safety factors other than temperature and room pressure are to be applied (Tee factor and others) these can be added as a *Design factor*.

STEP NO.6 – Specify room temperature and room pressure

Enter room temperature and room pressure.

The design quantity of agent shall be adjusted to compensate for ambient pressure that vary more than 11% (equivalent to approximately 915m [3000ft] of elevation change) from standard sea level pressures (760mm Hg at 0° C [29.92 in. Hg at 70° F])

STEP NO.7 - SPECIFY CYLINDER TYPE

Choose cylinder type, filling specification and storage conditions for the cylinders.

Standard filling pressure is 200 or 300 barg @ 15°C. typical storage temperature is 21°C.

STEP NO.8 – Calculate quantity of INERGEN

By pressing the button "Calculate cylinders" IMT3 will calculate, the required quantities of INERGEN cylinders, the total INERGEN mass, Flooding, Actual concentration, Oxygen conc and CO2 concentration.

STEP NO.9 – Verify actual concentration

Check that the Oxygen concentration is above NEL or LEL also at the minimum operating temperature.

Provisions to limit exposure to below specified must be provided.

The ΔT is giving the corresponding oxygen concentration with respectively 10 and 20 °C difference from the calculated.

Oxygen	Oxygen	Oxygen	Max exposure
	$\Delta T = 10^{\circ}C$	$\Delta T = 20^{\circ}C$	(minutes)
12.0%	12.2%	12.4%	5
10.1%	10.3%	10.5%	3
8.0%	8.3%	8.5%	0.5

STEP NO. 10 - Determine nozzle quantity

Nozzle quantity will be determined by many factors, such as size and shape of the hazard area, height of the ceiling, etc.

To determine the quantity of nozzles required.

Land systems:

divide the room length by 7.32m (max inter-nozzle distance) and round up to the next whole number. Then divide the room width by 7.32m and round up to the next whole number.

Then multiply the two answers to determine the total nozzle quantity.

Marine systems:

Use 8.0m instead of 7.32m

Complete this step for each area protected by the system.

360° NOZZLE REQUIREMENTS:

Maximum coverage length per nozzle (radial distance): 5.18m.

Above distance should not be exceeded from the nozzle to the farthest point.

The radial distance is defined as the distance from the nozzle to the farthest point of the area protected. The nozzle should be placed as close to the center of the hazard area as possible. On multiple nozzle systems, the nozzles should be as equally spaced as possible.

File: Ci Manual 2024-11 Page 78 of 143



Nozzle limitations

Maximum nozzle height above floor level for a single row of nozzles

Land systems (mono-orifice): 4.7m Marine systems (MED nozzle): 6.0m

For ceiling heights over above limits, additional row(s) of nozzles is required.

Minimum clearance in front of nozzle: 0.1m
 Minimum clearance behind nozzle: 0.0m
 Minimum protected area height is 0.3m

- For multiple level hazard areas, the intermediate levels of nozzles must be positioned at the top of the designed height for each intermediate level. Nozzles mounted at the ceiling must be within 1.0m of the ceiling.
- If noise level is a concern, additional nozzles may be used to reduce the noise level and a silencer should be installed, consult datasheet for recommendation regarding performance.

 The silencer is NOT FM approved (see section regarding Nozzle and silencer)
- If the room is an odd shape, the designer may wish to increase the nozzle quantity to provide a more even distribution of the agent.

STEP NO. 11 – Designing the pipe system

See IMT3 main features -> Pipe drawing tab. Only the flow path of INERGEN is included in the calculation. Dirt-traps may be placed at last nozzle without affecting the calculation, whether or not it is included in the design.

STEP NO. 12 - Determine nozzles locations

Using a plan view drawing of the protected areas, locate each nozzle and the cylinders. Then complete the 3D drawing using the IMT software as represented below, indicating the length of each pipe section.

NOTE:

- Nozzles should be placed as far from pressure vents as practically possible.
 Typically placed in the upper part of the hazard area, directed away from structures or object which could disturb the flow of INERGEN.
- Nozzles should be placed as evenly as possible within the protected area.
- A radial distance of minimum 0.5m from side of the nozzle must be clear to avoid damage to the structure.

If placed closer, deflectors should be used.

STEP NO. 13 – Pipe system calculation

Go to the Calculation tab and use Calculate pipe system to start the pipe system calculation.

File: Ci Manual 2024-11 Page 79 of 143



STEP NO. 14 – Calculate required area for pressure venting

Based on the discharge time and agent volume the mass flow is calculated by IMT and the required pressure relief area is calculated

The formula below is used to calculate the pressure relief opening area. For more detail, consult CEA 4008.

$$A = \frac{M * V_g}{\sqrt{\Delta p * V_{bl}}} * \sqrt{\frac{C_1}{2}}$$

$$V_{bl} = (1 - x) * V_{air} + x * V_{g}$$

A: Pressure relief opening area; m²

M: Mass flow of extinguishing agent; kg/s at t=0 (convert the flow from step 14, using the table below)

V_{bl}: Specific volume of blend; m³/kg (calculate using values from step 13 and table below)

V_g: Specific volume of extinguishing gas; m³/kg

V_{air}: Specific volume of atmospheric air; m³/kg

 Δp : Allowed pressure rise in the protected area; Pa (if Δp is unknown, use 500 Pa. This is considered a light construction and will generate a larger opening than might be required)

 C_1 : Resistance value for pressure relief opening C_1 =2 for openings with high flow resistance

x: Extinguishing concentration; m³ agent/m³ protected area

Temperature (°C)	V_{air}	$V_{g.\ INERGEN}$
-10	0.749	0.625
0	0.777	0.649
10	0.806	0.673
20	0.834	0.696
30	0.862	0.720
40	0.891	0.743

Specific volumes of air and Inergen at standard pressure

STEP NO. 15 - Create a bill of materials


Use the IMT "part finder" to generate a list of all materials and parts necessary to install the system.

File: Ci Manual 2024-11 Page 80 of 143



STEP NO. 16 - Create installation drawings
The final step in the design of an INERGEN system is completion of installation drawings for submission to the appropriate authority and the customer. These drawings should include all details necessary for installation of this system.

File >> Print drawings may be used to generate these:



Alternatively, the pipe system can be exported as a DXF file using File >> Export as dxf.

File: Ci Manual 2024-11 Page 81 of 143




Multizone systems (DV7 and SV valves)

The following information must be considered when designing a selector valve system.

- Selector valve systems should only be used for multi areas where each area is a separate fire zone.
- Each hazard area must be calculated as a separate system design.
- Start with the largest system, in order to determine the quantity of cylinders required.
- After calculating the largest system, complete additional system calculations.
- Selector valves can be located either upstream or downstream of the pressure reducer.
- The piping located between the pressure reducer and the selector valve must be rated for the system (cylinder) working pressure, respectively 200 or 300 bar [4350 psi] or greater.

The following drawing is an example of a selector valve system.



Α

Actuator; can be solenoid, push button or pneumatic

Р

Pneumatic actuator

MA • One way mechanical link between SV CiV and IV8 valve



SV CiV



IV8 valve

X

SV22 selector valve

-\$~

Non-return valve / check valve

File: Ci Manual 2024-11 Page 82 of 143



Main and Reserve System

Normally the authority having jurisdiction will determine whether a hazard requires a reserve set of INERGEN cylinders, either connected or spare.

NFPA 2001, Standard on Clean Agent Fire Extinguishing Systems (2022), states:

"Where required, a reserve agent supply shall consist of as many multiples of the primary agent supply as the authority having jurisdiction considers necessary."

"Where uninterrupted protection is required, both the primary and the reserve agent supplies shall be permanently connected to the distribution piping and arranged for easy changeover".

FM Global and IRI (Industrial Risk Insurers) require the following:

"In high pressure systems an extra full complement of charged cylinders (connected reserve) manifolded and piped to feed into the automatic system should be provided on all installations. The reserve supply is actuated by manual operation of the main/reserve switch on either electrically operated or pneumatically operated systems.

A connected reserve is desirable for several reasons:

Protection, should reflash occur.

Protection during impairment when main tanks are being replaced.

Protection of other hazard areas if selector valves are involved and multiple hazard areas are protected by the same set of cylinders.

If a full complement of charged cylinders cannot be obtained, or the empty cylinders recharged, delivered and reinstalled within 24 hours, a third complement of fully charged spare cylinders should be maintained on premises for emergency use.

The need for spare cylinders may depend upon whether or not the hazard is under protection of automatic sprinklers".

When designing a system, always determine if, and what kind of, reserve system is required.

NOTE: Usage of reserve systems with primary system may make hazard area unsafe for normal occupancy.

File: Ci Manual 2024-11 Page 83 of 143




Typical application
A server room is here used as an example for a typical Fire Eater total flooding INERGEN system.

The area consists of the server room itself and a subfloor.

An Inergen system can be used - and the room protected - even when normally occupied. Alarms or warning devices must be located in the protected area and give occupants sufficient annunciation of imminent Inergen discharge.

Area to protect:




File: Ci Manual 2024-11 Page 84 of 143



IMT3 output example:

IMT Isometric drawing



IMT Calculation

Printout shown on the next pages

File: Ci Manual 2024-11 Page 85 of 143





IMT 3.0.x calculation report

Project

Type
Application type
Location
Address 1
Address 2
Country
Contact name
Contact phone
Contact mall

Our reference Henrik Ditiev Nissen
Our reference mail hdn@fire-eater.dk
Purchase order no.

Purchase order no. Information Revision A Rev. description

Design state Work in progress

Customer

Name
Number
E-mail
Address 1
Address 2
Country
Phone
Contact name
Contact phone
Contact mail

System data

Cylinder type	inergen 80L steel cylinder					
Cylinder quantity	4					
Cylinder fill	15.0 °C	300.0 barg				
Cylinder storage	20.0 °C	308.8 barg				
Atmospheric pressure	1013.0 mbar					
Authority	NFPA 2001:2015					
Pressure relief resistance	1.0					

Rooms

Room	1	2	Total
Name	Under floor	Room	
Volume [m³]	39.2	122.3	161.5
Temperature [°C]	20.0	20.0	
Hazard	٨	٨	
MDC [%]	34.2	34.2	
Design factor [%]	5.0	5.0	
Final inergen [%]	44.1	44.1	
Flooding [%]	58.1	58.1	
Inergen mass [kg]	32.18	100.40	132.58
Final O2 [%]	11.7	11.7	
Final CO2 [%]	3.5	3.5	
Max flow rate [kg/s]	0.37	1.11	1.48
Max over pressure [Pa]	500	500	
Pressure relief (cm ²)	66	201	267

Discharge

Pipe family	FE galvanized welded steel pipe EN10220/10217-1 P235TR1.					
Actual discharge time target	32.5% IG-541					
Discharge time	120.0 sec					

File: UL-FM-manual-example.imt

1/6

Calc-ID: FE-DK-HDN-20181026-183920





Pipe system

No.	N1	N2	Elv	Start	End	Elb	Con	Noz	Room	L	Vol	т	N/P	DN	Press	Dia	М
MT_no1															301.6	5.5	
Pipe															76.5		
1	1	2		Plain	T branch	0	0			0.6		100.0	28.6	DN-20			0.130
2	3	4	-0.4	T branch	Plain	1	0	IN-15	1	1.8	19.6	50.0	6.3	DN-15	75.48	3.71	0.031
3	3	5	-0.4	Trun	Plain	2	0	IN-15	1	5.4	19.6	50.0	6.5	DN-15	75.19	3.77	0.032
4	6	7	2.2	Trun	Plain	1	0	IN-15	2	1.7	61.2	50.0	20.8	DN-15	70.14	6.73	0.101
5	2	3		Trun	Trun	1	0			2.8		24.3	12.9	DN-15			0.062
6	6	8	2.2	Trun	Plain	1	0	IN-15	2	1.7	61.1	50.0	20.8	DN-15	70.15	6.72	0.101
7	2	6		Trun	T branch	2	0			5.6		75.7	21.9	DN-20			0.103

Volume of pipe system: 0.0043 m³ Pipe to cylinder volume: 1.3 % Minimum pipe working pressure: 76.0 barg

Description

МТ Manifold with orifice

Pipe Pipe system inlet (flow from all manifolds merged)

inlet and outlet nodes N1, N2

Elv

Elevation
Connection at pipe inlet Start Connection at pipe outlet End Elb Number of 90 deg elbows Con Number of pipe connectors

Noz Room number Room m m³

Pipe length Volume of room protected by this pipe Vol

Tee split ratio Nozzie to pipe area ratio N/P Press barg Max pressure in pipe at outlet mm Diameter of orifice (Nozzie or Manifold) Dia

Mach number at pipe outlet







Oxygen and Inergen vs. time

Time	9.6	20.9	34.6	51.1	71.1	96.1	120.0	128.8	175.2	254.3	332.3		sec
Room1	19.8	18.6	17.6	16.6	15.7	14.8	14.1	14.0	13.2	12.4	12.1	11.7	02%
Room1	16	32	47	61	74	86	95	98	109	119	124	129	% MDC
Room2	19.8	18.6	17.6	16.6	15.7	14.8	14.1	14.0	13.2	12.4	12.1	11.7	02%
Room2	16	32	47	61	74	86	95	98	109	119	124	129	% MDC

Room O2% plots





4/6


File: UL-FM-manual-example.imt

Calc-ID: FE-DK-HDN-20181026-183920





Discharge graphs



Calculation summary

HWV HWV-8mm

Discharge valve CI-IV8

Total inergen 95% ₫ 332.3 sec IMT vers. IMT3.0.0

Flow design engine 2018-08-01

Info No errors during calculation.

No warnings during calculation. No cautions during calculation.





Calculation resume

Parameter	This calculation	Limit
Calculation time		
Rules applied	NFPA 2001:2015	NFPA 2001:2015
Cylinder pressure (fill) @ 15°C	300.0 barg	NA
Cylinder volume	80 L	NA
Number of cylinders	4	NA
Mass flow	1.48 kg/s	NA
Pipe length max	8.8 m	300 m (max)
Pipe to cylinder volume	1.3 %	20 % (max)
Discharge time to target	120 sec	120 sec (max)
Discharge time to 95% total IG-541	332.3 sec	30 - 600 sec
Max pipe pressure	76.5 barg	Defined by pipe
Re-number min	7.3E+05	4.0E+05 (min)
Mach number max	0.13	0.40 (max)
Max system orifice to pipe area ratio	6.3 %	64.0 % (max)
System orifice (all orifices)	23.9 mm ²	NA
Tee split builhead	24% / 76%	5% / 95%
Tee spilt run/side	50% / 50% - 50% / 50%	5% / 95% - 95% / 5%
Nozzie orffice min	ø3.7 mm	ø3.0 mm (min)
Max nozzie orffice to pipe area ratio	29 %	70 % (max)
Nozzie pressure peak min	70 barg	20 barg (min)
Max nozzie pressure variance	1.08	2.00 (max)
Nozzie flow max/min	0.56 / 0.18 kg/s	NA
Elevation change	3 m	50 m (max)
Temperature (cyl. storage)	20.0 °C	NA
Nozzie quantity	4	100 (max)



CHAPTER 6: INSTALLATION

General

All installations are to be performed in accordance with the parameters of this manual and all appropriate codes and standards from the authority having jurisdiction.

Before the INERGEN system is installed, the qualified installer should develop installation drawings in order to locate the equipment, to determine an actuation and distribution piping routing, and to develop a bill of material.

For successful system performance, the INERGEN system components must be located within their approved temperature ranges.

Only certified personnel should install Fire Eater INERGEN systems. Fire Eater Document INMON001 must be observed when handling pressurized cylinders.

Planning

The order in which the different parts are installed must be planned prior to the installation to avoid any dangerous situation which could arise in case of accidental activation of the extinguishing system.

Order in which the parts should be installed.

1. Distribution pipe-system

Cylinders

Manifold and Orifice

Room pressure reliefs.

Actuation circuitry (electrical and/or pneumatic)

Detection system

Control panels

Alarm and Indicators

- 2. Nozzles
- 3. Discharge valves (pressurized for integrity test)
 Discharge hoses
- 4. Discharge valve accessories and actuators
- 5. Signs and labels
- 6. Open and Seal Hand wheel valves

File: Ci Manual 2024-11 Page 91 of 143



Mounting of components

[01 + 02] Cylinders & Cylinder rails & Brackets

INERGEN cylinders may be located inside or outside the protected space, although it is preferable to locate them outside of the space. They must not be located where they will be exposed to a fire or explosion in the hazard. When they are installed within the space they protect, a remote manual control must be installed to release the system safely from outside the hazard area.

The cylinders should be installed so that they can be easily removed after use for recharging. Cylinders should be installed indoors; if located outdoors, cylinders must be protected using appropriate weather protection. Do not install the cylinders where they are exposed to direct sun. Cylinders may be installed horizontally or vertically. They should not be installed with the valve pointing downward as the valve could be blocked in case of dirt inside the cylinders.

Both steel brackets and wooden brackets are available.

For land bases system with standing (vertical) cylinders, minimum 1 rail/bracket set for each cylinder is required.

For Marine, Offshore and installations where vibrations and/or earthquakes may occure, or when discharge nozzles are fitted directly to the cylinder, minimum 2 cylinder brackets per cylinder are required.

MOUNT EACH INERGEN CYLINDER BY COMPLETING THE FOLLOWING:

CAUTION

Do not remove the safety shipping caps at this time. They are provided to prevent accidental actuation and discharge during shipping and handling. If valve assembly is accidentally operated, the velocity of the unrestricted escaping gas is powerful enough to cause injury, especially to the face and the head.

- Assemble bracket components.
- If a reserve system is being installed, mount the reserve cylinder(s) directly next to the main system cylinder(s).

CAUTION

Proper fasteners must be used when mounting cylinder bracketing to wall or support. Failure to properly mount could cause cylinder movement upon discharge.

- Securely mount bracketing to rigid wall or support.
- Fasten cylinder(s) securely in bracketing.

File: Ci Manual 2024-11 Page 92 of 143



Figure 1 (single row)


01 & 02 INERGEN cylinder and brackets. See "Control Inert System description" for item numbers.

- A. Cylinder rail is available in different length
 The rail is fastened to the wall, drilling holes in the rail
 to accomplish installation is required
 Use 1 screw + 1 nut per cylinder.
 Screws must be minimum ø6mm and must be evenly
 distributed throughout the length of the rail.
- B. Place the cylinder in front of the rail (Valve cap must be on the cylinder
- C. Cylinder bracket
 Turn 45° and insert in slot of cylinder rail
 One part on each side of the cylinder.
- M10 bolt (included with cylinder bracket)
 The bolt is inserted through the eye in the bracket and tightened to app 10Nm
- E. Remove the valve protection cap
 Rotate the cylinder so that the valve outlet is pointing
 straight forward (if nessecary loosen the M10 bolt
 slightly).
 Tighten the bolt and nut on the brackets
- F. When 2 pairs of brackets are used, the lower bracket is mounted 200mm from the foot of the cylinder. The height of the top brackets (Hbrk1) depends on the size of the cylinder and is given in the table below.

Cylinder size 140 litre	H _{bracket} 1400
80 litre	1400
50 litre	1200
30 litre	700

Cylinders positioned laying down should be fixed with 2 brackets.





File: Ci Manual 2024-11 Date: 2024-11-01



The rail


The rail is fixed to the wall by using screws compatible with the wall to which is attached.

If the wall has insufficient strength to support the cylinders, it is necessary to erect a frame to hold the cylinder rail.

The rail may also be welded to the fixture.

The Brackets

Simultaneously with the cylinder installation the brackets are placed in the rail by inserting and twisting them 45°. Notice that the brackets are still free to move from side to side until the bolt in front of the cylinder is tightened.



File: Ci Manual 2024-11 Page 94 of 143



Figure 2 (multiple row)

Same rail and brackets as for single row are used. Additional rails are fastened to the first by using item 400123 bracket (Elbow)


D. Bracket (Elbow) Item 400123

One elbow + one elbow per 2 cylinder is required.

The M10 bolt from the brackets of the previous row of cylinder are unscrewed and put through the hole in the elbow and then fastened to the cylinder bracket.

E. M10 bolt (included with bracket)

The bolt is inserted in the other hole in the elbow and used for fastening the next cylinder rail (hole drilling in rail is required).



File: Ci Manual 2024-11 Page 95 of 143




Figure 3 (wooden beams)

Wooden beams can also be used to support cylinders in vertical as well as horizontal position. The wooden beams provide better support for the cylinders and should be used if cylinders are stacked laying down.

- F. M12 threaded rod (Stainless) (f)
 The rod is inserted through the center hole on the steel base and the wooden outer beam (g +h)
- G. Rack Outer beam (g)
 This is keeping the cylinder in place so it does not roll
- H. Rack Bottom U-profile (h)
 Is supporting the wooden beam
- I. Rack Cross beam (i)

The rack cross beam is being placed on to of one layer of cylinders so that the next layer of cylinders can be added. M12 Nut, M12 washers

Washeres and nuts must be fitted to the threaded rod. It is important that the washers and nuts are placed at the bottom of the center rod before cylinders are layed down, as it will not be accessible afterwards.



File: Ci Manual 2024-11 Page 96 of 143



[12] Discharge valve accessories

DV7


If a cylinder is to be fitted with more than one discharge valve, or other outlets are required an adapter (DV7) can be fitted, allowing for installation of 2 or 3 discharge valves per cylinder.

This way up to 3 separate hazards can be protected from a single cylinder.

TO INSTALL A DV7

- A. Verify that the thread is correct 300 bar = M25×1.5 = Green Hand wheel = Round edge (not chamfered) 200 bar = W24.32 = Black Hand wheel = Chamfered edge
- B. Make sure sealing surfaces are clean and well lubricated Apply additional O-ring lubricant
- C. Place the DV7 on the valve outlet
- D. Tighten the union nut by hand until O-ring reaches the valve outlet surface (tightening becomes hard suddenly)

A slow increase in tightening torque indicate that there is something wrong Tighten to approximately 60 Nm (max 1/8 turn).



File: Ci Manual 2024-11 Page 97 of 143



[11] Ci IV8 installation

Do not apply PTFE tape or any other thread sealant on the connecting thread.

Remove the plug from the valve inlet

 Check that nut matches the thread on the hand wheel valve.

M25/300bar is identified by a green hand wheel and rounded edge on the nut.

W24/200bar is identified by a black hand wheel and a 45° chamfer on the nut.

- 2. Inspect the O-ring. Ensure that it is clean and placed in its groove.
- 3. Apply some O-ring lubricant if nessecary.
- 4. Attach the IV8 to the hand wheel valve by simply screwing it on.
- 5. Tighten to approximately 60Nm (max 1/8 turn) Use a 32mm spanner.



C. Discharge outlet 3/8" ISO228 (bspp).

This port is connected with a hose to the manifold, or directly to a nozzle through an adapter (orifice).

When valve is activated INERGEN is discharged through this port. This is also used for backpressure activation on slave valves.


D. Pneumatic activation outlet and inlet.


All equipment connected here MUST be rated for the same working pressure as the cylinder.

If backpressure is disabled (Non-return valve in manifold eg.) this port is used for pneumatic activation.

E. Actuator connection

Actuators are only installed on the master cylinder.





File: Ci Manual 2024-11 Page 98 of 143




Other valves

Proceed with connecting the discharge valves until all each cylinder has one.

<u>DO NOT</u> pressurize the valves at this stage, as a discharge hose must be installed first.

Pressure monitoring

The manoswitches are connected in a daisy chain and fitted with a end-of-line resistor to suit the control panel.



File: Ci Manual 2024-11 Page 99 of 143




Cylinder pressure monitoring

The pressure switches are part of the standard Ci IV8 valve and feature a change-over switch enabling the switches to be connected in a daisy-chain with proper end of line resistors.

The cable from each manoswitch is connected to the plug on the next manoswitch.

TO PLUG IN THE M8 CONNECTOR

- 1. Make sure the connectors are clean.
- 2. Align the male and the female connector.
- 3. Rotate one of the connectors to align the pins with the sockets.
- 4. Gently push the plug on, if necessary rotate careful to align pins.
- 5. When connector is pushed in, start rotating the nut on the cable end.
- 6. Tighten to approx 0.2Nm.



File: Ci Manual 2024-11 Page 100 of 143



[21] Actuators

General

The Ci IV8 is activated either by an actuator, the built-in Pneumatic actuator or by backpressure (outlet to manifold).

Different types of actuators are available depending on the requirements of the system design.

At least one actuator must be used on each system (zone being protected).

When using the Ci MT manifold (special check valves) all cylinders are activated by back-pressure from the Master cylinder (the one the actuator is placed on).

When using SV MT manifold (Non-return valves that disable the backpressure function), the built-in Pneumatic activated must be used (use the SV next kit, or PA kit).

For SV multi-zone the SV CiV valve is installed on the Master cylinder before installing the actuator.

CAUTION

Make sure that the actuator is reset before installing it on the discharge valve. Failure to do so will cause system activation. DO NOT install/connect actuators before cylinders are secured and discharge hoses are fitted.

Ensure all electric power from the panel to the actuator has been disconnected. Failure to disconnect power may cause the system to accidentally discharge.

Before installing an actuator, it must be inspected to verify that it has not been activated (plunger must be below end surface of the actuator). If it has been activated see "maintenance" for resetting.

Actuators can be fitted to any of the cylinders in a system. The cylinder with the actuator will be designated "Master Cylinder". The remaining cylinders which are activated by the manifold pressure will be referred to as "Slave Cylinders".

More than one actuator may be installed on the same system.

Built-in Pneumatic actuator

To connect the built-in pneumatic actuator, the 1/8" plug must be unscrewed from the valve body and the Tee from the PA kit is installed, the Dn6 hose are connected between the tees'. The ends of the PA line are fitted with Bleed fittings which prevent undesired pressure buildup.

Manual Actuator

The actuator is screwed into the Ci IV8 valve mechanical connection and tightened by hand (10Nm).

The two set screws are loosened, and the knob is rotated so the safety pin is in a convenient position. Only loosen the set screws! The two set screws must be tightened again, do not use excessive torque!

Pneumatic Actuator

The actuator is screwed into the IV8 valve mechanical connection until it reaches the stop, then it is turned back so that one of the inlet connections (1/8" ISO7) is in a proper position, it should never be turned more than 1/2 turn back.

A hose or tube must be connected to at least one inlet connection, to avoid accidental unscrewing due to vibrations.

After installing the PA8 Pneumatic Actuator, one additional actuator may be installed on the PA8.

Solenoid actuator

Before installing an electrical actuator, the actuator attachment switch must be installed on the Master cylinder in order to comply with NFPA2001.

The actuator is screwed into the IV8 valve mechanical connection and tightened by hand (10Nm).

The M12-4 electrical connection are connected to the junction box or directly to control panel.


File: Ci Manual 2024-11 Page 101 of 143





CI IS8 NFPA SWITCH:

The Ci IS8 NFPA switch can be connected to the control panel in 3 ways. (a is the recommend way of connecting the monitoring switch)

- a. To the Low pressure monitoring switch When the actuator is removed from the Master valve/cylinder the control panel will indicate "Flooding Zone Fault".
- b. To the Fault input signal When the actuator is removed a general fault will be indicated
- c. To separate set of lamps indicating whether the actuator is attached or if it has been removed.







File: Ci Manual 2024-11 Page 102 of 143




CI IS8 WIRE CODE:

1: Brown +Ve 2: White +Ve 3: Black -Ve 4: Blue -Ve

CI IS8 NFPA SWITCH:

1: Brown Common

2: White Closed with Actuator removed 4: Green Closed with Actuator attached




File: Ci Manual 2024-11 Page 103 of 143



Ci MT Next kit


ATTACHING ACTUATORS TO DISCHARGE VALVE

When more than one manifold is used on a stand-alone system, it is necessary to get the activation pressure from valves activated by the pressure in one manifold to one valve on the next manifold.



To install the kit

- 1. Remove the 1/8" plug from the IV8 PA in/outlet using a 5mm Inhex wrench
- 2. Apply PTFE tape or other thread sealant to the tapered 1/8" thread on the adapter 302467.
- 3. Screw the adapter into the valve
- 4. Attach the hose to the adapter and tighten DO NOT apply thread sealant on the $\frac{1}{4}$ " thread for the hose connection.



File: Ci Manual 2024-11 Page 104 of 143





[41-43] Manifold installation

Orifice Installation

Proceed as follows:

- Identify that the orifice has the right connection thread (NPT is identified by a groove in the shoulder. ISO (bspt) has no groove
- Identify that the orifice has been calibrated to the correct orifice diameter.
 The orifice diameter is stamped into the side of the adapter, and can be seen with the union pulled up over the shoulder.
- 3. Remove the plug from the orifice pipe thread Apply PTFE tape or other thread sealant to the pipe thread.
- 4. Insert the thread into the pipe system socket.
- 5. Tighten the adapter by using a pipe wrench, do ONLY grip on the curled schoulder, never on the smooth surface of the pipe as this will damage the marking making identification dificult.





File: Ci Manual 2024-11 Date: 2024-11-01



Manifold Installation

6. Find the O-ring 212097 (26×1.5) and apply O-ring lubricant.


7. Insert the O-ring in the groove in the orifice (/pipe adapter)

8. Check to see that it is placed correctly.


Remove the plastic cap from the Manifold M40 thread Do NOT apply thread sealant to the manifold thread

9. Insert the manifold to the orifice

10. Tighten the union nut on the manifold. App 50Nm



NPT thread is identified by a goove in the shoulder, ISO (bspt has no groove).








File: Ci Manual 2024-11 Page 106 of 143



[31] Discharge hoses

Attaching hose to valve


1. Connect the hose with the elbow to the discharge outlet. Always start with the shortest hoses.





2. Connect the hose to the manifold.

When hose is attached to the manifold the check valve in the manifold will open slightly.




- 3. Tighten both hose connections.
- 4. Proceed with the next discharge valve until all valves are connected to manifolds.
- 5. Use hose fixations on the pilot cylinder (the one with manual activation) and on cylinders closer than 1 m from the pilot cylinder if the hose is longer than 50 cm

File: Ci Manual 2024-11 Page 107 of 143



Hose details

Make sure that there are no sharp bends in the hoses:



File: Ci Manual 2024-11 Date: 2024-11-01 Page 108 of 143



[51 - 54] Distribution piping

Only pipe described on page 15, and pipe hangers and fasteners described on page 16 should be used

Install the pipe hangers in accordance with good piping practice as well as the following:

- 1. Refer to ASME 831.1, "Power Piping Code," and any appropriate local codes and standards.
- 2. A hanger should be installed between fittings when the fittings are more than 600 mm apart.
- 3. A hanger should be installed at a maximum of 100 mm for pipe <DN25 and 250mm for >DN25 from the nozzle. It must be located to keep nozzle from moving vertically.
- 4. The hangers must be UL listed and/or FM Approved and rigidly supported.

Installation

- 1. All threaded pipe beyond the manifold, or selector valve if applicable, to be black iron or galvanized
- 2. Cylinder and piping to be securely bracketed especially at the fittings and nozzles.
- 3. Ream, clean, and blowout all pipe before installing.
- 4. All dead end pipe lines to be provided with a capped nipple, 2 in. long.
- 5. All pipe lengths are measured center to center of fittings.
- 6. All distribution pipe and fittings must be assembled using either pipe tape or other appropriate sealant. Do not add to the first two threads nearest the end of the pipe.
- 7. Size reductions can be accomplished with the use of reducing bushings, reducing couplings, reducing tees or reducing elbows.
- 8. Bushing up (increasing pipe size) in the downstream piping is acceptable immediately after the pressure reducer only. Increase in size can be no greater than two nominal pipe sizes. Only the use of a close nipple and reducing coupling or a *swaged* nipple can be used.
- 9. Nozzles to be located at the top of the hazard area, directed downwards.

[61] Nozzle

Nozzles are installed on the pipe by the same way as the pipe fitting.

Nozzles must be placed in the correct location in accordance with the installation drawings in order to supply the correct amount of INERGEN to the designated area.

File: Ci Manual 2024-11 Page 109 of 143



[1xx] Multizone systems

Selector valves and Manifolds

To support the SV22 or SV48 during installation a Cylinder railed is fastened to the wall. SV22 app 2600 mm above cylinder foot SV48 app 2780mm above cylinder foot.

SV22 system

The distribution manifold is made by the Tee's supplied with the Zone and Manifold kits.


The Zone kit is assembled and hanged in the cylinder rail minimum 2 selectorvalves must be placed in the rail, Manifold kits can be placed between these zone kit, the kits are slided together and sealed by the Oring in the Tee. Unions are tightened so that the will not come loose due to vibration etc.

The distribution manifold is completed by installing the end plugs in the first and last Tee from the zone/manifold kit.

Additional bracket may be used to support the SV48 valve.

For SV48 it is recommended to assembly the manifold distribution line on the floor due to the high tightening forces and then lift the manifold into place as a assembled manifold with Selector valves, the inlet manifolds should be fitted after as the connections on these are sensitive to physical damage.


SV22 system drawing



File: Ci Manual 2024-11 Page 110 of 143




SV48 system




File: Ci Manual 2024-11 Date: 2024-11-01 Page 111 of 143



Manifold kit details






File: Ci Manual 2024-11 Date: 2024-11-01 Page 112 of 143







File: Ci Manual 2024-11 Date: 2024-11-01 Page 113 of 143



CHAPTER 7: TESTING AND COMMISSIONING

General

This chapter serves as a guide for final test and inspection before a system is commissioned.

Always check with the authorities having jurisdiction if additional requirements apply. Always check the system specifications to see if special attention should be required if other components are used etc.

The purpose is ensure that the system has been properly installed and will function as specified.

All mechanical components shall be checked for their suitability for the application and to make sure that their installation is in accordance with the system listing.

Non-system listed components must be identified and checked to ensure they are suitable for the system and acceptable to the authority having jurisdiction.

The completed system shall be tested by competent personnel to prove the correct operation of all required functions.

The detection and actuation system shall be tested in accordance with the control panel manual.

NOTE: Before starting any testing, REMOVE ALL ACTUATORS from their discharge valves.

Reinstalling the actuators after testing is the LAST operation to do.

Inspection & Test

Use the check list in chapter 9, and the guide and requirements in this chapter.

Tightness verification

In addition to these test a 24 hour leakage test should be made very time permanent pressurized parts have been dismantled. The Leakage test is performed by pressurizing the discharge valve/acc, by opening the hand wheel valve for 1 minute and the close it again. Mark the pressure on the pressure gauge dial and after 24 hours the hand wheel valve is reopened, if a pressure drop can be recorded the leakage must be identified and repaired.

System configuration

Review the "as-installed" plans to ensure that they accurately represent the system configuration of the area to be protected.

Warning signs and notices

Check that warning signs and safety instructions are installed in accordance with NFPA 2001, and observe if local regulations require additional signs.

Enclosure integrity & venting

All total flooding systems shall have the protected enclosure checked to locate and effectively seal any significant air leaks that could result in a failure of the enclosure to hold the specified extinguishing agent concentration level for the specified holding period.

NOTE: The data derived from this test should be retained as a benchmark for future tests.

Review the adequacy of the enclosure for its ability to vent pressure fluctuations developed during system discharge, taking into account the following:

- the equivalent leakage area determined from the enclosure integrity test.
- the provision of any required additional pressure vents.

File: Ci Manual 2024-11 Page 114 of 143



Cylinders

Cylinders may be stored in the protected area or in a separate cylinder storage room. The cylinders are high pressure cylinders and local authorities may have special regulations of how these have to be inspected and tested.

Check that all INERGEN cylinders are:

- properly located in accordance with the approved drawings
- in correct number and size and are appropriately marked
- charged in accordance with the "as-installed" drawing and correctly labeled
- positioned such that gauges can be read
- Securely fastened in accordance with the manufacturer's requirements.

Discharge valves Manoswitch and Actuators

Verify that actuator is positioned on the correct Master Valve.

Check that all actuators are:

- attached to the cylinder as indicated on the "as-installed" drawings
- properly connected, correctly set to operate and with safety devices disengaged
- when pneumatic actuation is used, that the hoses, pipes and adapters are correctly fitted
- installed correctly and have safety pin in place and are sealed (manual actuators)
- readily accessible, accurately identified, and properly protected to prevent damage

NOTE: Particular care should be taken to ensure labeling is unambiguous where manual actuators for more than one system are in close proximity and could be confused or the wrong system could be actuated.

File: Ci Manual 2024-11 Page 115 of 143



Manifolds, Hoses and Zone valves

Check the following:

- Manifold piping joints are physically checked for tightness and supports are checked
 A pneumatic pressure test at 2.7 bar (40 psi) should be performed¹
- Hoses are free from kinks and physically checked for tightness. Ensure that flexible connectors with integral check valves are installed for the correct direction of flow.
- PA hoses are used on correct inter-manifold valves and SV system.
- Selector valves, where used, are correctly fitted, and actuation circuitry is correctly installed.
- Bleed fittings are all open (pin is flush with the housing).
- All hand wheel valves are opened and sealed when all tests are completed.

SV Distribution manifold leakage test. This test is to be done pneumatically (preferable with pure Nitrogen) as parts are to be dry and clean after the test.

As all SV22 parts has been pressure tested to 600bar at Fire Eater only the leak tightness of the assembly has to be verified. As all seals are based on O-rings the test can be performed at low pressure, but as O-rings require pressure to seal it may be necessary to elevate the pressure to ensure the O-rings will seat and hold tight.

Manifolds made with welding and tapered thread has not been pressure tested at Fire Eater and have to be pressure tested at 1.43x working pressure, if this is done with hydraulic pressure testing all SV valves and manifolds should be removed prior to pressure testing or must be dried after the pressure testing. The parts are designed to hold gas pressure for a limited time only. Prolonged exposure to high gas pressure may have adverse effect on the parts depending on the applied gas.

- 1. Remove any hoses connected to the manifold.
- 2. Close all SV valves.
- For distribution manifolds based on Fire Eater SV22 parts (O-ring seals)
 Pressurise the manifold to 20bar for 3 minutes and inspect for leakages.
 if leakages are found it may be necessary to increase pressure to ensure proper O-ring seating, or inspect for missing O-rings.
 Notice that
 - small leakages from check valves on Ci MT manifolds are acceptable,
 - No Leakage on the outlet of SV MT manifolds are acceptable.
- 4. Depressurise the manifold by opening a SV22 through the installed test port.

File: Ci Manual 2024-11 Page 116 of 143

 $^{^{1}}$ According to NFPA2001:2012 - chapter 7.7.2.2.12 The discharge time applies to the last room to reach the discharge time target INERGEN[™] concentration, regardless of the hazard class chosen for that room.



Pipe system

Review pipe work to ensure that its layout conforms to the "as-installed" plans; pipe sizes, means of pipe size reduction and configuration of tees conform to the "as-installed" plans as required for proper agent flow splitting and hydraulic performance and piping joints, discharge nozzles, and piping supports are securely fastened to prevent unacceptable vertical or lateral movement during discharge.

Pipe work must be pressure tested to 1.43x work pressure (as per Fire Eater INMON002),

- 1. Pipe system visually inspected joints are checked, nozzles are blinded.
- 2. Pressurized to 20% of test pressure maintained for 1 minute wo. pressure drop.
- 3. Pressure increased in steps of 1/10 (11 bar) until test pressure (typical 110 bar).
- 4. Test pressure maintained for 30 min.
- 5. Pressure lowered to work pressure.
- 6. Pipe system visually inspected and leak tested.
- 7. Pipe system depressurized.
- 8. If the test was made hydraulic the pipe system has to be drained and dried.
- 9. End plugs are removed and nozzles are fitted.

Pipe test and test report must satisfy the authorities' requirement.

Nozzles

Ensure that discharge nozzles are

- drilled and stamped in accordance with the system design and are correctly positioned
- installed so that they will not cause injury to personnel or located where their discharge could dislodge ceiling fittings such as lighting, exit signs and fire detectors; and
- installed such that they are not likely to detach or cause pipe work to be unthreaded by reaction forces during discharge.

NOTE: Wherever possible, the extinguishing agent should not directly impinge on areas where personnel may be found in the normal work area, on any loose objects or shelves, cabinet tops, or similar surfaces where loose objects could be present and become missiles.

Electrical system

Review the system to ensure compliance with the system drawings and local laws.

Verify that there is enough power to activate the system (use a powermeter).

Verify that cables are listed and comply with local authorities.

When manoswitch is used, verify that signals from the low-pressure alarms work correctly by using the Manoswitch emulator.

Verify that alarm devices (sounders, optical beacons) are fitted according to local authorities and emit signal.

Pressure relief

Verify function and position, they should be installed far from nozzles to minimize loss of gas.

File: Ci Manual 2024-11 Page 117 of 143



Function test

Actuators are to be removed from the discharge valve during this testing to prevent accidental discharge of the INERGEN system and test the actuators.

An initial alarm test should be conducted following installation to determine that all parts of the system are functioning properly. The panels should remain powered for 24 to 36 hours prior to connecting the releasing solenoids. This precaution will avoid false activation of the suppression system in case of faulty or improperly placed detectors.

To perform an alarm test on the control panel, proceed with the following steps:

- 1. Disconnect AC power and battery power.
- 2. Close Hand wheel valve on Master cylinder
- 3. Remove hose from valve and manifold.
- 4. Remove any connected PA circuitry and place plug in PA connection
- 5. Remove the Actuator / solenoid after ensuring that the set screw for the IV8 disc is securely closed.
- 6. If other types of service are required on the rest of the system, close handwheel valve on all cylinders.
- 7. Disconnect the installed solenoid valve circuit leads and connect spare solenoid valves or connect an End-of-Line device to serve as a dummy load.
- 8. Reconnect AC and battery power.
- 9. Initiate a first zone alarm condition by introducing smoke into one of the Zone 1 detectors.

This should cause the first zone alarm condition.

- ✓ The red Fire Alarm indicator will illuminate.
- ✓ The LCD display will indicate an alarm condition for zone 1.
- ✓ The control panel piezo will sound.
- ✓ The Alarm relay will energize.
- ✓ The devices connected to the Indicating Circuit(s) programmed to activate on Zone 1.

Alarm will turn on.

- 1. Repeat step 4 for each input zone.
- 2. When testing has been completed, remove AC and battery power, reconnect the solenoid valve circuits removed in step 2, reconnect AC and battery power and ensure that the control panel is in normal standby condition.

Confirm the correct operation of all system components, including the following:

- audible discharge alarms
- visual warning devices
- door-closers and ventilation dampers
- discharge time delay
- directional valves
- container release actuators

MANUAL RELEASE DEVICES

Operate all manual release devices and verify that each manual release device functions according to design specifications. Reset the system.

STOP & DELAY SWITCH

Operate and verify the function of the switch. Confirm that visual and audible supervisory signals are received at the control panel.

PNEUMATIC EQUIPMENT

Where fitted, check pneumatic equipment for integrity, to ensure proper operation.

After the test, reset all tested components in accordance with their respective datasheets.

File: Ci Manual 2024-11 Page 118 of 143



Full-scale discharge test

Discharge test is not mandatory. If it is performed, a recommendation of how to perform it is given here:

- 1. Complete the system commissioning inspection.
- 2. Disable stops that are not desired for the full-scale testing.
- 3. Install measuring equipment.
- 4. Inform all personnel affected by the full-scale test.
- 5. Activate the INERGEN system discharge procedure. If electrically controlled, use a manual discharge call point. If manually controlled, close all opening first and stop ventilation manually.
- 6. Verify that ventilation stops, doors and gussets close.
- 7. INERGEN releases.
- 8. Read the oxygen level every 15 seconds for the first 120 sec (note that the test equipment may have a delay for more than 15 seconds) and every minute thereafter.
- 9. After 10 minutes verify that the oxygen concentration is still below the extinguishing concentration or that the clean agent concentration is still a minimum of 85% of the design concentration (NFPA 2001 ch 5.6).

NOTICE: When releasing a fire extinguishing system, there will be very high sound levels, and very large ventilation in the enclosure. blowing dust in the room and into adjacent rooms.

This must be taken into consideration as unintended dust could set-off undesired fire alarms.

RESETTING

After the full-scale test, the system must be reset and components that have been used should be inspected according to the commissioning inspection.

TEST REPORT MUST INCLUDE

- 1. System name, location, participants, date when test was performed, signature.
- 2. List of equipment in the extinguishing system, a description of enclosure including hazards, temperature record prior to the discharge.
- 3. IMT calculations (design concentration).
- 4. Rules applied.
- 5. Location of all measuring points.
- 6. Measurements.
 - If manual oxygen measurement is performed, a sample rate of 1 per 15 Seconds is recommended.
- 7. All pages should contain date and file name.

Documents to be submitted

- 1. Components list.
- 2. Components certificates:
 - a. Cylinder certificates.
 - b. Cylinder filling certificates.
 - c. Pipe pressure test report.
- 3. IMT calculations.
- 4. Drawings.
- 5. Checklist.
- 6. Certificate of completion.

File: Ci Manual 2024-11 Page 119 of 143



CHAPTER 8: RESETTING AND RECHARGING

General

A fire can cause damage to many parts and components in a fire extinguishing system, and it is therefore very important to do a thorough inspection of the complete system before resetting it. Failure to do so may cause damage and accidental discharge.

It is also very important to clear the area from smoke.

Always refer to the control panel manual regarding instructions on how this should be reset.

Check all electrical and mechanical equipment.

Piping and nozzles

Check all pipes, support members and nozzles.

Inspect all nozzles for obstructions.

Selector valves

Bleed off the pressure in the actuation line by attaching the APTB tool to the test port (should the tool not be available a discharge hose may be used, simply screw it to the Test port and the pressure will bleed out.

With the actuation line bleed insert the SV22 reset tool in the slot in the SV and turn 90° (Arrow on tool is across the direction of flow. When removing the tool check that the slot is across the flow direction.

Electrical and manual actuators

Remove the actuator from the discharge valve.

Use Ci Reset tool to reset the actuator. Screw the tool apart until the line in the recess on the tool is visible, Screw the tool onto the actuator by rotating the part closest to the actuator. When it is fitted completely turn the outer part until. Just before it reaches bottom you will feel a small click and you should only turn $\frac{1}{2}$ turn after that.

For the Manual actuator the pin must be inserted with the tool tightened. Insert the pin through the hole and seal it using fine sealing thread and seal.

Before removing the tool Loosen it by turning the outer part $\frac{1}{2}$ turn back.

Pneumatic actuators

Remove the actuator from the discharge valve.

Push back the pin by hand

Bleed fitting

With the line they are attached to depressurized the pin sticking out must be pushed back to almost flush with the body.

Notice not all bleed fittings may have actuated as some are only installed to bleed pressure not intended to be in the system.

Notice on stand-alone system Bleed fittings are not utilized.

Discharge valves

To ensure 100% leak proof the piston in the discharge valve and the O-ring between the hand wheel valve and the discharge valve must be replaced.

305403 Ci IV8 piston inside discharge valve.

2141160 O-ring 14.1x1.6 between discharge valve and hand wheel valve

File: Ci Manual 2024-11 Page 120 of 143



Recharging cylinders

As the cylinders are equipped with hand wheel valve, it is very easy to have a filling station refilling the cylinders. Before refilling, the discharge valve is to be removed.

CAUTION:

Filling is only to be performed by personnel with the required certification to perform this operation.

Ensure that the cylinder is fixed well and con not move, and that it will not be able to move in case the filling adapter breaks (reaction forces must be taken into account).

Filling equipment requirements

The filling equipment must have a suitable pressure gauge to verify correct filling (min class 0.5 accuracy), the gauge on the discharge valve is not suitable for this purpose.

Pressure relief valves with a capacity that exceeds the capacity of the pump being used or the flow capacity of the outlet of the tank being filled from, so that the max pressure is limited to the max operating pressure of the system @ 60°C.

Pressure reducers are not to be used as means for controlling filling pressure or protecting the cylinder to be filled from over pressurization.

File: Ci Manual 2024-11 Page 121 of 143



INERGEN, IG541 as per NFPA 2001

GENERAL

This is a supplement to datasheet 200500 dealing with specifications of how filling stations should handle filling of cylinders with IG541.

Please refer to latest data sheet 200500-1 Instruction filling station for specifications.

BEFORE FILLING

The validity of the cylinder pressure test period must be checked in accordance with local regulations before they are refilled.

Some typical requirements are:

Europe: 10 years TPED EEC 1999/36, ADR instruction P200: 2005 Marine (EU): 5 years (recertification 10-20 years depending on authority).

Asia: 5 years

As there is no residual pressure valve in the valve, it must be checked that the cylinder has not been filled with any liquids.

ISO 10286 defines 15°C as cylinder reference temperature.

GAS MIXTURE

	Nominal	EN 15004/ ISO 14520	NFPA 2001	CCC-FM
Carbon dioxide:	8%	7.6 to 8.4%	8.0 to 9.0%	8.0 to 8.4%
Argon:	40%	37.2 to 42.8%	36 to 44%	37.2 to 42.8%
Nitrogen:	52 %	48.8 to 55.2%	48 to 56%	48.8 to 55.2%
Moisture (Dew point):	0	<-60 °C (< 6ppm m)	<-60 °C (< 6ppm m)	<-59 °C (< 12ppm v))
Davinaint shall alviava	ha halavi fi		sura m-Mass v- Valur	

Dewpoint shall always be below freezing point at the pressure, m=Mass, v= Volume

PRESSURE & CYLINDER VOLUME

Cylinder volumes tolerances must always be -0 to +5%. The actual volume in a cylinder should never be less than the designated volume.

Filling pressure are in accordance with the ADR regulation, nominal pressure @ 15° C. Filled cylinders' pressure is always to be verified after cylinders have been conditioned 24 hours at a stable temperature between 15° C and 30° C.

Tolerance for filling pressure is -0 to +10bar @15°C for both 200 and 300bar filling pressures

CCC-FM FILLINGS

Filling in compliance with CCCF and NFPA.

Filling pressure are 200bar (20MPa) @ 20°C, Filling tolerance is -0 to +10bar @ 20°C Cylinder volume is minimum 82 liter water volume.

Water contents are not to exceed 12 ppm giving a dew point below -59°C.

File: Ci Manual 2024-11 Page 122 of 143



FILLING

Only correct adapters should be used, damaged adapters etc. are to be destroyed to prevent accidental use.

The filling has to comply with the requirements of ISO14520-15.

Fire Eater recommendations for this is to:

Connect hoses, close hand wheel valves.

1. Verify system integrity

Evacuate to 100 Pa (1 mbar) vacuum (accuracy 50 - 1000 Pa)

2. Verify free flow

Open all hand wheel valves and evacuate cylinders

3. Remove moist

Keep at 100 Pa for 5 minutes.

4. Flush:

Pressurize with Nitrogen or INERGEN to 2 bar

Repeat step 3+4 so that the cylinder is flushed minimum 3 times

Evacuate to 100 Pa (vacuum) for 5 minutes

5. Fill:

Start with CO2, follow with N2 and Ar or use premixed INERGEN.

6. Close Hand Wheel Valve

Tighten to 7Nm

7. Verify cylinder interiority

Check for leakage (use soap-water):

a. Cylinder-Valve connection

b. Burst-disc

Carbon dioxide: 8.0 to 9.0% Argon: 36.0 to 44.0% Nitrogen: 48.0 to 56.0%

File: Ci Manual 2024-11 Page 123 of 143



PURITIES

In the filled cylinder the purity of the individual gas must be within the ISO14520-15 specifications

	Argon	Nitrogen	Carbon dioxide	
Class	min 4.7	min 4.0	min 2.5	
Purity	99.997 %	99.99 %	99.5 %	(by volume, min.)
Water content	4 × 10⁻6.	5 × 10 ⁻⁶	10×10^{-6} .	(by mass, max.)
Oxygen	3×10^{-6} .	3 × 10 ⁻⁶	10×10^{-6} .	(by mass, max.)

Only principal contaminants are shown. Other measurements may include hydrocarbons, CO, NO, NO $_2$. Most are 20 \times 10 $^{-6}$

For the filled INERGEN cylinder

Impurities: Less than: 0.04%

Water content: Dew point below -60°C (6 ppm weight)

(UL spec 20ppm are not applicable for cylinders transported in Europe as they may

be exposed to sub 0°C)

Oxygen: Less than: 3×10^{-6}

ANALYSIS

A batch or container analysis must be performed for:

- a) CO2 contents.
- b) Water contents.
- c) Pressure after stabilizing (15 to 30 °C)

Minimum annually gas samples must be submitted to third party analysis.

Analysis results must be filed and be available on request by Fire Eater.

The analysis must as a minimum be of the mixed INERGEN.

For the INERGEN analysis of each gas component (N2, Ar, CO₂) as well for oxygen and moisture and any other present substances.

The individual gases are analyzed for purity and water contents, data must be available for FPC audits.

Filling certificates

Filling records and certificates are to contain information of:

- Cylinder number
- Filling spec
- Date
- Pressure
- CO₂
- Moisture contents.

File: Ci Manual 2024-11 Page 124 of 143



CHAPTER 9: INSPECTION, SERVICE & MAINTENANCE

General

Periodical inspection and maintenance by qualified and trained personnel must be made minimum in accordance with the authority having jurisdiction.

Minimum service intervals

DBI 253: Annual service + inspection.

UL: Semi-annual (cylinder pressure must be verified)

NFPA: At least annual: inspection and test

At least semi-annually: pressure check

MED:

GA400:

LPCB: Annual service + inspection

For components with limited service-life, always refer to the engineering datasheet for information regarding replacement intervals or required service.

At the end of this chapter there is a service check list where these parts are indicated.

When working on the system always keep personal safety in mind.

Procedure before servicing a system:

- 1. Close Hand wheel valve on Master cylinder
- 2. Remove hose from valve and manifold.
- 3. Remove any connected PA circuitry and place plug in PA connection
- 4. Remove the Actuator / solenoid after ensuring that the set screw for the IV8 disc is securely closed.
- 5. If other types of service are required on the rest of the system, close all handwheel valves on all cylinders.

This will ensure safety and prevent spontaneous discharge.

Only personnel Certified by Fire Eater should carry out inspection and maintenance of a Fire Eater system.

File: Ci Manual 2024-11 Page 125 of 143



Cleaning

General

Cleaning is only necessary when the components of the fire extinguishing system are heavily soiled.

The fire extinguishing system is only to be operated by instructed personnel.

Service and recharge of the system is only to be performed by a Fire Eater A/S approved fitter.

The person responsible for the installation performs the service at 6- or 12-month intervals. Components with limited life are replaced during these inspections.

Pipe system

Pipes are not to be damaged, deformed or used for fixation of equipment. Pipe hangers are not to be removed or moved without proper approval.

Pipes may be painted.

Cleaning:

Pipes should be cleaned with water and detergent suitable for cleaning copper, aluminum or galvanized steel, depending on installation, NEVER use chlorine or acidic cleaning agents.

Nozzles

Nozzles are not to be removed, blocked or altered in any way without consulting the person responsible for the installation for directions.

Nozzles are not to be painted, as this may alter the nozzle area.

Cleaning

Nozzles should be cleaned with ordinary detergent and water suitable for cleaning of brass.

INERGEN® cylinders.

Steel cylinders with INERGEN® gas at 200 or 300 bar. The content information is located on a label on the side of the cylinder. Pressure information is also available here.

Cylinder color must be according to national and international standards if painted.

Cylinder valves must be sealed. If seal is broken contact the installation responsible.

Cleaning:

Water and ordinary detergent. High pressure cleaner may be used if heavily soiled (steam cleaner is not recommended due to elevated temperatures).

Discharge valve.

Brass valve with equipment according to specifications on datasheet.

Cleaning:

Water and ordinary detergent. Valves are not to be submerged into or sprayed with water.

File: Ci Manual 2024-11 Page 126 of 143



Inspection

General

A visual inspection must be performed regularly to ensure proper function of the system.

The visual inspection is intended to give reasonable assurance that the system will operate, and has not been tampered with, and has not been rendered inefficient due to changes in the protected areas.

Below is a list of items that should be inspected monthly, and what should be observed on each item.

If any parts of the described service are omitted for any reason, or faults, or deviations are recorded during the service it must be noted on the Certificate of Service & Maintenance, and the owner of the system must be informed of the potential consequences.

0 Information

As people and processes can be affected by a fire alarm it is important to inform everybody affected by the INERGEN system about the test and inspection to avoid unintended actions.

1. Room

Fire detection and fire extinguishing systems are dimensioned specially for the room and the hazard they are installed in.

A verification of the room integrity and sufficient pressure relief should always be verified using a quantifying measuring method (such as a blower dorr or similar), this test can be waivered if it can be verified that no changes has been made which would affect the INERGEN system.

If the rooms are modified, the person responsible for the installation must be contacted to evaluate if the alteration will affect the performance of the fire extinguishing system.

CONSTRUCTION CHANGES:

Ventilation: Has it or its controls been changed?
 Doors/windows: Change, installation, removal.

Lowered sealing: Installation, removal.
 Raised floors: Installation, removal.

Walls: Both light and heavy. Installation, removal.

• Machines: Any new machines or changes.

• Pipe & cabling: Pipe and cable ducts and wall cut outs.

Fuels: Is the extinguishing system designed for the fuels present?

DETECTION, ACTIVATION AND INDICATION SYSTEM

Detectors: Are all in place, undamaged, clean.
Release station: Easy access, clean, undamaged.

• Beacons, horns: Clean, undamaged

PIPE SYSTEM

• Nozzles: No obstructions, clean, check distance to objects prone to damage.

Pipe: Damages, corrosion, loose parts
 Pipe brackets: Damages, corrosion, loose parts

SIGNS

Alarm: Are all indicators labeled correctly?

• Escape routes: Clearly marked and free from obstructions.

NFPA 2001: Warning and instruction signs at entrances to and inside protected areas shall be provided, and located such that they will be readily visible to personnel in the area where the clean agent design concentration exceeds that approved for use in normally occupied spaces.

Warning and safety instruction signs shall be located at all entrances to the INERGEN cylinder storage room. All signs shall be in accordance with ANSI Z535.

File: Ci Manual 2024-11 Page 127 of 143



2. Cylinders

Cylinders may be stored in the protected area or in a separate cylinder storage room.

The cylinders are high pressure cylinders and local authorities may have special regulations of how these must be inspected and tested.

Cylinder pressure shall be tested at each service by reading the pressure on the gauge of the discharge valve and correcting it for temperature. (See Engineering datasheet for Pressure Correction Chart).

UL requires that the pressure of the cylinder must be verified in accordance with NFPA 2001 2 times per year, with a test pressure gauge with an accuracy of Cl 0.5 (grade 2A) 0.5% If an agent container shows a loss in pressure (adjusted for temperature) of more than 5%, it shall be refilled or replaced.

Cylinder recertification interval vary depending on authority having jurisdiction:

NFPA 2001 specifies cylinders continuously in service without discharging shall be given a complete external visual inspection every 5 years or more frequently if required. The visual inspection shall be in accordance with Section 3 of CGA C-6, except that the cylinders need not be emptied or stamped while under pressure. Inspections shall be made only by competent personnel, and the results recorded on both of the following:

- 1) A record tag permanently attached to each cylinder.
- 2) A suitable inspection report.

TPED specifies 10 years interval for recertification testing.

3. Control systems

The INERGEN system may be activated manually or automatic.

If a control panel is fitted it is important to test this according to its manual and ensure that it is in good operating condition.

4. Discharge valve

The quick actuating discharge valve that when activated will open fully and release the INERGEN in the storage cylinder.

To test Master valves:

- 1) Close Hand wheel valve on Master cylinder
- 2) Remove hose from valve and manifold.
- 3) Remove any connected PA circuitry and place plug in PA connection.
- 4) Remove the actuator after ensuring that the set screw for the IV8 disc is securely closed. Install the test tool in its place.
- 5) Operate test tool until IV8 discharges and record the force required to open.
- 6) Reset the valve by pushing piston back, if too high activation force was required replace the Ci IV8 Piston with a new.

5. Manoswitch

This is the combined pressure gauge and pressure switch which is fitted to all cylinders to monitor the pressure of the cylinder.

6. Actuators

The device activating the discharge valve.

File: Ci Manual 2024-11 Page 128 of 143



7. Hoses

Pressure hoses must be examined for cracks in the skin or corrosion in fittings.

Pressure hoses are special hoses with connections which opens check valves in manifold, supply sufficient flow to ensure correct backpressure operation of the valves.

Hoses should be replaced every 10 years to ensure proper function.

When the hoses are hydrostatic tested it is important that they are dried properly afterward.

Local authorities may have different requirements for testing the hoses.

NFPA 2001: All system hose shall be examined annually for damage. If visual examination shows any deficiency, the hose shall be immediately replaced.

Hose shall be hydrostatic tested every 5 years at 1.5x max container pressure at 130°F (54.4°C).

Use hose fixations on the pilot cylinder (the one with Manual activation) and on cylinders closer than 1 m from the pilot cylinder if the hose is longer than 50 cm

8. Manifolds

Collecting the gas from the discharge valve, ensuring build-up of pressure for backpressure operating of slave discharge valves.

9. Pipe-system

Local authority regulations must be observed (For EU PED must be observed).

NFPA 2001: The piping distribution system shall be in compliance with the design and installation documents.

Means of pipe size reduction and attitudes of tees shall be checked for conformance to the design. Securely fastened to prevent unacceptable vertical or lateral movement during discharge. Discharge nozzles shall be installed in such a manner that piping cannot become detached during discharge.

10. Nozzles

Nozzles shall be oriented in such a manner that optimum agent dispersal can be affected.

If nozzle deflectors are installed, they shall be positioned to obtain maximum benefit. Nozzles, piping, and mounting brackets shall be installed in such a manner that they will not potentially cause injury to personnel. Pointing away from areas where personnel could be found in the normal work area. Agent shall not directly impinge on any loose objects (shelves, cabinet tops, etc.).

11. Signalling devices

Acoustic and Optical beacons, sirens etc.

12. Pressure relief

Function and size must be tested.

14. Selector valves

Function must be tested.

SV with test port installed:

Attach the APTB tool and check the valve opening pressure

The APTB tool is connected to this port and slowly pressurized until the Selector valve opens fully. The pressure at which the selector valve opens is recorded.

The connection is loosened to bleed the pressure and with the tool still attached the SV22 is closed manually.

File: Ci Manual 2024-11 Page 129 of 143



15. Non-return valves

Position and direction must be verified.

Opening and closing function must be verified.

16. Bleed fitting

Correct position. All bleed fittings are to be open when the system has not been released, notice that the bleed fittings will close during pressurization and may require to be reset manually (pin is pushed back).

17. Additional system inspections

If other components are used these should be verified with their instructions.

18. Final

Always open the cylinders hand wheel valves and seal them in open position when completed work on the installation.

File: Ci Manual 2024-11 Page 130 of 143



Service & Maintenance

General

Systems shall be serviced at regular intervals satisfying the authorities having jurisdiction (see page 125 for a list of rules and requirements)

It is intended to give maximum assurance that the system will operate efficiently and as designed. If any damages or changes, that would reduce the efficiency of the system are found during the service these are to be repaired before the Service & maintenance protocol is signed.

Procedures listed in this section are the minimum necessary to maintain an efficient system.

Service intervals may be different than here stated if:

- Authorities having jurisdiction requires so
- System installations are subject to harsh environment.

The service must always be performed by a Fire Eater licensed service technician.

The checklist can be used both as a commissioning checklist as well as the annual service checklist.

For Marine systems MSC/Circ 1432 and MSC/Circ 1516 must be followed.

File: Ci Manual 2024-11 Page 131 of 143



Check list

CHEC		
	Description	×
0	Inform the involved personnel.	
	Inform the employees about the maintenance.	
	Especially receivers of signals from the system (security department, local fire-brigade.)	
1a	System configuration	_
	Review the as-installed plans to ensure they accurately represent the system configuration to	
	be protected.	
1b	Room inspection (see page 127)	
	Verify that no alteration is made to the protect room.	
	If alternations are made, verify that they do not conflict with the function of the system.	
	Check fuels present.	
	Test: Doors, windows and ventilation are closed/close during fire. Leakage:	
1b	Signs	
	Visual inspection:	
	Signs are correctly placed, mounted securely, not damaged, easy to follow and readable.	
	Local authorities' regulations must be observed.	
2	INERGEN cylinders	
_	Tools required: Cylinder pressure gauge (530508)	
	Temperature gauge (530512)	
	Isolate system activation by is disconnecting it.	
	Visual inspection: All cylinders are opened and sealed.	
	Visual inspection: No corrosion, mechanical damages or similar.	
	Test: INERGEN pressure checked and within limits*.	
	Cylinder test date is within limitation** (to be tested year:)	
	Test: All cylinders are fastened securely	
3	General	
3	Close Hand wheel valve on Master cylinder	
	Remove hose from valve and manifold.	
	Remove any connected PA circuitry and place plug in PA connection	
	Remove the Actuator / solenoid after ensuring that the set screw for the IV8 disc is securely	_
	closed.	
	If other types of service are required on the rest of the system, close handwheel valve on all	_
	cylinders.	
3a	Control panel	
	Tools required: Power Meter (530500)	
	Manoswitch emulator (540501)	
	According to manual.	
	•	
	Test: Sufficient power for actuation.	
	replace all actuators with power meter and activate control panel	
	Test: Correct signals from pressure switches.	
	Normal pressure - Low Pressure - Short circuitry - Open circuitry.	
	Battery capacity	
	Lamps, Visual and Acoustic alarms	
	Manual Alarm points	
	Detectors	
	Acoustic alarm devices	
	Optical alarm devices	
4	Ci IV8 Discharge valve	
	Tools required: Ci IV8 activation tester (530520)	
	Visual inspection: No cracks, mechanical damages/deformation or corrosion	
	Master valve (with an actuator) opening pressure:MPa (max 500N)	
	Reset IV8	
5	Manoswitch / Pressure gauge / Pressure switch	
	Visual inspection: No cracks, mechanical damages/deformation or corrosion	
	Visual inspection: Cables and plugs are undamaged.	

File: Ci Manual 2024-11 Page 132 of 143



6a	Actuator Ci IS8B	
	Tools required: IS8 Test interface (530505)	
	Ci Actuator Reset (305495) Remove all actuators from the discharge valves.	
	Test: Actuation.	
	Visual inspection: No cracks, mechanical damages or corrosion	
	Reset IM8 with reset tool	
6b	Actuator Ci PA8	
	Tools required: Ci Actuator Reset (305495)	
	Remove all actuators from the discharge valves.	
	Test: Actuation.	
	Visual inspection: No cracks, mechanical damages or corrosion	
	Reset PA8 with reset tool.	
6c	Actuator Ci IM8	
	Remove all actuators from the discharge valves.	
	Test: Actuation.	
	Visual inspection: No cracks, mechanical damages or corrosion	
	Reset IM8 with reset tool.	
6d	PA system (next manifold) See Pressure hoses (pt 7)	
	Test: All inlet/outlet adapters are tightened.	
	Verify every manifold is connected via the PA system.	
7	Pressure hoses	_
•	Hoses are less than 10 years old (to be replaced in:)	
	Visual inspection: No cracks, mechanical damages (check at bends), or corrosion	
	Test: All hoses are tightened.	
	Use hose fixations on the pilot cylinder (the one with Manual activation) and on cylinders	
	closer than 1 m from the pilot cylinder if the hose is longer than 50 cm	
8	Manifold and Orifices	
	Visual inspection: Intact no corrosion or mechanical damages.	
	Visual inspection: Correct Orifice size (as per IMT calculation).	
•	Test: Union is tightened	
9	Pipe system	
	Visual inspection: Intact no corrosion or mechanical damages. Test: Hydrostatic pressure test (only new installations)	
	Measure: Bracket distance (only new installations)	
10	Nozzles	
. •	Visual inspection: Undisturbed flow of INERGEN, no corrosion or mechanical damages.	
	Placed according to drawings and nozzle numbers (only new installations).	
11	Signal Devices	
	Visual and audible inspection: Bells, sirens and flash work.	
	Alarms as required by local authorities	
12	Pressure relief	
	Test for correct function.	
	Correct dimension. (As per IMT Calculation) (Area:)	
14	Selector valves	
	Tools required: APTB tool (305148)	
	SV22 Reset tool (305149) Visual inspection: Intact and correct actuation lines	
	No cracks, mechanical damages (check at bends), or corrosion	
	Verify every correct direction of each non-return valve in the PA system.	_
	SV22 Opening pressure(Opening pressure:bar (max 35bar))	
	Test: All inlet/outlet adapters are tightened	
	Reset valves with SV22 reset tool	

File: Ci Manual 2024-11 Page 133 of 143



14b	SV with remote pneumatic actuation (PDS) Verify that pressure reaches the intended Actuator Verify that the intended zone valve(s) opens within its required pressure (SV22=35bar) 1. For PDS-II systems: Place a Test gauge (0-100 bar kl 1.0 in place of the Pneumatic Actuator (IV7, NPP or Ci PA8) 2. Open the "Discharge" valve 3. Open the pilot cylinder until the Test gauge reads 10bar, then close the Pilot cylinder 4. Open the "Zone" valve 5. Increase pressure until the Selector valve opens by opening the pilot cylinder	
15	Non return valves Verify every correct direction of each non-return valve in the PA system	
16	Bleed fittings Visual inspection: All taps on bleed fittings are pushed down. When the system has been pressurized these taps will be out from the body requiring to be pushed down manually)	
17	Additional system inspection Visual inspection: Non-return/Check valve on pipe systems is installed correctly. Visual inspection: Non-return valves on pilot systems installed correctly. Selector valves as in accordance with SV22 manual	000
18	Final All discharge valves are reset and mounted on the cylinders. All Actuators are reset and installed. All Selector valves are closed All cylinders are opened, and sealed in open position. The system is set for use. (activation is reconnected) Informed the employees that the test is finished. Informed the security department that the test is finished. Record that the system has been serviced.	00000000

File: Ci Manual 2024-11 Page 134 of 143



Tools necessary to perform service

530509 Tool Cylinder Pressure gauge M25+W24

530810 Toolkit: Ci 2015 530820 Toolkit: FE SV 2015 530830 Toolkit: Ci SV 2015

For dismantling the valve for resetting after discharge

305490 IV8 sep disc Used for resetting after discharge 305491 IV8 Act plug Used for resetting after discharge

For resetting the Ci Actuators after activation (whether or not the cylinder has been discharged)

305495 Ci Actuator Reset Tool Used for service

Verifies that sufficient power can be routed to the electrical actuator.

530506 IS8B Electric Circ Tester Used for service

Verifies y the cylinder pressure monitoring circuitry

530502 Manoswitch tester Used for service

Measure the required force to operate the discharge valve and measure the force provided by the actuator (all

actuators, electrical, manual, and pneumatic)

530520 Ci Force Act test Used for service

Testing the discharge valve

530525 Ci Outlet Damper Used for service

To reset the SV selector valve

305149 SV22 Reset tool Used for service

Measure the required pressure to activate the Selector valve

305148 APTB (Test port) Used for service

To test the Non Return Valve for flow

530530 Tool: NRV 1/4 Test Flow Used for service

To test the Non Return Valve for leaktightness

530531 Tool: NRV 1/4 Test No Flow Used for service

To verify the switchpoint for manifold and pipe pressure switches.

530540 Tool: Pressure switch setter Used for service

File: Ci Manual 2024-11 Page 135 of 143




Certification of Service & Maintenance

Cusi	tomer												
Company : Address : City & Zip						Tel.	(Primary): (Secondary): (Other):						
Con	tact.												
Invo	ice ac	ldress	·:					_ Att:					
Syst	em in	forma	ation										
	eral												
Typ	ation e :					Control par	nel				Sect:		
	m poi	nt:				Battery bac			Qty :		Year:		
	ector	Qty:				Cylinder:	<u> </u>				Qty:		
	/es : ation :	:				Press relief	•						
Chec	ck list	(sigr	naler)										
				Signa	l trans	smission				1	ted <i>No</i>	0 Yes	
	Faul	t:											
	Fire	: 1. [<u></u>										
	Exti	nguisł	ning.:										
	Oth	er:											
×	1.	2.	Ext	1	<i>tart</i> Man.	Туре	Section.						
						Engine stop:							
						Vent. stop:							
						Doors:							
						Dampers:							
						Other:							
Syste The s	ice & <i>l</i> em is i systen	n nor	mal oper ound to b	ation A e in com	Auto. 🗆 pliance	cordance with c Man. e with current re s for corrections	I: <i>Yes</i> □ ules and re		: Yes 🛭 nents: :	<u> </u>	Ye:	s 🗖	_
Serio	ous bre	eache	s are fou	nd and t	he syst	em is not appro	ved			_			
Date	+ sigi	nature								_			
Inspe	ector						Owners re	prese	ntative				

File: Ci Manual 2024-11 Page 136 of 143




CHAPTER 10: TYPICAL INSTALLATIONS



File: Ci Manual 2024-11 Page 137 of 143





Pos.	Name			Quantity	Item	
01	Cylinders	H _{brkt}	H _{Mfld}	• ,		
	Cylinder 80-300 M25	1400		1	200624	
	Cylinder 50-300 M25	1200	1850		200615	
	Cylinder 30-300 M25	700	1400		200609	
	Cylinder 80-200 W24	1400	2100		200616	
	Cylinder 50-200 W24	1200	1850		200610	
	Cylinder 30-200 W24	700	1400		200606	
02	Cylinder rail	2	400301			
	Cylinder bracket 80l	2	400109			
11	Ci IV8-300 Manoswitch			1	305410	
	Ci IV8-300 Basic				305411	Ci
	IV8-200 Manoswitch				305420	
	Ci IV8-200 Manoswitch				305420	
	Ci IV8-200 Basic				305421	
12	Manoswitch 470-5K6 cable 2m s	tart kit		1	540360	
21	Ci IM8 Manual actuator				305442	
	Ci IS8B w manual				305451	
	Ci IS8B Solenoid only				305450	
	Ci PA8 Pneumatic actuator				305448	
61	Nozzle w deflector				303129	
71		drawing)				
72	Signs and labels					
73	Accessories					
	Junction box				540350	
91	Remote activation					
92	Control panels					
	See system manual for complet components	e list and	options	for the in	ıdividual	
	•					


File: Ci Manual 2024-11 Page 138 of 143



Single manifold system

All discharge valves connected to a common manifold will be "back pressure activated" meaning they will be activated by the pressure from the manifold when the Master cylinder connected to that manifold is activated.

Pos. Name							
Cylinder 80-300 M25	Pos.	Name			Quantity	Item	
Cylinder 50-300 M25	01		H_{brkt}	H _{Mfld}			
Cytinder 30-300 M25					1		
Cytinder 80-200 W24 1400 2100 200616 Cytinder 50-200 W24 1200 1850 200610 Cytinder 30-200 W24 700 1400 200606 02 Cytinder rail 1 400301 200606 Cytinder bracket 80l 1 400109 1 11 Ci IV8-300 Basic 305410 305420 305420 Ci IV8-200 Manoswitch 305420 305420 305420 Ci IV8-200 Basic 305420 305421 305420 21 Ci IW8 Manual actuator 305421 305421 305420 21 Ci IS8B wanaual 305421 305420 305421 21 Ci IS8B Valla Manual actuator 305420 305421 305421 21 Ci IS8B Valla Manual actuator 305442 305421 305420 21 Ci IS8B Valla Manual actuator 305420 305420 305420 21 Ci IS8B Valla Manual actuator 305421 305421 305421 21 Ci IS8B Valla Manual actuator 305421 305421 305420 21 Ci PA8 Pneumatic actuator 305420			1200	1850		200615	
Cylinder 50-200 W24			700	1400		200609	
Cylinder rail 1 400301 Cylinder rail 1 400301 Cylinder bracket 80l 1 400109 11 Ci IV8-300 Manoswitch 1 305410 Ci IV8-200 Manoswitch 305420 Ci IV8-200 Manoswitch 305420 Ci IV8-200 Manoswitch 305420 Ci IV8-200 Basic 305421 12 Manoswitch 470-5K6 cable 2m start kit 1 540360 21 Ci IM8 Manual actuator 305421 Ci IS8B vananual 305451 Ci IS8B Solenoid only 305451 Ci IS8B Solenoid only 305450 305450 Ci PA8 Pneumatic actuator 305448 31 Hose Dn10-400, 1.5m std INERGEN 1 303102 Hose Dn10-400, 1.5m std INERGEN 303104 Hose Dn10-400, 2.5m std INERGEN 303106 Hose Dn10-400, 2.5m std INERGEN 303108 303109 Hose Dn10-400, 3.0m std INERGEN 303111 Hose Dn10-400, 3.5m std INERGEN 303113 303101 40 305702 Ci MT2 Manifold 305703 303113 41 Ci MT2 Manifold <t< th=""><th></th><th></th><th></th><th></th><th></th><th></th><th></th></t<>							
Cylinder rail				1850		200610	
Cytinder bracket 80l 1 400109 11 Ci IV8-300 Manoswitch 305410 Ci IV8-200 Manoswitch 305420 Ci IS8B w manual 305441 Ci IS8B w manual 305451 Ci IS8B Solenoid only 305450 Ci PA8 Pneumatic actuator 305448 31 Hose Dn10-400, 0.5m std INERGEN 303104 Hose Dn10-400, 1.5m std INERGEN 303106 Hose Dn10-400, 1.5m std INERGEN 303106 Hose Dn10-400, 2.5m std INERGEN 303108 Hose Dn10-400, 2.5m std INERGEN 303109 Hose Dn10-400, 2.5m std INERGEN 303111 Hose Dn10-400, 3.0m std INERGEN 303111 Hose Dn10-400, 4.0m std INERGEN 303111 41 Ci MT1 Manifold 305701 Ci MT2 Manifold 305702 Ci MT3 Manifold 305703 Ci MT4 Manifold 305706 Ci MT5 Manifold 305706 Ci MT6 Manifold 305706 Ci MT7 Manifold 305707 Ci MT8 Manifold 305708 Ci MT9 Manifold 305709 Ci MT9 Manifold 305709 Ci MT9 Manifold 305709 Ci MT9 Manifold 305709 Ci MT10 Manifold 305709 Ci MT5 Sorrifice kit 1" 305730 Ci MT6 Manifold 305709 Ci MT6 Manifold 305709 Ci MT7 IND Manifold 305709 Ci MT6 Manifold 305709 Ci MT7 Manifold 305709 Ci MT7 IND Manifold 305709 Ci MT6 Manifold 305709 Ci MT7 IND Manifold 305709 Ci MT6 Manifold 305709 Ci MT7 Manifold 305709 Ci MT0 Monifold 305709 Signs and labels 73 Accessories Junction box 540350 PRemote activation 92 Control panels See system manual for complete list and options for the individual			700	1400		200606	
11 Gi IV8-300 Manoswitch 1 305410 Ci IV8-200 Basic 305420 Ci IV8-200 Manoswitch 305420 Ci IV8-200 Manoswitch 305420 Ci IV8-200 Basic 305421 12 Manoswitch 470-5K6 cable 2m start kit 1 540360 21 Ci IM8 Manual actuator 305421 Ci IS8B w manual 305451 Ci IS8B Solenoid only 305450 Ci PA8 Pneumatic actuator 30548 305450 31 Hose Dn10-400, 0.5m std INERGEN 1 303102 Hose Dn10-400, 1.0m std INERGEN 303104 Hose Dn10-400, 1.0m std INERGEN 303106 Hose Dn10-400, 2.0m std INERGEN 303108 303108 303109 Hose Dn10-400, 3.0m std INERGEN 303109 303109 303109 Hose Dn10-400, 4.0m std INERGEN 303111 303109 305701 305701 Ci MT1 Manifold 305702 305701 305702 305702 Ci MT3 Manifold 305703 305703 305703 305706 Ci MT6 Manifold 305706 305708 305708	02						
Ci IV8-300 Basic 305411 Ci IV8-200 Manoswitch 305420 Ci IV8-200 Manoswitch 305420 Ci IV8-200 Basic 305421 2 Manoswitch 470-5K6 cable 2m start kit 1 540360 21 Ci IM8 Manual actuator 305442 Ci IS8B w manual 305451 Ci IS8B v manual 305451 Ci IS8B v manual 305450 Ci PA8 Pneumatic actuator 305448 305450 Ci PA8 Pneumatic actuator 305448 31 Hose Dn10-400, 0.5m std INERGEN 1 303102 Hose Dn10-400, 1.5m std INERGEN 303104 Hose Dn10-400, 1.5m std INERGEN 303106 Hose Dn10-400, 2.5m std INERGEN 303108 Hose Dn10-400, 2.5m std INERGEN 303109 Hose Dn10-400, 2.5m std INERGEN 303109 Hose Dn10-400, 3.0m std INERGEN 303111 Hose Dn10-400, 4.0m std INERGEN 303111 Hose Dn10-400, 4.0m std INERGEN 303113 41 Ci MT1 Manifold 305701 Ci MT2 Manifold 305702 Ci MT3 Manifold 305702 Ci MT3 Manifold 305704 Ci MT5 Manifold 305705 Ci MT6 Manifold 305706 Ci MT7 Manifold 305706 Ci MT7 Manifold 305707 Ci MT8 Manifold 305708 Ci MT9 Manifold 305708 Ci MT9 Manifold 305708 Ci MT10 Manifold 305708 Ci MT10 Manifold 305709 Ci MT10 Manifold 305700 Ci MT10 M			1	400109			
V8-200 Manoswitch	11				1		
Ci IV8-200 Manoswitch							Ci
Ci IV8-200 Basic Manoswitch 470-5K6 cable 2m start kit Manoswitch 470-5K6 cable 2m start kit Ci IM8 Manual actuator Ci IS8B w manual 305451 Ci IS8B Solenoid only 305450 Ci IP8A Pneumatic actuator Hose Dn10-400, 0.5m std INERGEN 1 303102 Hose Dn10-400, 1.5m std INERGEN 303104 Hose Dn10-400, 1.5m std INERGEN 303106 Hose Dn10-400, 2.5m std INERGEN 303108 Hose Dn10-400, 2.5m std INERGEN 303109 Hose Dn10-400, 2.5m std INERGEN 303111 Hose Dn10-400, 3.0m std INERGEN 303113 41 Ci MT1 Manifold Ci MT2 Manifold Ci MT2 Manifold Ci MT3 Manifold Ci MT5 Manifold Ci MT6 Manifold Ci MT6 Manifold Ci MT7 Manifold Ci MT7 Manifold Ci MT7 Manifold Ci MT6 Manifold Ci MT7 Manifold Ci MT8 Manifold Ci MT9 Manifold Ci MT9 Manifold Ci MT7 Manifold Ci MT8 Manifold Ci MT8 Manifold Ci MT8 Manifold Ci MT9 Manifold Ci MT8 Manifold Ci MT9 Manifold Ci MT8 Manifold							
12 Manoswitch 470-5K6 cable 2m start kit 1 540360 21 Ci IM8 Manual actuator 305442 Ci IS8B vanual 305451 Ci IS8B Solenoid only 305458 Ci IS8B Pneumatic actuator 305448 31 Hose Dn10-400, 0,5m std INERGEN 1 Hose Dn10-400, 0,5m std INERGEN 303104 Hose Dn10-400, 1.0m std INERGEN 303106 Hose Dn10-400, 1.5m std INERGEN 303108 Hose Dn10-400, 2.5m std INERGEN 303109 Hose Dn10-400, 2.5m std INERGEN 303111 Hose Dn10-400, 3.0m std INERGEN 303111 Hose Dn10-400, 4.0m std INERGEN 303111 Gi MT2 Manifold 305701 Ci MT3 Manifold 305702 Ci MT4 Manifold 305703 Ci MT5 Manifold 305706 Ci MT6 Manifold 305706 Ci MT7 Manifold 305708 Ci MT7 Manifold 305709							
21 Gi IM8 Manual actuator 305442 Ci IS8B w manual 305451 Ci IS8B Solenoid only 305450 Ci PA8 Pneumatic actuator 305448 31 Hose Dn10-400, 0.5m std INERGEN 1 303102 Hose Dn10-400, 1.0m std INERGEN 303104 Hose Dn10-400, 2.0m std INERGEN 303108 Hose Dn10-400, 2.0m std INERGEN 303109 Hose Dn10-400, 3.0m std INERGEN 303111 Hose Dn10-400, 4.0m std INERGEN 303113 41 Ci MT1 Manifold 1 305701 Ci MT2 Manifold 305702 Ci MT3 Manifold 305703 Ci MT4 Manifold 305704 Ci MT5 Manifold 305705 Ci MT6 Manifold 305706 Ci MT7 Manifold 305707 Ci MT8 Manifold 305708 Ci MT9 Manifold 305708 Ci MT9 Manifold 305708 Ci MT7 Manifold 305708 Ci MT7 Manifold 305708 Ci MT7 Manifold 305708 Ci MT7 Orifice kit 1" 305730 Ci MT TI OManifold 305730 Ci MT To Orifice kit npt 1"<							
Ci IS8B w manual Ci IS8B Solenoid only Ci PA8 Pneumatic actuator 305448 31 Hose Dn10-400, 0.5m std INERGEN 1 303102 Hose Dn10-400, 1.5m std INERGEN 303104 Hose Dn10-400, 1.5m std INERGEN 303106 Hose Dn10-400, 2.0m std INERGEN 303108 Hose Dn10-400, 2.5m std INERGEN 303109 Hose Dn10-400, 2.5m std INERGEN 303111 Hose Dn10-400, 3.0m std INERGEN 303111 Hose Dn10-400, 4.0m std INERGEN 303111 41 Ci MT1 Manifold Ci MT2 Manifold Ci MT2 Manifold Ci MT3 Manifold Ci MT4 Manifold 305702 Ci MT5 Manifold 305703 Ci MT6 Manifold 305705 Ci MT7 Manifold 305706 Ci MT7 Manifold 305707 Ci MT7 Manifold 305708 Ci MT7 Manifold 305708 Ci MT7 Manifold 305708 Ci MT9 Manifold 305708 Ci MT9 Manifold 305709 Ci MT0 Fifice kit npt 1" 305730 Ci MT0 orffice kit npt 1" 305731 Pipe system Fittings for pipe system Nozzles (IN-xx) (not shown on drawing) Pressure relief) (not shown on drawing) Pressure relief) (not shown on drawing) Remote activation Control panels See system manual for complete list and options for the individual			2m start kit		1		
Ci IS8B Solenoid only Ci PA8 Pneumatic actuator 305448 31 Hose Dn10-400, 0.5m std INERGEN 1 303102 Hose Dn10-400, 1.5m std INERGEN 303106 Hose Dn10-400, 1.5m std INERGEN 303106 Hose Dn10-400, 2.5m std INERGEN 303108 Hose Dn10-400, 2.5m std INERGEN 303109 Hose Dn10-400, 2.5m std INERGEN 303111 Hose Dn10-400, 3.0m std INERGEN 303111 Hose Dn10-400, 3.0m std INERGEN 303111 41 Ci MT1 Manifold Ci MT2 Manifold Ci MT3 Manifold Ci MT3 Manifold Ci MT4 Manifold 305702 Ci MT5 Manifold 305703 Ci MT6 Manifold 305706 Ci MT7 Manifold 305706 Ci MT7 Manifold 305706 Ci MT7 Manifold 305707 Ci MT8 Manifold 305708 Ci MT9 Manifold 305709 Ci MT6 Manifold 305709 Ci MT7 in Manifold 305709 Ci MT6 Manifold 305709 Ci MT7 Monifold 305709 Ci MT6 Monifold 305709 Ci MT orifice kit npt 1" 305730 Ci MT orifice kit npt 1" 51 Pipe system Fittings for pipe system Fittings for pipe system 52 Fittings for pipe system 53 Signs and labels 54 Accessories Junction box 540350 96 Remote activation 97 Control panels 56 See system manual for complete list and options for the individual	21						
Ci PA8 Pneumatic actuator 1 Hose Dn10-400, 0.5m std INERGEN 1 303102 Hose Dn10-400, 1.5m std INERGEN 303104 Hose Dn10-400, 1.5m std INERGEN 303108 Hose Dn10-400, 2.5m std INERGEN 303108 Hose Dn10-400, 2.5m std INERGEN 303109 Hose Dn10-400, 3.0m std INERGEN 303111 Hose Dn10-400, 3.0m std INERGEN 303111 Hose Dn10-400, 4.0m std INERGEN 303113 41 Ci MT1 Manifold Ci MT2 Manifold Ci MT3 Manifold Ci MT4 Manifold 305701 Ci MT5 Manifold 305704 Ci MT6 Manifold 305704 Ci MT6 Manifold 305705 Ci MT7 Manifold 305706 Ci MT7 Manifold 305707 Ci MT7 Manifold 305707 Ci MT7 Manifold 305708 Ci MT7 Manifold 305708 Ci MT9 Manifold 305709 Ci MT9 Manifold 305709 Ci MT9 Manifold 305709 Ci MT SO Orifice kit 1" 305730 Ci MT orifice kit 1" 305730 Ci MT orifice kit npt 1" 305730 Signs and labels 30500 91 Remote activation 92 Control panels See system manual for complete list and options for the individual							
Hose Dn10-400, 0.5m std INERGEN 1 303102 Hose Dn10-400, 1.5m std INERGEN 303104 Hose Dn10-400, 1.5m std INERGEN 303106 Hose Dn10-400, 2.0m std INERGEN 303108 Hose Dn10-400, 2.5m std INERGEN 303109 Hose Dn10-400, 3.0m std INERGEN 303111 Hose Dn10-400, 4.0m std INERGEN 303111 Hose Dn10-400, 4.0m std INERGEN 303111 Hose Dn10-400, 4.0m std INERGEN 303111 Gi MT1 Manifold 305701 Ci MT2 Manifold 305702 Ci MT3 Manifold 305703 Ci MT4 Manifold 305704 Ci MT5 Manifold 305705 Ci MT6 Manifold 305705 Ci MT7 Manifold 305706 Ci MT7 Manifold 305707 Ci MT7 Manifold 305708 Ci MT9 Manifold 305708 Ci MT9 Manifold 305709 Ci MT10 Manifold 305709 Ci MT10 Orifice kit 1" 305730 Ci MT10 Orifice kit npt 1" 305731 Pipe system 52 Fittings for pipe system 540350 Pressure relief (not shown on drawing) Pressure relief (not shown on drawing) Signs and labels 305700 Remote activation 540350 Remote activation 540350 See system manual for complete list and options for the individual							
Hose Dn10-400, 1.0m std INERGEN 303104 Hose Dn10-400, 1.5m std INERGEN 303106 Hose Dn10-400, 2.0m std INERGEN 303108 Hose Dn10-400, 2.5m std INERGEN 303109 Hose Dn10-400, 3.0m std INERGEN 303111 Hose Dn10-400, 4.0m std INERGEN 303111 Hose Dn10-400, 4.0m std INERGEN 303111 Ci MT1 Manifold 1 305701 Ci MT2 Manifold 305702 Ci MT3 Manifold 305703 Ci MT4 Manifold 305703 Ci MT5 Manifold 305704 Ci MT6 Manifold 305706 Ci MT7 Manifold 305706 Ci MT7 Manifold 305706 Ci MT7 Manifold 305707 Ci MT8 Manifold 305708 Ci MT9 Manifold 305708 Ci MT9 Manifold 305709 Ci MT10 Manifold 305709 Ci MT rifice kit 1" 305730 Ci MT orifice kit 1" 305731 Pipe system 52 Fittings for pipe system 52 Fittings for pipe system 53 Nozzles (IN-xx) (not shown on drawing) Pressure relief) (not shown on drawing) Signs and labels 540350 Remote activation 540350 Remote activation 540350 See system manual for complete list and options for the individual	٠.						
Hose Dn10-400, 1.5m std INERGEN 303106 Hose Dn10-400, 2.0m std INERGEN 303108 Hose Dn10-400, 2.5m std INERGEN 3031109 Hose Dn10-400, 3.0m std INERGEN 303111 Hose Dn10-400, 4.0m std INERGEN 303113 41	31				1		
Hose Dn10-400, 2.0m std INERGEN 303108 Hose Dn10-400, 2.5m std INERGEN 303109 Hose Dn10-400, 3.0m std INERGEN 303111 Hose Dn10-400, 4.0m std INERGEN 303113 Ci MT1 Manifold 1 305701 Ci MT2 Manifold 305702 Ci MT3 Manifold 305703 Ci MT4 Manifold 305704 Ci MT5 Manifold 305705 Ci MT6 Manifold 305706 Ci MT7 Manifold 305706 Ci MT7 Manifold 305706 Ci MT7 Manifold 305707 Ci MT8 Manifold 305707 Ci MT9 Manifold 305708 Ci MT9 Manifold 305708 Ci MT9 Manifold 305709 Ci MT1 SO Orifice kit 1" 305730 Ci MT Torifice kit 1" 305730 Ci MT orifice kit npt 1" 305731 Pipe system 52 Fittings for pipe system 54 Nozzles (IN-xx) (not shown on drawing) Pressure relief) (not shown on drawing) Pressure relief) (not shown on drawing) Pressure relief (not shown on drawing)							
Hose Dn10-400, 2.5m std INERGEN 303109 Hose Dn10-400, 3.0m std INERGEN 303111 Hose Dn10-400, 4.0m std INERGEN 303111 Hose Dn10-400, 4.0m std INERGEN 303113 Ci MT1 Manifold 1 305701 Ci MT2 Manifold 305702 Ci MT3 Manifold 305703 Ci MT4 Manifold 305704 Ci MT5 Manifold 305706 Ci MT6 Manifold 305706 Ci MT7 Manifold 305706 Ci MT7 Manifold 305706 Ci MT8 Manifold 305708 Ci MT9 Manifold 305708 Ci MT9 Manifold 305709 Ci MT10 Manifold 305709 Ci MT ISO Orifice kit 1" 305730 Ci MT orifice kit npt 1" 305730 Tipe system 52 Fittings for pipe system 52 Fittings for pipe system 53 Nozzles (IN-xx) (not shown on drawing) 74 Fressure relief (not shown on drawing) 75 Signs and labels 76 Accessories Junction box 540350 Remote activation 50 Control panels 50 See system manual for complete list and options for the individual							
Hose Dn10-400, 3.0m std INERGEN 303111 Hose Dn10-400, 4.0m std INERGEN 303113 41							
Hose Dn10-400, 4.0m std INERGEN 303113							
Ci MT1 Manifold							
Ci MT2 Manifold 305702 Ci MT3 Manifold 305703 Ci MT4 Manifold 305704 Ci MT5 Manifold 305705 Ci MT6 Manifold 305706 Ci MT6 Manifold 305706 Ci MT7 Manifold 305707 Ci MT8 Manifold 305707 Ci MT8 Manifold 305708 Ci MT9 Manifold 305709 Ci MT10 Manifold 305709 Ci MT ISO Orifice kit 1" 305730 Ci MT orifice kit 1" 305730 Ci MT orifice kit npt 1" 305731 51 Pipe system Fittings for pipe system 52 Fittings for pipe system 61 Nozzles (IN-xx) (not shown on drawing) 71 Pressure relief) (not shown on drawing) 72 Signs and labels 73 Accessories Junction box 540350 91 Remote activation 92 Control panels 5ee system manual for complete list and options for the individual			d INERGEN				
Ci MT3 Manifold 305703 Ci MT4 Manifold 305704 Ci MT5 Manifold 305705 Ci MT6 Manifold 305705 Ci MT6 Manifold 305706 Ci MT7 Manifold 305707 Ci MT8 Manifold 305708 Ci MT9 Manifold 305709 Ci MT9 Manifold 305709 Ci MT10 Manifold 305710 42 Ci MT ISO Orifice kit 1" 305730 Ci MT orifice kit 1" 305730 Ci MT orifice kit npt 1" 305731 51 Pipe system Fittings for pipe system 61 Nozzles (IN-xx) (not shown on drawing) 72 Pressure relief) (not shown on drawing) 73 Accessories Junction box 540350 94 Remote activation 95 Control panels 96 See system manual for complete list and options for the individual	41				1		
Ci MT4 Manifold 305704 Ci MT5 Manifold 305705 Ci MT6 Manifold 305706 Ci MT7 Manifold 305706 Ci MT7 Manifold 305707 Ci MT8 Manifold 305708 Ci MT9 Manifold 305709 Ci MT10 Manifold 305709 Ci MT ISO Orifice kit 1" 305730 Ci MT orifice kit 1" 305730 Fittings for pipe system 52 Fittings for pipe system 8 Nozzles (IN-xx) (not shown on drawing) 72 Figns and labels 73 Accessories Junction box 540350 91 Remote activation 92 Control panels 5ee system manual for complete list and options for the individual							
Ci MT5 Manifold 305705 Ci MT6 Manifold 305706 Ci MT7 Manifold 305707 Ci MT8 Manifold 305708 Ci MT9 Manifold 305709 Ci MT9 Manifold 305709 Ci MT10 Manifold 305709 Ci MT ISO Orifice kit 1" 305730 Ci MT orifice kit npt 1" 305731 Pipe system Fittings for pipe system 10 Nozzles (IN-xx) (not shown on drawing) Pressure relief) (not shown on drawing) Signs and labels Accessories Junction box 540350 Remote activation Control panels See system manual for complete list and options for the individual							
Ci MT6 Manifold 305706 Ci MT7 Manifold 305707 Ci MT8 Manifold 305708 Ci MT9 Manifold 305708 Ci MT9 Manifold 305709 Ci MT10 Manifold 305710 42 Ci MT ISO Orifice kit 1" 305730 Ci MT orifice kit npt 1" 305731 51 Pipe system Fittings for pipe system 61 Nozzles (IN-xx) (not shown on drawing) 71 Pressure relief) (not shown on drawing) 72 Signs and labels 3 73 Accessories Junction box 540350 91 Remote activation 92 Control panels See system manual for complete list and options for the individual							
Ci MT7 Manifold 305707 Ci MT8 Manifold 305708 Ci MT9 Manifold 305709 Ci MT9 Manifold 305709 Ci MT10 Manifold 305710 Ci MT ISO Orifice kit 1" 305730 Ci MT orifice kit npt 1" 305731 Pipe system 52 Fittings for pipe system Nozzles (IN-xx) (not shown on drawing) Pressure relief) (not shown on drawing) Signs and labels Accessories Junction box 540350 Remote activation Control panels 5ee system manual for complete list and options for the individual							
Ci MT8 Manifold 305708 Ci MT9 Manifold 305709 Ci MT10 Manifold 305710 42 Ci MT ISO Orifice kit 1" 305730 Ci MT orifice kit npt 1" 305731 51 Pipe system Fittings for pipe system 61 Nozzles (IN-xx) (not shown on drawing) 71 Pressure relief) (not shown on drawing) 72 Signs and labels 73 Accessories Junction box 540350 91 Remote activation 92 Control panels See system manual for complete list and options for the individual							
Ci MT9 Manifold Ci MT10 Manifold Ci MT10 Manifold 305710 42 Ci MT ISO Orifice kit 1" Ci MT orifice kit npt 1" 305730 Ci MT orifice kit npt 1" 305731 51 Pipe system Fittings for pipe system 61 Nozzles (IN-xx) (not shown on drawing) 71 Pressure relief) (not shown on drawing) 72 Signs and labels 73 Accessories Junction box 94 Remote activation 95 Control panels 96 See system manual for complete list and options for the individual							
Ci MT10 Manifold 305710 42 Ci MT ISO Orifice kit 1" 305730 Ci MT orifice kit npt 1" 305731 51 Pipe system 52 Fittings for pipe system 61 Nozzles (IN-xx) (not shown on drawing) 71 Pressure relief) (not shown on drawing) 72 Signs and labels 73 Accessories Junction box 540350 91 Remote activation 92 Control panels 5ee system manual for complete list and options for the individual							
42 Ci MT ISO Orifice kit 1" 305730 Ci MT orifice kit npt 1" 305731 51 Pipe system 52 Fittings for pipe system 61 Nozzles (IN-xx) (not shown on drawing) 71 Pressure relief) (not shown on drawing) 72 Signs and labels 73 Accessories Junction box 540350 91 Remote activation 92 Control panels See system manual for complete list and options for the individual							
Ci MT orifice kit npt 1" 305731 Pipe system Fittings for pipe system Nozzles (IN-xx) (not shown on drawing) Pressure relief) (not shown on drawing) Signs and labels Accessories Junction box Semote activation Control panels See system manual for complete list and options for the individual	42						
51 Pipe system 52 Fittings for pipe system 61 Nozzles (IN-xx) (not shown on drawing) 71 Pressure relief) (not shown on drawing) 72 Signs and labels 73 Accessories Junction box 91 Remote activation 92 Control panels See system manual for complete list and options for the individual	72						
Fittings for pipe system Nozzles (IN-xx) (not shown on drawing) Pressure relief) (not shown on drawing) Signs and labels Accessories Junction box Remote activation Control panels See system manual for complete list and options for the individual	51					303731	
61 Nozzles (IN-xx) (not shown on drawing) 71 Pressure relief) (not shown on drawing) 72 Signs and labels 73 Accessories Junction box 540350 91 Remote activation 92 Control panels See system manual for complete list and options for the individual							
71 Pressure relief) (not shown on drawing) 72 Signs and labels 73 Accessories 740350 91 Remote activation 92 Control panels 86 See system manual for complete list and options for the individual			wn on drawir	ng)			
72 Signs and labels 73 Accessories Junction box 91 Remote activation 92 Control panels See system manual for complete list and options for the individual							
73 Accessories Junction box 540350 91 Remote activation 92 Control panels See system manual for complete list and options for the individual	72			,			
91 Remote activation 92 Control panels See system manual for complete list and options for the individual	73						
92 Control panels See system manual for complete list and options for the individual		Junction box				540350	
See system manual for complete list and options for the individual	91	Remote activation					
See system manual for complete list and options for the individual	92	Control panels					
			plete list an	d options	for the ir	ndividual	
		components	-	•			



File: Ci Manual 2024-11 Page 139 of 143




Multiple manifold system I
If multiple manifolds are used in a system the pressure from a activated cylinder on one manifold must be used to activate a cylinder on the next manifold. The cylinders do not have to be the first and last on the manifold.

See datasheet on previous page for items not listed here.

Pos. Name 32 Ci MT next kit (350mm)

Quantity Item 1 305621



File: Ci Manual 2024-11 Page 140 of 143




Multiple manifold system II
Even if the manifolds are connected to the same pipe system pressure must be taken from a valve to ensure sufficient pressure for activation.

See datasheet on previous page for items not listed here.

Pos. Name 32 Ci MT next kit (350mm)

Quantity Item 1 305621



File: Ci Manual 2024-11 Page 141 of 143



System with back-up system

If a back-up fire extinguishing system is sharing the same pipe system a non-return valve must be used to separate the 2 systems in order to prevent the back-up systemn to be activated by the pressure generated in the pipe system when the first extinguishing system is activated.


See datasheet on previous page for items not listed here.

Pos. Name

Non Return valve 1"

Quantity Item 2 305304

Activators must be doubled, as each system must have its own actuators.



File: Ci Manual 2024-11 Page 142 of 143



Directional system using DV7a Up to 3 discharge valves may be fitted to each cylinder, this way up to 3 zones can be protected.

See datasheet on previous page for items not listed here.


Pos. 12c

Name DV7a-2 M25 (300 bar)

DV7a-3 M25 (300 bar) DV7-2 W24 (200 bar) DV7-3 W24 (200 bar)

Quantity Item 6 304042

304043 302163 302164



File: Ci Manual 2024-11 Page 143 of 143