

Tool: SV22 Switch installation

General


This tool is used to install the position switches that detect if the SV22 is not in the fully closed position (switch on the left side of the valve on picture below) and when it is in the fully open position (switch at top of the valve in picture below).

Installation

For the closed position switch:

1. Remove the grey plastic cap on the left side of the SV22 and discard it,
2. Fit the SV22 switch instead until tight (approx. 2 to 5 Nm) using the Switch installation tool pictured below.

For the fully open switch, consult datasheet 305186 as the procedure is more complex.



Document: 305188 Tool SV22 Switch
installation

Product:
Tool

Id: KP
Rev: 13.04.10



Vølundsvej 17
DK- 3400 Hillerød
Tel +45 7022 2769
Fax +45 7023 2769

Text

1

2

3

4

5

6

7

8

9